

[Manuals.plus](#) /

› [KASIYLUX](#) /

› [KASIYLUX Smart Jumping Ball for Dogs Instruction Manual](#)

KASIYLUX Toopuerthur-88

KASIYLUX Smart Jumping Ball for Dogs Instruction Manual

Model: Toopuerthur-88

[Product Overview](#)

[Setup](#)

[Operation](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty &](#)

[Support](#)

1. PRODUCT OVERVIEW

The KASIYLUX Smart Jumping Ball is an interactive pet toy designed to provide engaging play for dogs. It features automatic shaking, vibration, and LED lighting to stimulate your pet's natural instincts. Constructed from high-strength Thermoplastic Rubber (TPR), this toy is bite-resistant and durable for active use.



Image 1.1: The KASIYLUX Smart Jumping Ball, available in orange and blue.

Key Features:

- **Automatic Shaking and Vibration:** Mimics real prey movements to attract and engage your pet.
- **High-Quality Bite-Resistant Material:** Made from durable TPR for extended play.
- **Smart Activation:** Activates manually or automatically upon your dog's interaction, rolling or bouncing for 5 minutes before entering standby.
- **LED Lighting Effect:** Bright LED light ring enhances visibility and fun in dim environments.
- **USB Fast Charging:** Ensures strong endurance for daily use.

2. SETUP

2.1 Charging the Device

Before first use, fully charge the Smart Jumping Ball. The device uses a Type-C charging port.

1. Rotate the casing counterclockwise to unscrew and open the ball.
2. Insert the Type-C charging cable into the port located inside the ball.
3. Allow the ball to charge completely. The LED indicator will change to show charging status (e.g., red for charging, green for full).



◀ Step 1

**Rotate Counterclockwise
To Unscrew The Casing**

Step 2 ▶

Insert Type-C Port



Image 2.1: Steps for charging the KASIYLUX Smart Jumping Ball. Unscrew the casing and insert the Type-C cable.

2.2 Initial Activation

Once charged, the ball can be activated manually or by your dog's interaction.

- To activate manually, press the power button located on the internal module.
- The ball will automatically activate when your dog bites or interacts with it.

3. OPERATION

3.1 Play Modes

The Smart Jumping Ball offers dynamic play modes to keep your dog entertained:

- **Automatic Movement:** The ball will roll and rotate or bounce wildly for 5 minutes.
- **Standby Mode:** After 5 minutes of activity, the ball enters standby mode to conserve battery. It will reactivate upon further interaction from your dog.
- **LED Lights:** The integrated LED lights illuminate during active play, making the toy visible and engaging, especially in low-light conditions.



Image 3.1: A dog actively playing with the KASIYLUX Smart Jumping Ball, which moves randomly to attract attention.

INTELLIGENT COMPANIONSHIP



Image 3.2: The Smart Jumping Ball provides intelligent companionship for pets, engaging them with its movements.



Image 3.3: Interactive design encourages dogs to bite and play, activating the toy's features.

3.2 Product Suitability

This product is suitable for toy, small, and medium-sized dogs. It is **not recommended** for dogs that are aggressive chewers or for large dog breeds due to potential safety concerns and durability limitations.

Product size

2.04in/5.2cm

1.57in

Shaky Ball

Ping Pong

Suitable for

Note: This product is **not suitable for crazy chewing dogs**
Not recommended for large dogs

| | | | |
|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
|  |  |  |  |
| Toy | Small | Medium | Large |
|  |  |  |  |

Image 3.4: Guide indicating the Smart Jumping Ball is suitable for toy, small, and medium dogs, but not large dogs or aggressive chewers.

3.3 Obstacle Avoidance

The ball is designed with random escape routes that automatically avoid obstacles, providing a dynamic and engaging hunting experience for your dog.



Random escape routes automatically avoid obstacles, allowing dogs to enjoy the fun of hunting and fully release their energy.

Image 3.5: The ball's random movements and obstacle avoidance keep dogs engaged and active.

3.4 Official Product Video

Your browser does not support the video tag.

Video 3.1: This video demonstrates the shaking and vibrating action of the KASIYLUX Smart Jumping Ball, showcasing its interactive features for dogs and cats.

4. MAINTENANCE

4.1 Cleaning

To ensure hygiene and longevity of the toy:

- Wipe the exterior of the ball with a damp cloth.
- Do not submerge the ball in water or use harsh cleaning agents.
- Ensure the charging port and internal components are dry before reassembling or charging.

4.2 Storage

Store the Smart Jumping Ball in a cool, dry place away from direct sunlight when not in use. Keep it out of reach of pets to prevent unsupervised chewing or damage.

5. TROUBLESHOOTING

If you encounter issues with your Smart Jumping Ball, please refer to the following common solutions:

| Problem | Possible Cause | Solution |
|--------------------------------|---------------------------------------|----------------------------------------------------------------------------------------------------------------------------------|
| Ball does not turn on or move. | Low battery or not activated. | Ensure the ball is fully charged. Press the power button or have your dog interact with it to activate. |
| Ball stops moving frequently. | Entering standby mode or low battery. | The ball is designed to enter standby after 5 minutes of activity. Re-engage your dog or recharge if battery is low. |
| LED lights are not working. | Battery issue or internal fault. | Ensure the ball is charged. If the issue persists, contact customer support. |
| Ball is damaged from chewing. | Excessive chewing by a strong chewer. | This toy is not recommended for aggressive chewers. Supervise play and discontinue use if damaged to prevent ingestion of parts. |

6. SPECIFICATIONS

| Feature | Detail |
|------------------------|--------------------------------------------|
| Product Dimensions | 0.02 x 0.02 x 0.02 inches |
| Item Model Number | Toopuerthur-88 |
| Material Type | Thermoplastic Rubber (TPR) |
| Item Weight | 0.17 Kilograms (approximately 5.93 ounces) |
| Color | Orange+Blue |
| Power Source | Rechargeable (USB Type-C) |
| Target Species | Dog |
| Breed Recommendation | Dog (Toy, Small, Medium) |
| Recommended Uses | Playing |
| Indoor/Outdoor Usage | Outdoor |
| Water Resistance Level | Not Water Resistant |

7. WARRANTY AND SUPPORT

7.1 Warranty Information

For detailed warranty information regarding your KASIYLUX Smart Jumping Ball, please refer to the product

packaging or contact the manufacturer directly. Keep your proof of purchase for any warranty claims.

7.2 Customer Support

If you have any questions, concerns, or require assistance with your product, please contact KASIYLUX customer support through the retailer where the product was purchased or visit the official KASIYLUX website for contact details.