

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [VGR](#) /

> [VGR Professional Grooming Kit User Manual](#)

**VGR VGR-001, VGR-977, VGR-378**

# VGR Professional Grooming Kit User Manual

Models: VGR-001 Hair Clipper, VGR-977 T-Blade Trimmer, VGR-378 Foil Shaver

Brand: VGR

## 1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using the VGR Professional Grooming Kit. Retain this manual for future reference.

- Avoid using the devices near the face or eyes, especially the trimmer and shaver blades.
- Do not ingest or inhale small parts. Keep out of reach of children.
- Not suitable for children without direct adult supervision.
- Clean the devices only with the provided cleaning brush. Do not immerse in water unless specified as waterproof.
- Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

## 2. PRODUCT OVERVIEW

The VGR Professional Grooming Kit is a comprehensive 3-piece set designed for precise hair cutting, trimming, and shaving. It includes a professional hair clipper, a T-blade trimmer, and a triple floating blade foil shaver, each equipped with advanced features for optimal performance.



Figure 2.1: The VGR Professional Grooming Kit, featuring the VGR-001 hair clipper, VGR-977 T-blade trimmer, and VGR-378 triple floating blade foil shaver, each resting on its respective charging base.

### Kit Components:

- **VGR-001 Professional Hair Clipper:** Designed for precise haircuts with adjustable taper lever and high-performance motor.
- **VGR-977 T-Blade Trimmer:** Ideal for clean trims, detailing, and zero-gapped precision.
- **VGR-378 Triple Floating Blade Foil Shaver:** Provides smooth shaves with hypoallergenic foils.

### Included Accessories:

- Various Guide Combs (for clipper and trimmer)
- Cleaning Brush
- Lubricating Oil
- Charging Bases (for each device)
- Protective Caps
- Type-C Charging Cables



Figure 2.2: The VGR-001 Professional Hair Clipper is shown alongside its comprehensive set of accessories, including various guide combs, a cleaning brush, blade oil, a charging adapter, and a USB cable, all neatly arranged with its charging base and packaging.



Figure 2.3: This image features the VGR-977 T-Blade Hair Trimmer, accompanied by its essential accessories: multiple guide combs for different lengths, blade oil, a cleaning brush, a USB charging cable, and its charging base, presented with its product box.



Figure 2.4: The VGR-378 Triple Floating Blade Foil Shaver is displayed with its charging base, USB charging cable, cleaning brush, and blade oil, along with its packaging, highlighting the complete set for a smooth shave.

### 3. SETUP AND CHARGING

#### Initial Charging:

Before first use, fully charge each device. The intelligent LED displays will show battery status.

- **Fast Charging:** Use a 5V=2A adapter for approximately 3 hours to fully charge.
- **Compatible with Slow Charging:** Use a 5V=1A adapter for approximately 6 hours to fully charge.
- When fully charged, the display will show 260/300 minutes (depending on the device) and emit three beeping sounds.

# TAPER LEVER

5 settings of cutting length:

1.0 / 1.5 / 2.0 / 2.5 / 3.0 mm

# CHARGING INSTRUCTIONS

- **Fast charging:**  
5V = 2A ⇒ 3 hours.
- **Compatible with slow charging:**  
5V = 1A ⇒ 6 hours.
- Show the usable time, when fully charged show 260/300, and with 3 beeping sound.



Figure 3.1: The VGR hair clipper is shown with its adjustable taper lever. Detailed charging instructions are provided, specifying fast charging (3 hours for 5V=2A) and slow charging (6 hours for 5V=1A), and indicating that a full charge shows 260/300 minutes of usable time with three beeping sounds.



Figure 3.2: A close-up of the VGR foil shaver's bottom, highlighting its convenient and safe USB-C charging port. Text overlays indicate a 1400 mAh Li-ion battery, 2.0 hours charge time, and 100 minutes running time, with icons for compatible charging sources like computer, laptop, USB charging, and power bank.

### Attaching Guide Combs:

For the hair clipper and trimmer, select the desired guide comb and securely attach it to the blade before use. Ensure it clicks into place to prevent movement during operation.

## 4. OPERATING INSTRUCTIONS

### VGR-001 Professional Hair Clipper:

- **Power On/Off:** Press the ON/OFF button to turn the clipper on or off.
- **Speed Adjustment:** The clipper features infinitely variable speed adjustment from 7000 RPM to 9000 RPM. Turn the center knob to adjust the speed in 100 RPM increments. The LED display will show the current RPM.
- **Taper Lever:** Use the adjustable taper lever for 5 settings of cutting length: 1.0mm, 1.5mm, 2.0mm, 2.5mm, and 3.0mm.
- **Front Light:** Click the front light button to activate the integrated light, improving visibility in poorly

lit conditions. Click again to turn off.

# LED LIGHTING OPERATION

**ON :** Click on the front light button and come with a beeping sound.

**OFF :** Click again and come with a beeping sound




Figure 4.1: A detailed view of the VGR hair clipper's LED display, indicating RPM and remaining battery minutes. The image also points out the front light button and ON/OFF buttons, illustrating how to activate the integrated light for improved visibility during use.

# DLC COATING FIX BLADE CERAMIC MOVING BLADE

Cutting more fast and smooth



Figure 4.2: This image highlights the advanced blade system of the VGR hair clipper, featuring a DLC (Diamond-Like Carbon) coated fixed blade and a ceramic moving blade, designed for fast and smooth cutting performance. An arrow indicates the 21-level adjustment operation.

## VGR-977 T-Blade Trimmer:

- **Power On/Off:** Use the power button to operate the trimmer.
- **LED Display:** The intelligent LED display shows speed and battery status.
- **Front Light:** The trimmer also features a front light for enhanced visibility during detailed trimming.

## VGR-378 Triple Floating Blade Foil Shaver:

- **Power On/Off:** Use the power button to operate the shaver.
- **High-Speed Motor:** Features a motor with speeds ranging from 7000 to 9000 RPM for an efficient shave.
- **LED Display:** The intelligent LED display shows speed and battery status.
- **Detachable Shaver Head:** For easy cleaning, press the release button and pull out the shaver head.

# DETACHABLE SHAVER HEAD

Press and hold the release button, pull out the shaver head for easy cleaning of stubble and debris with a brush



Figure 4.3: This image demonstrates the detachable shaver head of the VGR foil shaver. It shows how to press the release button and pull out the shaver head, revealing the internal blades, for easy cleaning of stubble and debris with a brush.

## 5. MAINTENANCE

### Cleaning the Blades:

1. Ensure the device is turned off and unplugged before cleaning.
2. Use the provided cleaning brush to remove hair clippings and debris from the blades and cutting head.
3. For the shaver, detach the head as shown in Figure 4.3 for thorough cleaning.

### Oiling the Blades:

Regularly apply a few drops of the included lubricating oil to the blades of the clipper and trimmer after cleaning. This helps maintain blade sharpness and ensures smooth operation.

1. Apply 1-2 drops of oil across the top of the blades.
2. Turn on the device for a few seconds to distribute the oil.

3. Wipe off any excess oil with a soft cloth.

## 6. TROUBLESHOOTING

If you encounter any issues with your VGR Professional Grooming Kit, please refer to the following common solutions:

- **Device not turning on:** Ensure the device is fully charged. Connect it to the charger and check the LED display for battery status.
- **Reduced cutting performance:** Clean the blades thoroughly to remove any accumulated hair or debris. Apply lubricating oil to the blades. If the issue persists, the blades may need replacement (contact customer support).
- **Unusual noise or vibration:** Turn off the device immediately. Check for any foreign objects lodged in the blades or motor area. Clean and oil the blades. If the noise continues, discontinue use and contact customer support.
- **Charging issues:** Ensure the charging cable and adapter are securely connected. Try using a different compatible USB-C cable or power source.

For issues not covered here, please refer to the Warranty and Support section for assistance.

## 7. SPECIFICATIONS

Feature	Detail
Brand	VGR
Models Included	VGR-001 (Hair Clipper), VGR-977 (Trimmer), VGR-378 (Foil Shaver)
Battery Type	Lithium-Ion
Total Runtime	Approximately 4 hours and 20 minutes (combined for all devices)
Clipper Speed	Up to 9,000 RPM (adjustable)
Shaver Speed	7,000 - 9,000 RPM
Charging Interface	Type-C USB
Manufacturer	VGR
ASIN	B0DPSWDTDG

## 8. WARRANTY AND SUPPORT

VGR stands behind the quality of its products. Your VGR Professional Grooming Kit comes with a warranty and dedicated customer support.




Figure 8.1: VGR offers a 1-Year Warranty and 24-Hour Support for its products, ensuring customer satisfaction and assistance.

- **Warranty Period:** This product is covered by a 1-year warranty from the date of purchase.
- **Customer Support:** For any inquiries, technical assistance, or warranty claims, please contact VGR customer support.
- **Seller Information:** The product is sold by VGR-VOVAGER and fulfilled by Amazon.

For the most up-to-date contact information, please refer to the product listing page on Amazon or the official VGR website.