

[Manuals.plus](#) /

› [LIDYUK](#) /

› LIDYUK White 6-Drawer Dresser with Charging Station and LED Lights User Manual (Model LID-6DG-W)

## LIDYUK LID-6DG-W

# LIDYUK White 6-Drawer Dresser with Charging Station and LED Lights

Model: LID-6DG-W

## 1. INTRODUCTION

---

Thank you for choosing the LIDYUK White 6-Drawer Dresser. This modern furniture piece is designed to provide ample storage and convenience with its integrated charging station and customizable LED lighting. This manual provides essential information for assembly, operation, maintenance, and troubleshooting to ensure safe and optimal use of your dresser.

Please read this manual thoroughly before assembly and retain it for future reference.



Image 1.1: The LIDYUK White 6-Drawer Dresser in a bedroom setting.

## 2. SAFETY INFORMATION

To prevent injury and damage to the product, please observe the following safety guidelines:

- **Anti-Tip Kit:** Always install the included anti-tip kit to secure the dresser to a wall. This is crucial to prevent the dresser from tipping over, especially in households with children or pets.
- **Weight Capacity:** Do not exceed the specified weight limits for the top surface and drawers. Overloading can compromise stability and structural integrity.
- **Placement:** Place the dresser on a flat, stable, and level surface. Uneven surfaces can lead to instability.
- **Electrical Safety:** Ensure the charging station is connected to a properly grounded electrical outlet. Do not overload the power outlets or USB ports. Keep liquids away from the charging station.
- **Assembly:** Follow all assembly instructions carefully. Do not skip steps or use unauthorized parts. Two adults are recommended for assembly.

# Anti-tip kit adds extra stability

## Protect your kids and pets




Image 2.1: Illustration of the anti-tip kit installation and the importance of securing the dresser.

### 3. SETUP AND ASSEMBLY

The LIDYUK dresser requires assembly. All necessary hardware and a detailed instruction manual are included in the packaging. Please ensure all parts are present before beginning assembly.

#### 3.1 Package Contents

Verify that all components are included:

- Dresser panels (pre-drilled and pre-numbered)
- 6 Drawer components
- Drawer slides
- Gold handles
- Charging station unit (2 AC outlets, 2 USB ports)
- LED light strip
- LED remote control
- Anti-tip kit

- Assembly hardware (screws, dowels, cam locks, etc.)
- Instruction manual

### 3.2 Assembly Steps

1. **Unpack and Organize:** Lay out all parts on a clean, soft surface to prevent scratches. Group similar hardware.
2. **Assemble Frame:** Follow the numbered steps in the provided manual to construct the main dresser frame.
3. **Install Drawer Slides:** Attach the drawer slides to the dresser frame and drawer sides as instructed.
4. **Assemble Drawers:** Construct each of the 6 drawers according to the manual.
5. **Install Charging Station:** Secure the charging station into the designated cutout on the top panel.
6. **Attach LED Lights:** Adhere the LED light strip to the underside of the top shelf as shown in the manual.
7. **Insert Drawers:** Carefully slide the assembled drawers into their respective slots.
8. **Install Handles:** Attach the gold handles to each drawer front.
9. **Secure Anti-Tip Kit:** Mount the anti-tip kit to the back of the dresser and to a wall stud using the provided hardware.

**Estimated Assembly Time:** Approximately 2 hours for two adults.

## 4. OPERATING INSTRUCTIONS

---

### 4.1 Drawer Usage

The dresser features 6 spacious drawers designed for smooth operation. To open, gently pull the handle. To close, push firmly until the drawer is fully seated. Avoid slamming drawers to prolong the life of the slides.



Image 4.1: Drawers provide ample storage for various items.



Image 4.2: Detail of a drawer interior and slide mechanism.

## 4.2 Charging Station

The integrated charging station provides convenient power access. It includes 2 standard AC outlets (120V/12A) and 2 USB ports (5V/2A MAX).

- **To Use:** Plug the dresser's power cord into a wall outlet. Then, plug your devices into the AC outlets or USB ports on the dresser's top surface.
- **Compatibility:** The USB ports are suitable for charging most smartphones, tablets, and other USB-

powered devices.



Image 4.3: Integrated charging station with AC outlets and USB ports.



Image 4.4: Detailed view of the charging station's ports.

### 4.3 LED Lights Operation

The dresser features multi-color RGB LED lights integrated into the open shelves. These lights can be controlled via the included remote control or a compatible smartphone application.

- **Power On/Off:** Use the power button on the remote or app to turn the lights on or off.
- **Color Selection:** Choose from 16 million colors using the color wheel or preset color buttons.

- **Brightness Adjustment:** Increase or decrease the light intensity.
- **Mode Selection:** Select from various dynamic modes such as Flash, Jump, or Fade, and adjust their speed.



Image 4.5: LED lights in operation with remote and app control options.



Image 4.6: Detail of the LED light strip.

Your browser does not support the video tag.

Video 4.1: Demonstration of the LIDYUK dresser's features, including LED lighting, charging station, and storage capacity.

## 5. MAINTENANCE

---

Proper care will help maintain the appearance and longevity of your dresser.

- **Cleaning:** Wipe the dresser surfaces with a damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Dusting:** Regularly dust with a soft, dry cloth.
- **Spills:** Clean up spills immediately to prevent staining or damage to the wood finish.
- **Hardware Check:** Periodically check and tighten all screws and fasteners to ensure stability.

## 6. TROUBLESHOOTING

---

If you encounter issues with your dresser, refer to the following common problems and solutions:

- **Drawers do not close smoothly:**
  - Ensure drawer slides are correctly aligned and installed.
  - Check for any obstructions within the drawer or on the slides.
  - Verify that the dresser is on a level surface.
- **LED lights are not working:**
  - Check if the dresser's main power cord is securely plugged into a wall outlet.
  - Ensure the LED light strip is properly connected to its power source.
  - Replace the remote control battery if necessary.
- **Charging station is not providing power:**
  - Confirm the dresser's power cord is plugged in and the wall outlet is functional.
  - Check if the device you are trying to charge is properly connected and functional.
  - Avoid overloading the charging station with too many high-power devices.

For issues not covered here, please contact LIDYUK customer support.

## 7. SPECIFICATIONS

---



Image 7.1: Product dimensions and weight capacities.

Feature	Detail
Brand	LIDYUK
Model Number	LID-6DG-W
Product Dimensions	15.8"D x 47.3"W x 32.1"H
Color	White
Furniture Finish	Wood
Number of Drawers	6
Drawer Type	Under Mounted Slide
Charging Station	2 AC Outlets (120V/12A), 2 USB Ports (5V/2A MAX)
LED Lights	Multi-color RGB, Remote/App Control
Item Weight	97 Pounds
Assembly Required	Yes

Feature	Detail
Product Care Instructions	Wipe with Damp Cloth

## 8. WARRANTY AND SUPPORT

---

For warranty information, product support, or to order replacement parts, please contact LIDYUK customer service. Refer to your purchase documentation for specific warranty terms and contact details.

You can also visit the official LIDYUK store for more information: [LIDYUK Store](#)