

## Gotopceed T070

# Rechargeable Ceiling Light User Manual

Model: T070 | Brand: Gotopceed

## INTRODUCTION

Thank you for purchasing the Gotopceed T070 Rechargeable Ceiling Light. This versatile lighting solution offers both RGB color-changing and white light options, along with magnetic and screw mounting for easy installation. Featuring a motion sensor and remote control, it is ideal for various indoor spaces such as showers, bathrooms, closets, and porches. Please read this manual thoroughly before installation and use to ensure proper operation and longevity of your product.

## SAFETY INFORMATION

- Do not disassemble or modify the light. This may cause damage, electric shock, or fire.
- Keep the light away from extreme temperatures, direct sunlight, and high humidity.
- Use only the provided USB cable for charging.
- Ensure the mounting surface is clean, dry, and stable before installation.
- This product is designed for indoor use. Avoid exposure to direct water spray or submersion.
- Keep out of reach of children.

## WHAT'S IN THE BOX

The package includes the following components:

- 2 x Rechargeable Motion Sensor Light
- 2 x Remote Control
- 2 x USB Cable
- 2 x Magnet Strip
- 4 x Sticky Back Pads
- 1 x User Manual



Image: The complete package contents of the Gotopceed T070 Rechargeable Ceiling Light.

## SETUP AND INSTALLATION

The Gotopceed T070 offers two convenient installation methods: magnetic mounting and sturdy screw mounting.

### **Magnetic Mounting (Recommended for smooth surfaces)**

1. Clean the desired installation surface thoroughly to ensure it is free of dust and moisture.
2. Peel off the protective film from one side of the sticky back pad and attach it to the magnet strip.
3. Peel off the protective film from the other side of the sticky back pad and firmly press the magnet strip onto the clean ceiling or wall surface.
4. Align the light with the magnet strip and allow the strong magnets to securely attach the light to the strip.

# No Wires & Magnetic Mounting

Easy stick-on mounting and sturdy drill mounting



Image: Illustration of the magnetic mounting process, highlighting the ease of installation.

## Screw Mounting (Recommended for uneven or peeling surfaces)

1. Position the magnet strip on the desired installation spot on the ceiling or wall.
2. Mark the two screw holes on the surface through the holes in the magnet strip.
3. Drill pilot holes at the marked spots (if necessary, depending on wall material).
4. Secure the magnet strip to the surface using appropriate screws (not explicitly listed as included, but implied by "sturdy screw mount").
5. Align the light with the secured magnet strip and allow the strong magnets to securely attach the light.

## OPERATING INSTRUCTIONS

### Powering On/Off and Modes

The light features two primary working modes: Sensor Mode and Stay On Mode, controlled via the included remote.

- **Sensor Mode:** In this mode, the light automatically turns on when motion is detected within 9-16 feet and turns off after 20 seconds of no movement. This mode is energy-efficient and ideal for areas with intermittent use.

- **Stay On Mode:** For continuous illumination, set the light to 'ON' mode using the remote control. The light will remain on until manually turned off with the remote.



**Motion Sensor**  
AUTO ON

Image: The motion sensor feature automatically activating the light upon detecting movement.



Image: Using the remote control to manually turn the light on or off, or to adjust settings.

## Remote Control Functions

The remote control provides comprehensive control over the light's features:

- **ON/OFF:** Turn the light on or off.
- **Brightness Adjustment:** Increase or decrease the light intensity.
- **Color Changing:** Select from 12 RGB colors or cool white light.
- **Color Changing Modes:**
  - *SMOOTH:* Gradually transitions between colors.
  - *FLASH:* Quickly cycles through colors.
- **Timer Function:** Set the light to turn off automatically after a specified duration (e.g., 15, 30, 60 minutes).



Image: The light displaying 12 RGB colors and white light options, with dimming capability.

## Charging the Light

The light is equipped with an 8000mAh high-capacity rechargeable battery. When the battery is low, connect the provided USB cable to the light's charging port and a suitable USB power source (e.g., computer, wall adapter). A full charge typically takes approximately 4 hours.

Battery life varies depending on usage:

- **Stay On Mode:** 7-10 hours
- **Motion Sensor Mode:** 30-60 days (depending on brightness and frequency of use)

# Rechargeable & Long Lasting

# 8000mAh



Image: The light connected for USB charging, illustrating its long-lasting battery performance.

## MAINTENANCE

- **Cleaning:** Wipe the light with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Recharge the light when the brightness noticeably diminishes.
- **Storage:** If storing the light for an extended period, charge it fully every 3 months to maintain battery health.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on.	Low battery; Motion sensor not activated or blocked; Incorrect mode.	Charge the light; Ensure motion sensor is clear and activated; Switch to 'ON' mode or check sensor settings.

Problem	Possible Cause	Solution
Remote control not working.	Remote battery low; Obstruction between remote and light; Remote out of range.	Replace remote battery (if applicable); Ensure clear line of sight; Move closer to the light.
Light falls from mounting.	Adhesive not strong enough for surface; Uneven or peeling surface.	Re-apply with stronger adhesive pads, or use screw mounting method for better security.
Motion sensor is too sensitive/not sensitive enough.	Sensor settings need adjustment.	Refer to remote control instructions for adjusting sensor sensitivity (if available, not explicitly detailed in feature bullets).

## SPECIFICATIONS

- **Brand:** Gotopceed
- **Model Name:** 2 Pack Rechargeable Shower Ceiling Light
- **Model Number:** T070
- **Color:** RGB Color & White Light
- **Material:** Plastic
- **Style:** USB Rechargeable & Magnetic Suction
- **Light Fixture Form:** Close to Ceiling
- **Product Dimensions:** 7.5"L x 7.5"W x 0.5"H
- **Item Weight:** 1.69 pounds
- **Power Source:** Battery Powered
- **Battery Capacity:** 8000mAh (Built-in)
- **Charging Time:** Approx. 4 hours
- **Battery Life (Stay On):** 7-10 hours
- **Battery Life (Motion Sensor):** 30-60 days
- **Switch Type:** Motion Sensor / Remote Control
- **Installation Type:** Magnetic Mounting & Drill Mounting
- **Indoor/Outdoor Usage:** Indoor
- **Special Feature:** Color Changing

## WARRANTY AND SUPPORT

This product does not come with an explicit manufacturer's warranty period stated in the provided information. For any product inquiries, technical support, or assistance with installation and operation, please contact Gotopceed customer service through the retailer's platform where the product was purchased. Please retain your purchase receipt for any potential support claims. Optional protection plans may be available for purchase separately through the retailer.

