

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [YUMAZLA](#) /

› [YUMAZLA 86-inch Phone Tripod and Selfie Stick Instruction Manual \(Model YMPT05\)](#)

YUMAZLA YMPT05

YUMAZLA 86-inch Phone Tripod and Selfie Stick

Model: YMPT05

INTRODUCTION

This manual provides detailed instructions for the safe and effective use of your YUMAZLA 86-inch Phone Tripod and Selfie Stick (Model YMPT05). Please read this manual thoroughly before operating the device and retain it for future reference.



Image: The YUMAZLA 86-inch Phone Tripod and Selfie Stick shown in both its extended tripod configuration and compact selfie stick form, alongside its detachable remote control.

WHAT'S IN THE BOX

- YUMAZLA 86-inch Phone Tripod & Selfie Stick

- Detachable Bluetooth Remote Control
- Standard Smartphone Holder (integrated)
- User Manual (this document)

SETUP INSTRUCTIONS

1. **Unfold the Tripod Legs:** Gently pull the three legs outwards from the main shaft until they are fully extended and stable. The wide base design ensures stability.
2. **Extend the Main Shaft:** Loosen the locking knob located above the tripod legs. Pull the telescopic shaft upwards to extend it to your desired height. Tighten the locking knob to secure the shaft in place. The tripod can extend up to 2.1 meters (86 inches).
3. **Attach Smartphone Holder:** The standard smartphone holder is integrated at the top. Ensure it is securely fastened. It can be rotated for horizontal or vertical phone placement.
4. **Insert Smartphone:** Gently expand the smartphone holder and insert your smartphone. Ensure the phone is centered and securely gripped by the holder. The holder is compatible with smartphones ranging from 3.7 to 7 inches.
5. **Pair Bluetooth Remote:**
 - Remove the remote control from its storage slot on the tripod.
 - Turn on the remote control (usually by pressing and holding the button). An indicator light will blink.
 - On your smartphone, go to Bluetooth settings and search for available devices.
 - Select the device named "AB Shutter3" or similar to pair. The indicator light on the remote will stop blinking once paired.

Embeddable Remote Control

Simple to find, convenient and practical



Image: Detachable Bluetooth remote control for easy photo and video capture, compatible with most smartphones.

OPERATING INSTRUCTIONS

1. Tripod Mode

For stable, hands-free recording or photography, extend the tripod legs and adjust the height as described in the Setup section. This mode is ideal for:

- Video recording (vlogs, tutorials)
- Group photos
- Time-lapse photography
- Live streaming

3 MODELS

Meet your different needs



Selfie Mode



Handheld Mode



Tripod Mode



Image: The tripod's versatility, showcasing its use as a selfie stick, handheld device, and stable tripod.

2. Selfie Stick Mode

To use as a selfie stick, collapse the tripod legs and hold the main shaft. Extend the shaft to your desired length. Use the Bluetooth remote control to capture photos or start/stop video recording.

3. Handheld Mode

For quick, on-the-go shots, keep the tripod legs folded and the shaft retracted. This provides a comfortable grip for handheld filming or photography.

4. Using the Cold Shoe Port

The smartphone holder features a cold shoe port at the top. This allows you to attach additional accessories such as a fill-in light or an external microphone (sold separately) to enhance your content quality.

Multi-functional Cell Phone Holder

Practical gadgets



Fill-in Light



Microphones



3.7"-7" Smartphones

1/4 standard screws



GoPro



Camera



Ring Light



Image: The phone holder's cold shoe mount and 1/4" screw compatibility for various accessories.

5. Height Adjustment and Stability

The tripod's extendable legs allow for height adjustment from ground level to eye-level. The unique design with 2cm wide legs, 6cm longer than average, provides enhanced stability, preventing accidental tipping even when fully extended.



Image: Detail of the tripod's wide and long legs, designed for superior stability.

MAINTENANCE

- **Cleaning:** Wipe the tripod with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.

- **Storage:** When not in use, collapse the tripod to its most compact form and store it in a dry place away from direct sunlight.
- **Battery:** The Bluetooth remote control requires 1 LR44 battery (included). Replace the battery when the remote's indicator light fails to illuminate or blinks erratically.

TROUBLESHOOTING

- **Remote Control Not Pairing:**
 - Ensure the remote control is turned on and its battery is not depleted.
 - Make sure Bluetooth is enabled on your smartphone.
 - Try unpairing and re-pairing the remote control in your smartphone's Bluetooth settings.
 - Ensure no other Bluetooth devices are interfering with the connection.
- **Tripod Instability:**
 - Ensure the tripod legs are fully extended and locked into position.
 - Verify that the main shaft's locking knob is securely tightened after adjusting height.
 - Avoid placing the tripod on uneven surfaces.
- **Phone Holder Not Gripping:**
 - Ensure your smartphone is within the compatible size range (3.7-7 inches).
 - Check for any obstructions in the phone holder's grip.

SPECIFICATIONS

Brand	YUMAZLA
Model Name	YMPT05
Maximum Height	210 Centimeters (86 inches)
Item Weight	0.66 Kilograms (1.46 pounds)
Material	Aluminum
Color	Black
Compatible Devices	Smartphone
Special Features	Adjustable, Compact, Portable, Rotatable, Telescopic
Tripod Head Type	Ball Heads
Leg Diameter	2.00 centimeters
Batteries	1 LR44 battery (included)

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact YUMAZLA customer service directly. Contact details can typically be found on the manufacturer's official website or through your point of purchase.