

[Manuals.plus](#) /

> [Bezseller](#) /

> Bezseller 3 Pieces Patio Furniture Set Instruction Manual

## Bezseller BSOT-001BK

# Bezseller 3 Pieces Patio Furniture Set Instruction Manual

Model: BSOT-001BK

Brand: Bezseller

## 1. INTRODUCTION

Thank you for choosing the Bezseller 3 Pieces Patio Furniture Set. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure safe and enjoyable use of your new outdoor furniture. This set includes two comfortable chairs with strapped cushions and a convenient coffee table, perfect for enhancing your outdoor living space.



Figure 1.1: Bezseller 3 Pieces Patio Furniture Set (Black)

## 2. SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- **Assembly Precaution:** Do not fully tighten all screws initially. Instead, align all screws properly first. Hand-tighten each screw vertically to prevent difficulties in tightening due to misalignment. Final tightening should

only occur after all components are loosely assembled.

- Ensure all bolts and nuts are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not stand on the furniture.
- Do not exceed the weight capacity of 250 lbs per chair.
- Place the furniture on a flat, stable surface to prevent tipping.
- Move cushions indoors during heavy rain or extreme weather conditions to prolong their lifespan.

### 3. PACKAGE CONTENTS

Verify that all components listed below are present before beginning assembly. If any parts are missing or damaged, please contact customer support.




Figure 3.1: Included Components and Dimensions

- 2 x Single Chairs (Components A, B, C, D, J3, I)
- 1 x Side Table (Components E, F, G, H, J1, J2, I)
- Assembly Hardware (Screws, Washers, Allen Wrench)
- Instruction Manual

## 4. ASSEMBLY INSTRUCTIONS

---

Assembly is straightforward and typically takes about 30 minutes. Follow these steps carefully.

### 4.1. Chair Assembly

1. Identify all chair components: Seat (D), Backrest (C), Left Armrest (A), Right Armrest (B), and associated screws (J3) and washers (I).
2. Attach the backrest (C) to the seat (D) using the designated screws. **Remember to only hand-tighten screws initially (3-5 turns) to allow for adjustment.**
3. Connect the armrests (A and B) to the assembled seat and backrest. Ensure all holes align.
4. Once all screws are partially threaded into their holes, begin tightening them fully with the provided Allen wrench. Tighten screws evenly to prevent misalignment.
5. Repeat for the second chair.

Your browser does not support the video tag.

Video 4.1: 3 Pcs Assembly Instructions. This video demonstrates the step-by-step assembly process for the chairs and table.

### 4.2. Side Table Assembly

1. Identify side table components: Top Frame (G), Bottom Frame (F), Crossbar (E), Tempered Glass Top (H), and associated screws (J1, J2) and washers (I).
2. Attach the top frame (G) to the bottom frame (F) using screws, ensuring the crossbar (E) is installed for stability.
3. Place the tempered glass top (H) onto the assembled frame. The glass top is designed to sit securely without additional fasteners.

## 5. OPERATING INSTRUCTIONS

---

Your Bezseller patio set is designed for comfort and durability in outdoor environments.

- **Cushion Security:** The cushions feature secure straps that attach to the chair legs. This design prevents them from slipping during use, even with active movement.
- **Comfort:** The cushions are made from high-density foam and soft polyester fabric, providing a comfortable seating experience.
- **Adjustable Foot Pads:** The chairs are equipped with adjustable foot pads to ensure stability on uneven surfaces. Rotate the pads to level the chairs.



Comfortable support  
for your back



Sleek arc  
craftsmanship



Enhanced  
support frame



Adjustable foot pad

# No Fatigue

from sitting for a long time



Sleek



Stable



long-lasting



# Tempered Glass Side Table



Easy to Clean



Crossbar  
support



Fixed suction  
cups



Scratch-resistant



Safe



High Gloss




Figure 5.1: Secure Cushions and Tempered Glass Table


## 6. MAINTENANCE


Proper maintenance will extend the life and appearance of your patio furniture set.

- **Cleaning:** The PE rattan and steel frame can be wiped clean with a damp cloth and mild soap. The tempered glass top is also easy to wipe down.
- **Cushion Care:** The cushions are splash-proof and have removable, washable covers. For best results, hand wash or machine wash on a gentle cycle with cold water, and air dry.
- **Weather Resistance:** The powder-coated steel frame provides superior rust resistance, and the PE rattan is weather-resistant. While designed for outdoor use, it is recommended to move cushions indoors during heavy rain or prolonged periods of non-use to ensure longevity.

- **Color Fastness:** The PE rattan is designed with 2000h+ color fastness, making it resistant to fading in sunlight.

  
 Hand-made

  
 Weather Resistant

  
 Easy to Clean

Ours	Others
<input checked="" type="checkbox"/> Wider wicker	<input type="checkbox"/> Thin rattan
<input checked="" type="checkbox"/> <b>2000h+</b> Color fastness	<input type="checkbox"/> Fade in the sun
<input checked="" type="checkbox"/> More Stylish Type	<input type="checkbox"/> Poor texture

Figure 6.1: Durable and Easy-to-Maintain Materials

## 7. TROUBLESHOOTING

If you encounter issues during assembly or use, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Holes do not align during assembly.	Screws were tightened too early or unevenly.	Loosen all screws on the affected component. Re-align parts and hand-tighten all screws partially before fully tightening them evenly. Refer to the assembly video for visual guidance.
Chair feels wobbly after assembly.	Screws are not fully tightened or foot pads are uneven.	Ensure all assembly screws are fully tightened. Adjust the foot pads on the bottom of the chair legs to stabilize on uneven surfaces.
Cushions slide off the chairs.	Cushion straps are not secured.	Utilize the integrated straps on the cushions to tie them securely to the chair legs.

Your browser does not support the video tag.

Video 7.1: Assembly Troubleshooting. This video addresses common issues like screw alignment during assembly.

## 8. SPECIFICATIONS

Feature	Detail
Brand	Bezseller
Model Number	BSOT-001BK
Material	Powder-coated Steel Frame, PE Rattan, Tempered Glass (Table Top), Polyester Fabric (Cushions)
Color	Black
Product Dimensions (L x W x H)	24.4 x 22.6 x 31.3 inches
Item Weight	33 pounds
Special Features	Water-resistant, Strap-secured Cushion, Rust-resistant, Long-lasting
Max. Weight Capacity (per chair)	250 lbs

## 9. WARRANTY & SUPPORT

For any product inquiries, missing parts, or support, please contact Bezseller customer service directly. Information regarding extended protection plans may be available through your retailer.

You can visit the official Bezseller store for more products and support: [Bezseller Store](#)