

Gaimoo GM700

Gaimoo GM700 Projector Instruction Manual

Model: GM700 | Brand: Gaimoo

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Gaimoo GM700 Projector. Designed for both home and outdoor use, the GM700 features advanced auto-focus and auto-keystone correction, 3600 rotatable stand, and built-in smart applications for a seamless entertainment experience.

PRODUCT OVERVIEW

Familiarize yourself with the components of your GM700 projector.

Front View



The main image shows the Gaimoo GM700 projector from the front, highlighting its lens, control panel, and the included remote control. Various streaming service logos (Netflix, Prime Video, YouTube, Disney+) are displayed in the background, indicating built-in app support.

Side and Rear Views

Immersive 360° Surround Audio Dual Stereo Speakers

Deliver Ultra-High Definition & Super Realistic of Sound Quality

HiFi Audio


3D Stereo Sound

15W Dual Speakers



This image displays the side of the projector, illustrating its connectivity options such as HDMI, USB, and audio ports. The design emphasizes portability and ease of access to connections.

3600 Rotatable Stand



The projector features an integrated 360° rotatable stand, allowing projection onto walls, ceilings, or any desired surface. This image demonstrates the projector's flexibility in various viewing angles, including ceiling projection while lying in bed.

Auto Focus and Auto Keystone

Netflix Official Licensed – Unique OS



Unique Personalised Settings from **WhaleOS**



Endless Film and TV Resources



One-Click Access to Popular Websites and Games



Netflix Official Licensed



Online Upgrade

Super Device Compatibility



One-Click Access to Projector

The GM700 is equipped with auto-focus and auto-keystone correction, ensuring a clear and perfectly rectangular image regardless of the projection angle. This feature simplifies setup and maintains optimal picture quality.

SETUP

Follow these steps for initial setup:

1. **Power Connection:** Connect the power adapter to the projector and plug it into a power outlet.
2. **Placement:** Place the projector on a stable surface. The 3600 rotatable stand allows for flexible positioning.
3. **Initial Power On:** Press the power button on the remote control or the projector. The projector will automatically perform auto-focus and auto-keystone correction to optimize the image.
4. **Network Connection:** Navigate to the settings menu to connect to your Wi-Fi network. This is essential for accessing built-in smart applications.

OPERATING INSTRUCTIONS

Your Gaimoo GM700 Projector features a smart operating system with pre-installed applications.




The projector runs on a unique OS (WhaleOS) with a user-friendly interface. It comes pre-loaded with officially licensed Netflix, Prime Video, YouTube, and Disney+ for immediate access to content. Additional apps can be downloaded from the built-in App Store.

- **Remote Control:** Use the included remote control for navigation. Dedicated buttons provide one-click access to popular streaming services.
- **Navigation:** Use the directional pad and OK button on the remote to browse the interface.
- **Settings:** Access the settings menu to adjust display, audio, network, and system preferences.

Screen Size Adjustment

50"-300" 1080P 4K Support Giant Screen



The projector supports screen sizes from 50 to 300 inches. The auto-focus and auto-keystone features will adjust the image automatically. For manual adjustments, refer to the display settings in the menu.

CONNECTIVITY

The GM700 offers multiple connectivity options:

- **HDMI:** Connect external devices such as laptops, gaming consoles, or Blu-ray players using an HDMI cable.
- **USB:** Play media files directly from a USB drive.
- **Wi-Fi:** Connect to your home network for online streaming and updates. Supports Wi-Fi 6 for smoother visuals.
- **Bluetooth 5.2:** Connect external Bluetooth speakers or headphones for enhanced audio. The projector can also function as a standalone Bluetooth speaker.
- **Screen Mirroring (TV CAST, Miracast, Airplay):** Cast content from your iPhone, iPad, Android smartphone, or tablet using the TV CAST app (downloadable via remote control), Miracast, or Airplay.

AUDIO FEATURES

Experience immersive sound with the GM700's integrated audio system.

Immersive 360° Surround Audio Dual Stereo Speakers

Deliver Ultra-High Definition & Super Realistic of Sound Quality

HiFi Audio

3D Stereo Sound

15W Dual Speakers



The projector is equipped with 2 x 15W high-quality stereo speakers, delivering 3600 3D stereo high-fidelity audio. This provides an immersive sound experience for movies, music, and games. You can also connect external speakers via Bluetooth for a full range of immersive sound experiences.

MAINTENANCE

To ensure the longevity and optimal performance of your projector, follow these maintenance guidelines:

- **Cleaning the Lens:** Gently wipe the projector lens with a soft, lint-free cloth designed for optical surfaces. Do not use abrasive cleaners or excessive force.
- **Cleaning the Exterior:** Use a soft, dry cloth to clean the exterior of the projector. Avoid using liquid cleaners directly on the device.
- **Ventilation:** Ensure that the ventilation openings are not blocked to prevent overheating. Keep the projector in a well-ventilated area.
- **Storage:** When not in use for extended periods, store the projector in a cool, dry place, away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

If you encounter issues with your Gaimoo GM700 Projector, refer to the following common solutions:

Problem	Possible Cause	Solution
No image projected	Power cable disconnected, input source incorrect, lens cap on.	Check power connection. Select correct input source (HDMI, USB). Remove lens cap.
Image is blurry	Out of focus, projection distance incorrect.	Allow auto-focus to complete. Adjust projector distance from the screen/wall.
Image is distorted (trapezoid shape)	Projector not perpendicular to the screen.	Allow auto-keystone correction to complete. Adjust projector position.
No sound	Volume too low, external speakers not connected, incorrect audio output.	Increase volume. Check Bluetooth connection for external speakers. Verify audio output settings.
Cannot connect to Wi-Fi	Incorrect password, out of range, network issue.	Re-enter password. Move projector closer to router. Restart router.

SPECIFICATIONS

Feature	Detail
Brand	Gaimoo
Model Number	GM700
Native Resolution	1920 x 1080 (1080P FHD)
4K Support	Yes
Brightness	400 ANSI Lumens
Contrast Ratio	20000:1
Connectivity	HDMI, USB, Wi-Fi 6, Bluetooth 5.2, 3.5mm Jack
Special Features	Auto Focus, Auto Keystone Correction, 3600 Rotatable Stand, Built-in Smart OS (Netflix Officially Licensed), Dual 15W Speakers, Dolby Audio
Product Dimensions	6.9 x 7.9 x 11.2 inches
Item Weight	2.86 pounds

WHAT'S IN THE BOX

- 1 x Gaimoo GM700 Projector
- 1 x HDMI Cable

- 1 x Power Adapter with Cable
- 1 x Remote Control
- 1 x User Manual (this document)

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official Gaimoo website or contact their customer service directly. Details can typically be found on the product packaging or the manufacturer's official support page.

© 2024 Gaimoo. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question