

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [DCHK](#) /

› **DCHK Haribo HBT-01 Wireless Earbuds User Manual**

DCHK HBT-01

DCHK Haribo HBT-01 Wireless Earbuds User Manual

Model: HBT-01

1. IMPORTANT SAFETY INFORMATION

Please read all safety instructions carefully before using your DCHK Haribo Wireless Earbuds. Keep this manual for future reference.

- Do not expose the earbuds or charging case to extreme temperatures, direct sunlight, or fire.
- Avoid dropping or applying excessive force to the device.
- Do not disassemble or modify the product. This may void the warranty and pose a safety risk.
- Keep the product away from water and moisture. The earbuds have an IPX4 rating, meaning they are resistant to splashing water, but are not waterproof.
- Use only the provided USB-C charging cable.
- Listening at high volume levels for extended periods can cause hearing damage. Adjust volume to a safe level.

2. PACKAGE CONTENTS

Verify that all items are present in your package:

- DCHK Haribo Wireless Earbuds (Left and Right)
- Charging Case
- USB-C to USB-A Charging Cable
- 3 Sizes of Eartips (Small, Medium, Large)
- User Manual

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your DCHK Haribo Wireless Earbuds.



This image displays the DCHK Haribo Wireless Earbuds in their open yellow charging case. The earbuds are yellow with black ear tips, and a small red gummy bear charm is attached to the side of the charging case.



This image shows two views of the yellow charging case for the DCHK Haribo Wireless Earbuds. One view shows the top with a small indicator light, and the other shows the bottom with the USB-C charging port.

Earbud Components:

- **Touch Control Area:** For managing music playback, calls, and voice assistant.
- **Microphone:** For calls and voice commands.
- **Charging Contacts:** Connects to the charging case.
- **Ear Tip:** Replaceable silicone tips for comfort and sound isolation.

Charging Case Components:

- **Charging Port:** USB-C port for charging the case.
- **LED Indicator:** Displays charging status and battery level.
- **Earbud Slots:** Holds and charges the earbuds.

4. SETUP

4.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and charging case.

1. Place the earbuds into the charging case. Ensure the charging contacts align.
2. Connect the USB-C charging cable to the charging port on the case and the other end to a USB power source.
3. The LED indicator on the case will show the charging status. A full charge typically takes 1.5 hours.

Fast charging, long-lasting performance

1.5H

Charging time

4H

Single Play Time

12H

With charging case



This graphic highlights the battery performance of the DCHK Haribo Wireless Earbuds. It shows a 1.5-hour charging time, 4 hours of single play time, and up to 12 hours of total play time with the charging case.

4.2 Pairing with a Bluetooth Device

The earbuds feature auto-pairing for convenient connection.

1. Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your device (smartphone, tablet, laptop), enable Bluetooth.
3. Search for available Bluetooth devices and select "HBT-01" from the list.
4. Once connected, you will hear a confirmation tone, and the LED indicator on the earbuds may change.
5. The earbuds will automatically reconnect to the last paired device when taken out of the case, if Bluetooth is enabled on the device.

Bluetooth 5.3

32 ft

Improved Transmission range



Enhanced Connection Stability



Faster Pairing

This image emphasizes the Bluetooth 5.3 capabilities of the DCHK Haribo Wireless Earbuds, indicating an improved transmission range of up to 32 feet for stable and faster pairing.

4.3 Selecting the Right Ear Tips

Choose the ear tips that provide the best seal and comfort for optimal sound quality and secure fit.

Perfectly fitting ear tips



This image displays the three available ear tip sizes (Small, Medium, Large) for the DCHK Haribo Wireless Earbuds, measuring 0.45in, 0.47in, and 0.51in respectively, to ensure a comfortable and secure fit.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- Power On:** Open the charging case, and the earbuds will automatically power on.
- Power Off:** Place the earbuds back into the charging case and close the lid. They will automatically disconnect and power off.

5.2 Touch Controls

The earbuds feature intuitive touch controls on the outer surface of each earbud.

Function	Action
Play/Pause Music	Single tap on either earbud
Next Track	Double tap on the right earbud
Previous Track	Double tap on the left earbud
Answer/End Call	Single tap on either earbud

Function	Action
Reject Call	Press and hold either earbud for 2 seconds
Activate Voice Assistant (Siri, Bixby, etc.)	Triple tap on either earbud

Note: Touch control sensitivity may vary. Ensure your fingers are clean and dry for optimal response.

5.3 Making and Receiving Calls

The earbuds support hands-free calling with built-in microphones.

- When a call comes in, tap either earbud once to answer.
- To end an active call, tap either earbud once.
- To reject an incoming call, press and hold either earbud for 2 seconds.

5.4 Music Playback

Enjoy high-quality audio with 13mm dynamic drivers and support for SBC and AAC audio codecs.

- After pairing, open your music application on your device.
- Use the touch controls (single tap for play/pause, double tap for next/previous track) or your device's controls to manage playback.

6. MAINTENANCE

6.1 Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove ear tips and clean them with mild soap and water if necessary. Ensure they are completely dry before reattaching.
- Gently clean the charging contacts on both the earbuds and the case with a dry cotton swab to ensure proper charging.

6.2 Storage

- When not in use, always store the earbuds in their charging case to protect them and keep them charged.
- Store the product in a cool, dry place, away from extreme temperatures and direct sunlight.

7. TROUBLESHOOTING

If you encounter issues, refer to the following common solutions:

Problem	Solution
Earbuds not pairing	Ensure earbuds are charged. Place them back in the case, close, then reopen. Turn off and on Bluetooth on your device. Forget the device in your Bluetooth settings and re-pair.
No sound from one earbud	Check battery levels. Ensure both earbuds are properly seated in the charging case. Try resetting the earbuds (refer to manufacturer's website if specific reset instructions are not in this manual).

Problem	Solution
Charging case not charging	Verify the USB-C cable is securely connected to both the case and the power source. Try a different USB-C cable or power adapter. Clean the charging port.
Touch controls unresponsive	Ensure your fingers are clean and dry. Try cleaning the touch control area on the earbuds.
Poor sound quality	Ensure ear tips provide a good seal. Try different sized ear tips. Move closer to your paired device to reduce interference.

8. SPECIFICATIONS

Key technical specifications for the DCHK Haribo HBT-01 Wireless Earbuds:

Feature	Detail
Model Name	HBT-01
Brand	DCHK
Connectivity Technology	Wireless (Bluetooth 5.3)
Bluetooth Range	32.8 Feet (approx. 10 meters)
Audio Driver Size	13mm Dynamic Driver
Noise Control	Environmental Noise Cancellation (ENC)
Water Resistance Level	IPX4 (Water Resistant)
Battery Life (Earbuds)	Up to 5 Hours
Total Playtime (with Charging Case)	Up to 12 Hours
Charging Time	1.5 Hours (for full charge)
Charging Port	USB-C
Control Type	Touch Control
Compatible Devices	Cellphones, Desktops, Laptops, Tablets, iPhone
Material	ABS Plastic
Item Weight	2.39 ounces

9. WARRANTY AND SUPPORT

DCHK products are designed and manufactured to the highest quality standards. For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official DCHK website.

Keep your proof of purchase for any warranty claims.

© 2025 DCHK. All rights reserved.

Related Documents - HBT-01

	<p><u>PORTENTUM-01 True Wireless Earbuds with Noise Cancellation - User Manual</u></p> <p>User manual for PORTENTUM-01 True Wireless Earbuds, detailing features like Active Noise Cancellation (ANC), Environmental Noise Cancellation (ENC), pairing instructions, usage, safety guidelines, and technical specifications.</p>
	<p><u>ANKO Cylinder TWS BUDDY IM-SG-1253 User Manual - Setup and Operation Guide</u></p> <p>Official user manual for the ANKO Cylinder TWS BUDDY wireless earbuds, model IM-SG-1253 (Part No: 42828853 (01)). Includes setup, pairing, usage, troubleshooting, and specifications.</p>
	<p><u>Gembird KK-TWS-01-MX Wireless Earbuds - Product Overview</u></p> <p>Product overview for the Gembird KK-TWS-01-MX wireless earbuds, detailing model information and key specifications. Includes model number KK-TWS-01-MX/1 and size details.</p>
	<p><u>PODS 01 Active Noise Cancelling Earbuds: User Instructions</u></p> <p>Comprehensive instructions for setting up and using PODS 01 Active Noise Cancelling Earbuds, covering pairing, controls, ANC mode, gaming mode, and safety information.</p>
	<p><u>Gembird KK-TWS-01-MX True Wireless Stereo Earbuds Manual</u></p> <p>User manual for the Gembird KK-TWS-01-MX True Wireless Stereo Earbuds, providing instructions on usage, features, and specifications.</p>
	<p><u>Gembird BHP-ANC-01 BT Headset with Active Noise Cancelling - Specifications and Package Contents</u></p> <p>Detailed specifications, package contents, and system requirements for the Gembird BHP-ANC-01 black BT headset with active noise cancelling. Features include Bluetooth v5.3, 40mm speakers, 500 mAh battery, and ANC noise reduction.</p>