

DCHK HBT-01

DCHK Haribo Wireless Earbuds (Model HBT-01) User Manual

Brand: DCHK | Model: HBT-01

1. IMPORTANT SAFETY INFORMATION

Please read all safety instructions before using this product. Failure to follow these instructions may result in electric shock, fire, or other hazards.

- **Hearing Protection:** Avoid listening at high volume levels for extended periods to prevent hearing damage.
- **Driving Safety:** Do not use earbuds while driving or cycling where the inability to hear ambient sounds may present a danger.
- **Water Resistance:** The earbuds are IPX4 water resistant, meaning they are protected against splashing water from any direction. They are not designed for submersion in water.
- **Charging:** Use only the provided USB-C to USB-A charging cable and a compatible power adapter.
- **Disposal:** Dispose of this product responsibly according to local regulations. Do not dispose of batteries in household waste.

2. PACKAGE CONTENTS

Ensure all items are present in the package:

- Haribo Earbuds
- Charging Case
- USB-C to USB-A Charging Cable
- 3 Sizes of Eartips (S, M, L)
- User Manual (This document)

3. PRODUCT OVERVIEW

The DCHK Haribo Wireless Earbuds (Model HBT-01) offer a blend of stable connectivity, deep bass sound, and convenient features in a compact design.



Figure 1: DCHK Haribo Wireless Earbuds and Charging Case.

Bluetooth 5.3 Wireless Earbuds




Figure 2: Key features of the DCHK Haribo Wireless Earbuds.

Key Features:

- **Stable Connectivity:** Bluetooth 5.3 for faster speeds and lower power consumption. Supports SBC, AAC audio codecs, and A2DP, AVRCP, HFP, HSP profiles.
- **Auto Pairing:** Earbuds automatically connect when removed from the charging case.
- **Deep Bass Sound:** Equipped with 13mm dynamic driver units for rich audio.
- **Touch Control:** Easy-to-use touch controls for music and calls.
- **Fast Charging:** USB Type-C terminal allows full charge in 1.5 hours.
- **Water Resistance:** IPX4 rated for protection against splashing water.

4. SETUP

4.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and charging case.

1. Place the earbuds into the charging case. Ensure they are correctly seated.
2. Connect the USB-C end of the charging cable to the charging port on the case and the USB-A end to a compatible power source (e.g., computer USB port, wall adapter).

3. The indicator light on the case will show charging status. A full charge takes approximately 1.5 hours for the case.



Figure 3: Charging and battery life overview.

4.2 Pairing with a Device

The earbuds support automatic pairing for convenience.

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically enter pairing mode, indicated by a flashing LED light on the earbuds.
3. On your device (smartphone, tablet, laptop), enable Bluetooth.
4. Search for available Bluetooth devices and select "HBT-01" from the list.
5. Once connected, the LED indicator on the earbuds will stop flashing.

The earbuds will automatically reconnect to the last paired device when removed from the case, provided Bluetooth is enabled on the device.




Figure 4: Bluetooth 5.3 connectivity features.

5. OPERATING INSTRUCTIONS

The DCHK Haribo Wireless Earbuds feature intuitive touch controls.

5.1 Touch Controls

Function	Action
Play/Pause Music	Single tap either earbud
Next Track	Double tap right earbud
Previous Track	Double tap left earbud
Answer/End Call	Single tap either earbud
Reject Call	Press and hold either earbud for 2 seconds
Activate Voice Assistant (Siri, Bixby)	Triple tap either earbud

5.2 Environmental Noise Cancelling (ENC)

The earbuds feature ENC technology to reduce ambient noise during calls, ensuring clearer voice transmission.

6. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your earbuds.

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Eartips:** Remove and clean the eartips periodically with mild soap and water. Ensure they are completely dry before reattaching.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage.
- **Avoid Extreme Conditions:** Do not expose the earbuds to extreme temperatures, humidity, or direct sunlight.

Perfectly fitting ear tips



Figure 5: Included eartips for a comfortable fit.

7. TROUBLESHOOTING

If you encounter issues with your earbuds, refer to the following common solutions:

- **Earbuds not pairing:**
 - Ensure both earbuds are charged.

- Turn off Bluetooth on your device, then turn it back on.
 - Forget/delete "HBT-01" from your device's Bluetooth list and attempt to pair again.
 - Place earbuds back in the case, close the lid, wait a few seconds, then open to re-enter pairing mode.
- **No sound or low volume:**
 - Check the volume level on both your device and the earbuds.
 - Ensure earbuds are properly connected to your device.
 - Clean any debris from the eartips and speaker mesh.
 - **Earbuds not charging:**
 - Ensure the charging cable is securely connected to both the case and the power source.
 - Verify the power source is active.
 - Clean the charging contacts on both the earbuds and the case.

8. SPECIFICATIONS

Feature	Detail
Model Name	HBT-01
Brand	DCHK
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.3
Bluetooth Range	32.8 Feet
Audio Driver Type	Dynamic Driver
Audio Driver Size	13 Millimeters
Noise Control	Active Noise Cancellation (ENC for calls)
Frequency Response	20 KHz
Impedance	16 Ohms
Control Type	Touch Control
Battery Life (Earbuds)	5 Hours
Charging Time (Case)	1.5 Hours
Water Resistance Level	Water Resistant (IPX4)
Material	ABS Plastic
Item Weight	2.39 ounces
Carrying Case Dimensions	2.16 x 0.98 x 1.96 Inches

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the DCHK official website. Keep your proof of purchase for warranty claims.