

[Manuals.plus](#) /

> [Mova](#) /

> MOVA K30 SE Wet Dry Vacuum Cleaner User Manual

Mova K30SE

MOVA K30 SE Wet Dry Vacuum Cleaner User Manual

Comprehensive guide for setup, operation, and maintenance of your MOVA K30 SE Wet Dry Vacuum Cleaner.

1. PRODUCT OVERVIEW

The MOVA K30 SE is an advanced wet dry vacuum cleaner designed for efficient cleaning of various floor types. It features a 180° lie-flat design for hard-to-reach areas, dual rotation self-cleaning, dual-sided cleaning, and powerful suction for both wet and dry messes.

1.1 Package Contents

Ensure all items are present in the package:

- Main Body x1
- Handle x1
- Charging Base x1
- Power Adaptor x1
- Cleaning Solution x1
- Cleaning Brush x1



Figure 1: MOVA K30 SE Wet Dry Vacuum Cleaner and included accessories. This image displays the main vacuum unit, handle, charging base, power adapter, cleaning solution, and a small cleaning brush.

2. SETUP GUIDE

2.1 Assembly

1. **Attach the Handle:** Insert the handle into the main body until it clicks securely into place.
2. **Charge the Device:** Place the main body onto the charging base. Connect the power adapter to the charging base and plug it into a power outlet. The LED display on the vacuum will indicate charging status.
3. **Prepare Water Tanks:** The MOVA K30 SE features an integrated water tank system that separates clean and dirty water. Fill the clean water tank with water and, if desired, the provided cleaning solution.

3. OPERATING INSTRUCTIONS

3.1 Powering On and Off

To power on the device, place your foot on the brush head to stabilize it, then lean the main body back. Press the power button located on the handle. The device will announce its status. To power off, press the power button again.




Figure 2: The MOVA K30 SE Wet Dry Vacuum Cleaner in its upright standing position, ready for use or storage.

3.2 Cleaning Modes and Features

- **180° Lie-Flat Reach:** The K30 SE's design allows it to lie nearly flat, enabling cleaning under low furniture and in tight spaces. The brush head is only 3.15 inches high, and the main body can fit into spaces as low as 5.51 inches.



Figure 3: The MOVA K30 SE demonstrating its 180° lie-flat design, allowing it to reach under low furniture for thorough cleaning. The image shows the vacuum's low profile, with the brush head at 3.15 inches and the main body at 5.51 inches from the floor.

- **Dual-Edge Cleaning:** The exclusive brush roller is designed for precise cleaning along baseboards and into corners, reaching down to 0 inches from edges.



0mm* Dual-Edge Cleaning

Figure 4: The MOVA K30 SE performing dual-edge cleaning, effectively reaching dirt and debris right up to walls and furniture edges. This highlights the vacuum's ability to clean corners and baseboards without leaving gaps.

- **Powerful Suction:** With 18,000 Pa suction power and 500 RPM rapid mopping, the K30 SE effectively handles both wet and dry messes, including pet hair.
- **Lightweight and Self-Propelled:** Weighing 8.8 lbs, the vacuum is easy to maneuver around the home and up stairs, with a self-propelled design assisting movement.



Solids & Liquids Separate for Easy Disposal

Figure 5: A user easily carrying the lightweight MOVA K30 SE up stairs, demonstrating its portability and self-propelled traction for effortless cleaning.

- **Extended Runtime:** The device offers up to 30 minutes of runtime, capable of cleaning areas up to 2595 sq ft on a single charge.



Figure 6: An internal view illustrating the battery components of the MOVA K30 SE, highlighting its consistent and durable performance with a 30-minute runtime and capacity to clean up to 2583 sq ft.

4. MAINTENANCE

4.1 Self-Cleaning Function

The MOVA K30 SE features a one-press self-cleaning function. Place the vacuum on its charging base and press the self-clean button. The rotation brush will be washed, and then spin at high speed to remove excess water.

During self-cleaning, the brush detangles by reversing back and forth, ensuring thorough cleaning.



Figure 7: Visual representation of the MOVA K30 SE's self-cleaning process, showing the one-press activation and dual rotation brush cleaning for simplified care.

4.2 Emptying Water Tanks and Filter

The integrated water tank system keeps clean water and dirty waste separated. After use, the dirty water tank

should be emptied. The easy-to-empty filter container separates solid dirt from liquid waste, preventing drain clogs and simplifying disposal.




Figure 8: A user demonstrating the easy disposal of solids and liquids from the MOVA K30 SE's integrated water tank, ensuring no cross-contamination and simple waste management.

4.3 Anti-Tangle Design

The brush's anti-tangle design, paired with a specialized comb-tooth scraper, significantly helps reduce hair entanglement and assists in thorough brush cleaning.

5. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device not powering on	Low battery; improper handle attachment.	Ensure device is fully charged. Re-attach handle securely until it clicks.
Weak suction	Dirty filter; clogged brush roller; full dirty water tank.	Clean or replace HEPA filter. Clear any blockages from the brush roller. Empty dirty water tank.
Brush roller not rotating	Hair entanglement; foreign object obstruction.	Remove hair and debris from the brush roller using the cleaning brush. Check for and remove any foreign objects.
Water leakage	Water tank not properly sealed; damaged tank.	Ensure water tanks are correctly installed and sealed. Contact customer support if tank is damaged.

6. SPECIFICATIONS

- **Brand:** Mova
- **Model Name:** K30SE
- **Special Features:** 18,000Pa Suction, 180° Lie-Flat Reach, Anti-Tangle Design, 0 in Dual-Edge Cleaning, One-Press Self-Cleaning
- **Filter Type:** HEPA Filter
- **Is Cordless?:** Yes
- **Clean Water Tank Capacity:** 0.6 Liters (600ml)
- **Used Water Tank Capacity:** 500ml
- **Runtime:** Up to 30 minutes
- **Recommended Uses:** Carpet, Hard Floor, Hardwood, Stairs
- **Form Factor:** Handheld
- **Color:** White
- **Product Dimensions:** 10.8"L x 9.4"W x 43.4"H
- **Battery Type:** Lithium-Ion (6 batteries included)
- **Noise Level:** 76 dB
- **Item Weight:** 8.38 pounds
- **Control Method:** Touch
- **Number of Power Levels:** 3
- **Indoor/Outdoor Usage:** Indoor
- **UPC:** 850070941303

7. WARRANTY AND SUPPORT

MOVA offers comprehensive support for its products:

- **24/7 Rapid Responding Service Team:** For immediate assistance.
- **30-Day Money Back Service:** If you are not satisfied with your purchase.
- **Up to 36-Month Warranty:** Providing long-term peace of mind.
- **Fast Shipping from Local Warehouses:** For quick delivery of products and parts.

For further assistance, please visit the [Official Mova Store on Amazon](#) or contact their customer support directly.