

- Manuals.plus /
- › ZWXYVUT /
- › ZWXYVUT S40 Max Game Projector Instruction Manual

ZWXYVUT S40 Max

ZWXYVUT S40 Max Game Projector Instruction Manual

Model: S40 Max | Brand: ZWXYVUT

INTRODUCTION

The ZWXYVUT S40 Max Game Projector is a versatile entertainment device featuring an Android 11 system, Wi-Fi 6, and Bluetooth 5.4 connectivity. It offers a native 720p resolution with support for 4K video playback, 8000 lumens brightness, and an auto-correction feature for precise image alignment. Designed for both indoor and outdoor use, this portable projector comes with over 36,000 pre-installed games and supports various streaming applications, making it suitable for home theater, gaming, and other multimedia needs.



Image: The ZWXYVUT S40 Max Game Projector, a compact white cylindrical device with a lens, shown against a vibrant yellow floral background. Icons indicate 1080P support, Android 11.0, WiFi 6, and Auto Keystone features.

What's in the Box

Verify that all components are present in the package:

- S40 Max Game Projector
- Remote Control
- Power Cable
- 2 Wireless Controllers
- User Manual

Video: An unboxing of a similar game projector, showing the projector unit, two wireless controllers, a remote control, and power cables being removed from the packaging. This demonstrates the typical contents of the product box.

1. **Power Connection:** Connect the power cable to the projector's power input port and then plug it into a standard electrical outlet.
2. **Positioning:** Place the projector on a stable surface. The adjustable stand allows for projection onto walls or ceilings.
3. **Initial Power On:** Press the power button on the projector or the remote control to turn on the device.
4. **Focus Adjustment:** If the image appears blurry, gently adjust the focus ring around the lens until the picture is clear.
5. **Keystone Correction:** The projector features automatic keystone correction to ensure a rectangular image, even if the projector is placed at an angle.
6. **Network Connection:** Navigate to the settings menu to connect the projector to your Wi-Fi network (2.4G/5G Wi-Fi 6 supported).
7. **Controller Connection:** The wireless controllers can be connected via USB or Bluetooth. For wired connection, plug the controller into a USB port on the projector. For wireless, follow the on-screen instructions for Bluetooth pairing.




Image: The ZWXYVUT S40 Max Projector displaying its Android 11.0 interface, highlighting its portable design, 2.4G/5G WiFi, 120 ANSI

OPERATING INSTRUCTIONS

Navigation

Use the provided remote control or wireless game controllers to navigate the Android 11 interface. The main screen displays various applications such as 'Game', 'YouTube', 'Max', and 'Netflix'.

Game Play

The projector comes with over 36,000 classic and modern 3D games, supported by 14 built-in emulators. Select the 'Game' application to browse and launch games. The high-sensitivity joystick controllers provide precise control for an engaging gaming experience.


Video: A demonstration of game play on a projector, showing a user interacting with a game using a controller. This illustrates the gaming functionality and controller usage.

Media Playback

Access pre-installed streaming services like YouTube, Netflix, and Prime Video directly from the home screen. The Android 11 system ensures smooth connectivity and high-quality streaming.

Screen Mirroring

Connect your iPhone, Android phone, or tablet wirelessly via Wi-Fi to mirror your device's screen onto the projector. This feature allows for flexible content sharing.



Convenient Screen Mirror

Connect your
iPhone/Android phone
or tablet by WiFi



Image: The ZWXYVUT S40 Max Projector displaying a mirrored screen from a smartphone, tablet, and laptop, illustrating its convenient screen mirror function via WiFi.

Projection Size and Quality

The projector can display images up to 100 inches without sacrificing quality. The 8000 lumens brightness ensures clear images in various lighting conditions. The auto-correction feature maintains precise alignment for clear projections.

120 Large-screen projector

Better viewing experience




Image: The ZWXYVUT S40 Max Projector projecting a large image onto a wall, with overlays indicating various screen sizes (40", 80", 120") for a better viewing experience.

CONNECTIVITY

The S40 Max Game Projector offers multiple connectivity options:

- **HDMI:** Connect to laptops, gaming consoles, or other HDMI-enabled devices.
- **USB:** For connecting external storage devices or wired controllers.
- **3.5mm Audio Output:** Connect external speakers or headphones for customized audio.
- **Wi-Fi 6:** Fast and stable wireless network connection for streaming and online gaming.
- **Bluetooth 5.4:** Easily pair Bluetooth speakers or headphones for enhanced audio.

MAINTENANCE

To ensure the longevity and optimal performance of your projector, follow these maintenance guidelines:

- **Lens Cleaning:** Use a soft, lint-free cloth specifically designed for optical lenses to gently wipe the projector lens. Avoid abrasive materials or harsh chemicals.
- **Ventilation:** Ensure the projector's ventilation ports are clear of dust and obstructions to prevent overheating. Do not block the air vents during operation.
- **Storage:** When not in use, store the projector in a cool, dry place away from direct sunlight and extreme temperatures. Use the original packaging or a protective case to prevent dust accumulation and damage.
- **General Cleaning:** Wipe the exterior of the projector with a soft, dry cloth. Do not use liquid cleaners directly on the device.

TROUBLESHOOTING

If you encounter issues with your projector, refer to the following common solutions:

- **Blurry Image:** Adjust the focus ring around the lens. Ensure the projection surface is flat and the projector is within the recommended distance.
- **No Power:** Check if the power cable is securely connected to both the projector and the electrical outlet. Try a different outlet.
- **No Sound:** Verify that the volume is not muted or set too low. Check the audio output settings and ensure external speakers/headphones are properly connected if used.
- **No Signal:** Ensure the input source (HDMI, USB, screen mirroring) is correctly selected and the external device is powered on and functioning.
- **Overheating:** Check that the ventilation ports are not blocked. Allow the projector to cool down if it has been running for an extended period.

SPECIFICATIONS

Feature	Detail
Brand	ZWXYVUT
Model	S40 Max
Operating System	Android 11
Display Resolution	Native 1280x720dpi (supports 4K video playback)
Brightness	8000 Lumens
Connectivity Technology	HDMI, USB, Wi-Fi 6, Bluetooth 5.4
Special Features	3D-Ready, Auto Correction, 50% Zoom Function, Ultra-Quiet Operation (25 Db)
Recommended Uses	Home Cinema, Gaming, Outdoor Use
Pre-installed Games	Over 36,000 with 14 emulators

WARRANTY AND SUPPORT

For detailed warranty information, please refer to the warranty card included in your product packaging or visit the official ZWXYVUT website. If you require technical assistance or have questions regarding your S40 Max Game Projector, please contact customer support through the provided channels on the manufacturer's website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DPWY1G71>

More documents and user manuals: <https://manuals.plus/>