Lavazza Classy Mini

Lavazza Classy Mini Espresso Coffee Machine User Manual

Model: Classy Mini

1. Introduction

Thank you for choosing the Lavazza Classy Mini Espresso Coffee Machine. This compact single-serve brewer is designed to deliver authentic Italian espresso and lungo using Lavazza Expert and BLUE capsules. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new coffee machine. Please read it thoroughly before first use and keep it for future reference.

2. Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and/or injury to persons.

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.

- Do not use appliance for other than intended use.

3. Package Contents

Verify that all items are present and in good condition upon opening the package.



Image: The Lavazza Classy Mini coffee machine bundled with 72 Lavazza Expert Intenso coffee capsules.

- Lavazza Classy Mini Espresso Coffee Machine
- Removable Water Tank
- Adjustable Cup Rack/Drip Tray
- Power Cord
- Instruction Manual (this document)
- 72 Lavazza Expert Intenso Coffee Capsules (included in this bundle)

4. Product Overview

Familiarize yourself with the components of your Lavazza Classy Mini machine.



Image: Front view of the Lavazza Classy Mini machine, showcasing its sleek design and a brewed espresso.



Image: Visual representation of key features: compact design, adjustable cup rack, and two programmable coffee selections.

- **Water Tank:** Located at the back, removable for easy filling. Capacity: 1 Liter (approx. 23 fl. oz).
- **Capsule Insertion Lever:** Used to open and close the capsule compartment.
- **Brew Buttons:** Two programmable buttons for Espresso and Lungo.
- **Capsule Collection Drawer:** Collects used capsules.
- **Drip Tray:** Collects excess liquid, removable for cleaning.
- **Adjustable Cup Rack:** Can be set to two heights to accommodate different cup sizes.

5. Setup

5.1 Unpacking

Carefully remove all packaging materials from the machine. Retain packaging for future transport or storage if needed.

5.2 Initial Cleaning

Before first use, wash the water tank, drip tray, and cup rack with warm water and a mild detergent. Rinse thoroughly and dry. Wipe the exterior of the machine with a damp cloth.

5.3 Filling the Water Tank

1. Remove the water tank from the back of the machine.
2. Fill the tank with fresh, cold drinking water up to the MAX fill line. Do not exceed the MAX line.
3. Place the water tank back onto the machine, ensuring it is securely seated.

5.4 Power Connection

Plug the power cord into a grounded electrical outlet. The machine will enter standby mode.

6. Operating Instructions

6.1 First Use / Priming the Machine

Before brewing your first coffee, it is recommended to prime the machine to ensure proper water flow and heating.

1. Ensure the water tank is filled.
2. Place a large container (at least 200ml) under the coffee dispenser.
3. Press either the Espresso or Lungo button. The machine will start pumping water through without a capsule.
4. Allow the machine to complete a full cycle, dispensing water into the container. Repeat this process 2-3 times.

6.2 Brewing Coffee

1. Ensure the water tank is filled with fresh water.
2. Lift the capsule insertion lever to open the capsule compartment.
3. Insert one Lavazza Expert or BLUE capsule into the compartment. Close the lever firmly until it clicks.
4. Place your cup on the adjustable cup rack. Adjust the rack height if necessary.
5. Press the desired brew button:
   Espresso Button: For a short, concentrated coffee.
   Lungo Button: For a longer coffee.
6. The machine will begin brewing. The brewing process will stop automatically.
7. Once brewing is complete, lift the capsule insertion lever to eject the used capsule into the collection drawer.

6.3 Programming Coffee Volume

You can customize the volume for both Espresso and Lungo buttons.

1. Insert a capsule and place a cup under the dispenser.
2. Press and hold the brew button you wish to program (Espresso or Lungo).
3. Release the button once your desired coffee volume is reached. The machine will remember this setting for future brews.

7. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your machine.

7.1 Daily Cleaning

- **Drip Tray and Capsule Collection Drawer:** Empty and rinse daily. Wash with warm, soapy water, rinse, and dry.
- **Water Tank:** Empty any remaining water and rinse daily. Refill with fresh water before each use.
- **Exterior:** Wipe the machine's exterior with a soft, damp cloth. Do not use abrasive cleaners or immerse the

machine in water.

7.2 Descaling

Over time, mineral deposits (limescale) can build up in your machine, affecting performance. Descale your machine regularly, depending on water hardness and frequency of use (e.g., every 3-6 months).

1. Use a descaling solution specifically designed for coffee machines. Follow the instructions on the descaling solution packaging.
2. Empty the water tank and fill it with the descaling solution mixed with water as per the solution's instructions.
3. Place a large container under the coffee dispenser.
4. Run several brewing cycles without a capsule until the water tank is empty.
5. Rinse the water tank thoroughly and fill it with fresh water.
6. Run several cycles with fresh water to rinse out any remaining descaling solution.

8. Troubleshooting

If you encounter issues with your Lavazza Classy Mini, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Machine does not turn on.	No power supply.	Check if the power cord is securely plugged into the machine and the wall outlet. Check the power outlet.
No coffee dispenses or only a few drops.	Water tank is empty. Machine needs descaling. Capsule not inserted correctly.	Fill the water tank. Perform a descaling cycle. Lift the lever, remove and re-insert the capsule correctly.
Coffee is not hot enough.	Machine not preheated. Cups are cold.	Allow the machine to heat up fully (indicator light stable). Preheat cups with hot water.
Water leaks from the machine.	Water tank not seated correctly. Drip tray is full.	Ensure the water tank is firmly in place. Empty the drip tray.
Used capsules not ejecting.	Capsule collection drawer is full.	Empty the capsule collection drawer.

9. Specifications

Technical specifications for the Lavazza Classy Mini Espresso Coffee Machine.



Image: Detailed specifications including dimensions, water tank capacity, voltage, and weight.

Feature	Detail
Model Name	Classy Mini
Brand	Lavazza
Coffee Maker Type	Espresso Machine (Single-Serve)
Compatible Capsules	Lavazza Expert & BLUE Capsules
Capacity (Water Tank)	1 Liter (approx. 23 fl. oz)
Color	Black
Product Dimensions (D x W x H)	7"D x 4"W x 6"H
Item Weight	4.99 pounds (approx. 2.26 kg)

Feature	Detail
Special Feature	Auto Shut-Off
Filter Type	Reusable (internal system)
UPC	860013184414

10. Warranty and Support

For warranty information and customer support, please refer to the documentation provided with your purchase or visit the official Lavazza website. Keep your proof of purchase for warranty claims.

Online Resources: For additional support, FAQs, and product registration, please visit the official Lavazza website.

© 2024 Lavazza. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question