

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Weofly](#) /

› [Weofly Lifefits Wireless Earbuds with Smart Touchscreen - Instruction Manual](#)

## Weofly Lifefits

# Weofly Lifefits Wireless Earbuds with Smart Touchscreen - Instruction Manual

Model: Lifefits | Brand: Weofly

## INTRODUCTION

Welcome to the Weofly Lifefits Wireless Earbuds. These earbuds feature a smart touchscreen charging case, Bluetooth 5.4 technology, IPX4 waterproofing, and immersive stereo sound. This manual provides detailed instructions to help you get the most out of your new earbuds.

## WHAT'S IN THE Box

- Weofly Lifefits In-Ear Earbuds (Left and Right)
- Smart Touchscreen Wireless Charging Case
- USB-C Charging Cable
- User Manual
- M Size Ear Tips
- L Size Ear Tips
- Lanyard



Image: All components included in the Weofly Lifefits Wireless Earbuds package.

## SETUP

### 1. Initial Charging

Before first use, ensure both the earbuds and the charging case are fully charged. Connect the provided USB-C cable to the

charging case and a power source. The touchscreen display on the case will indicate the charging status.

## 2. One-Step Pairing

1. Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
3. Select "Weofly Lifefits" from the list to connect. Once connected, the earbuds will automatically reconnect to the most recently paired device when taken out of the case.




Image: Bluetooth 5.4 technology ensures a fast and stable connection.

## 3. Comfortable Fit

The ergonomic, stick-closed design of the Weofly Lifefits earbuds is engineered for comfort. Choose the appropriate ear tip size (M or L provided) for a secure and comfortable fit that enhances sound quality and passive noise isolation.

## OPERATING INSTRUCTIONS

### Smart Touchscreen Case Functions

The 1.28-inch color touchscreen on the charging case provides convenient control over various functions without needing your phone.

- **Music Playback:** Control play/pause, skip tracks.
- **Volume Adjustment:** Easily change the listening volume.
- **Call Management:** Answer, end, or reject calls.
- **Language Switching:** Select your preferred language for the case interface.
- **Wallpaper Switching:** Customize the screen background.
- **Screen Brightness:** Adjust the display brightness.
- **Headphone Search:** Locate misplaced earbuds by activating a sound.
- **Timer:** Utilize a built-in timer function.
- **Camera Control:** Remotely trigger your phone's camera.
- **Flashlight:** Activate a small flashlight feature.
- **Audio Equalizer:** Switch between 5 different sound styles (e.g., Jazz, Studio, Club, Bass, Vocal) to suit your audio preferences.

# Weofly Lifefits

Smart Touch Screen Earbuds



13mm Dynamic  
Driver



Bluetooth  
5.4



HiFi Stereo  
Sound



Auto  
Pairing



Comfortable  
Fit



40 Hrs  
Playtime



LED  
Touch Screen



IPX4  
Waterproof



Image: The smart touchscreen case offers a wide range of controls and features.

## What's In The Box

- Weofly LifeFits x1
- Charging Cable x1
- User Manual x1
- M Size Ear Tips x1
- L Size Ear Tips x1
- Lanyard x1




Image: Built-in audio equalizer allows for effortless switching between music styles.

## Earbud Touch Controls

The earbuds themselves feature touch controls for basic functions. Refer to the quick start guide or the case's display for specific tap gestures for play/pause, track skipping, and call handling.

## Immersive Sound Quality

Experience rich sound with punchy bass and full, textured mids, delivered by 13mm dynamic drivers. The unique design provides a realistic music experience for both indoor and outdoor use.

## 13mm Dynamic Driver Brings Powerful Sound Experience

Weofly LifeFits earbuds feature a 13mm oversized driver module paired with a premium sound solution, delivering clear beats, crisp vocals, and transparent highs for an immersive music experience.



13mm Dynamic Driver



Professional Acoustic Transmission Structure



HD Sound Quality



Image: The 13mm dynamic drivers deliver powerful and immersive sound.

## CHARGING

The earbuds automatically recharge when placed inside the charging case. The case itself can be recharged via the USB-C port. A full charge of the case provides multiple recharges for the earbuds.

- **Earbud Playtime:** Up to 6-10 hours of music playback on a single charge. (Note: Approximately 5 hours for calls).
- **Total Playtime with Case:** Up to 40 hours.
- **Charging Time:** Approximately 2 hours for a full charge of the case.

## Bluetooth 5.4 Connection



20% Faster Transmission



Lower Energy



Lower latency



Image: Extended playtime ensures long-lasting music enjoyment.



## More Than Just a Charging Case

Weofly LifeFits charging case not only lets you enjoy music more conveniently, but also supports phone call answering/rejecting, earbud find function, flashlight, and remote control for taking photos, among other practical features.



Reject/Answer Phone Call



Find Earbuds



Flashlight



Remote Photo Capture



Battery Life Status

Image: The 400mAh high-density battery provides extended music experience.

## MAINTENANCE

### Water Resistance

The earbuds have an IPX4 waterproof rating, making them resistant to water splashes and sweat. This makes them suitable for fitness, jogging, and running. However, they are not designed for submersion in water.




Image: IPX4 waterproof design protects earbuds from sweat and rain.

### Cleaning

To ensure optimal performance and charging, regularly wipe the metal charging contacts on both the earbuds and inside the case with a dry cloth. If a charging contact becomes dirty, a small alcohol rubbing cloth can be used to clean it.

After exercise, wipe the metal part of the headphones with a dry cloth to prevent corrosion from sweat.

## TROUBLESHOOTING

Problem	Possible Solution
Earbuds not pairing/connecting.	Ensure earbuds are charged. Turn off and on Bluetooth on your device. Forget the device in your Bluetooth settings and re-pair.

Problem	Possible Solution
One earbud not charging or connecting.	Clean the charging contacts on the earbud and inside the case with a dry cloth or alcohol wipe. Ensure the earbud is seated correctly in the case.
Touchscreen on case unresponsive.	Ensure the case is sufficiently charged. Try restarting the case by closing and reopening it.
Poor sound quality or low volume.	Adjust the volume on both your device and the charging case. Ensure ear tips provide a good seal in your ear. Check equalizer settings on the case.
Case battery drains quickly when not in use.	Ensure the case lid is fully closed when not in use. Avoid leaving the case in extreme temperatures.

## SPECIFICATIONS

- Model Name:** Lifefits
- Brand:** Weofly
- Connectivity Technology:** Wireless
- Wireless Communication Technology:** Bluetooth 5.4
- Bluetooth Range:** Up to 15 meters
- Ear Placement:** In Ear
- Form Factor:** In Ear
- Control Method:** Touch
- Audio Driver Type:** 13mm Dynamic Driver
- Battery Life (Earbuds):** 6-10 Hours (Music Playback), 5 Hours (Calls)
- Total Battery Life (with Case):** Up to 40 Hours
- Charging Time:** 2 Hours
- Water Resistance Level:** IPX4 Water Resistant
- Item Weight:** 0.17 Kilograms (approx. 5.9 ounces)
- Compatible Devices:** Laptops, Desktops, Tablets, Telephones, Smart Speakers, Televisions, Cellphones

## WARRANTY AND SUPPORT

Weofly products are designed for quality and reliability. For any issues or support needs, please refer to your purchase platform for warranty details or contact Weofly customer service directly. Information regarding extended protection plans may also be available from your retailer.

For further assistance, visit the official Weofly store: [Weofly Store on Amazon](#).

## PRODUCT VIDEO

Your browser does not support the video tag.

Video: Official product overview of the Weofly Lifefits Wireless Earbuds with Smart Touchscreen, demonstrating key features and design. This video is provided by the seller, Jinhongmei.

