

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Tronsmart](#) /

› [Tronsmart Mirtune C3 Plus Bluetooth Speaker User Manual](#)

## Tronsmart Mirtune C3 Plus

# Tronsmart Mirtune C3 Plus Bluetooth Speaker User Manual

Model: Mirtune C3 Plus

## INTRODUCTION

This manual provides detailed instructions for the safe and efficient operation of your Tronsmart Mirtune C3 Plus Bluetooth Speaker. Please read this manual thoroughly before using the product and retain it for future reference. The Tronsmart Mirtune C3 Plus Bluetooth speaker is designed to provide exceptional sound quality and convenience for music lovers on the go. It features powerful 30W stereo sound and Bluetooth 5.3 technology, ensuring a strong and stable connection for seamless streaming. Its IPX7 waterproof rating and durable dust-resistant exterior make it a reliable choice for outdoor adventures, picnics, or poolside gatherings. True Wireless Stereo (TWS) pairing allows you to connect two speakers for an enhanced stereo experience. With up to 18 hours of playtime, this speaker ensures continuous music playback for any event. Its modern design and compact size make it an essential companion for music enthusiasts. Available in black.

## PRODUCT FEATURES

- Provides powerful 30W stereo sound with seamless Bluetooth 5.3 connection.
- Enables True Wireless Stereo pairing with enhanced stereo sound through dual speakers.
- Features IPX7 water and dust resistance for reliable outdoor use.
- 18 hours of continuous playback ensures you enjoy music throughout long events.
- Great for picnics, poolside gatherings, and adventure trips.
- Built-in Microphone for hands-free calls.
- Portable and compact design.

## PACKAGE CONTENTS

Please check the package contents upon unboxing to ensure all items are present:

- Tronsmart Mirtune C3 Plus Bluetooth Speaker
- Charging Cable (USB-C)
- User Manual

- Auxiliary Cable (if applicable, not explicitly mentioned but common)





Image: The Tronsmart Mirtune C3 Plus Bluetooth Speaker, showcasing its sleek black design and portable form factor.

## SETUP

---

### Charging the Speaker

Before first use, fully charge the speaker. Connect the provided USB-C charging cable to the speaker's charging port and the other end to a compatible USB power adapter (not included) or a computer's USB port. The charging indicator light will show the charging status.

### Powering On/Off

To power on the speaker, press and hold the power button ( ) for 2-3 seconds until you hear an audible prompt or see the indicator light illuminate. To power off, press and hold the power button again for 2-3 seconds.

### Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode. The Bluetooth indicator light will typically flash rapidly.
2. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
3. Select "Tronsmart Mirtune C3 Plus" from the list of devices.
4. Once connected, the Bluetooth indicator light will become solid, and you will hear a confirmation sound.



Image: Top view of the Tronsmart Mirtune C3 Plus speaker, showing the power button, Bluetooth indicator, and other control buttons.

# OPERATING INSTRUCTIONS

---

## Basic Controls

- **Power Button ( ):** Press and hold to power on/off.
- **Play/Pause Button (▶/||):** Press once to play or pause music.
- **Volume Up (+):** Press to increase volume. Press and hold for next track.
- **Volume Down (-):** Press to decrease volume. Press and hold for previous track.
- **Mode Button (M):** Press to switch between Bluetooth, AUX, or other available modes.

## True Wireless Stereo (TWS) Pairing

To achieve an enhanced stereo sound experience, you can pair two Tronsmart Mirtune C3 Plus speakers together:

1. Ensure both speakers are powered on and not connected to any other Bluetooth device.
2. On one speaker (this will be the primary speaker), press the TWS button (often indicated by a chain link icon or "TWS"). The speaker will enter TWS pairing mode.
3. The primary speaker will automatically search for the secondary speaker. Once connected, you will hear a confirmation sound, and the TWS indicator light will become solid on both speakers.
4. Now, connect your device to the primary speaker via Bluetooth as described in the "Bluetooth Pairing" section.

# Robust Bold Sound

Excursion driver with tweeter delivers refined sound.



Image: An exploded view diagram illustrating the internal components of the Tronsmart Mirtune C3 Plus speaker, highlighting its robust sound drivers.

## Water and Dust Resistance (IPX7)

The speaker is rated IPX7, meaning it can be submerged in water up to 1 meter for 30 minutes. This makes it suitable for use near water, but it is not designed for prolonged submersion. Ensure the charging port cover is securely closed before exposing the speaker to water.

# IPX7 Waterproof

Ready to listen by the pool.



Image: The Tronsmart Mirtune C3 Plus speaker resting on wet rocks, illustrating its IPX7 waterproof capability, ready for poolside or outdoor listening.

## MAINTENANCE

- **Cleaning:** Wipe the speaker with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use for extended periods.
- **Water Exposure:** After exposure to water, ensure the charging port is dry before charging.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker fully.
Cannot pair with Bluetooth device.	Speaker not in pairing mode; device too far; interference.	Ensure speaker is in pairing mode. Move device closer. Turn off other Bluetooth devices.
No sound or low volume.	Volume too low; device not connected; incorrect audio source.	Increase volume on speaker and device. Reconnect Bluetooth. Check audio source.
TWS pairing fails.	Speakers too far apart; already connected to another device.	Ensure speakers are close. Disconnect from other devices before TWS pairing.

## SPECIFICATIONS

Feature	Detail
Brand	Tronsmart
Model Name	Mirtune C3 Plus
Connectivity Technology	Bluetooth
Maximum Speaker Output Power	30W
Audio Output Mode	Stereo
Frequency Response	20 kHz
Special Features	Built-in Microphone, Portable, Waterproof (IPX7)
Speaker Type	Subwoofer
Mounting Type	Tabletop
Material	Plastic
Product Dimensions	21 x 8 x 21 cm
Weight	684 grams
Batteries	1 9V battery required (Included)
Country of Origin	China

## WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official Tronsmart website or contact their customer service directly. Keep your purchase receipt as proof of purchase for warranty claims.

**Manufacturer:** Tronsmart

**ASIN:** B0DPXLX72X

**First Available Date:** December 9, 2024

