

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Tronsmart](#) /

› [Tronsmart Mirtune C3 Portable Bluetooth Speaker User Manual](#)

Tronsmart Mirtune C3

Tronsmart Mirtune C3 Portable Bluetooth Speaker User Manual

Model: Mirtune C3 | Brand: Tronsmart

INTRODUCTION

The Tronsmart Mirtune C3 is a portable Bluetooth speaker designed for high-fidelity audio experiences. Featuring 24W stereo sound, IPX7 waterproof rating, and up to 12 hours of playtime, it is suitable for various environments including outdoor activities, home use, and parties. This manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your Mirtune C3 speaker.

PACKAGE CONTENTS

- Tronsmart Mirtune C3 Portable Bluetooth Speaker
- USB-C Charging Cable
- User Manual
- Warranty Card

PRODUCT OVERVIEW

Familiarize yourself with the main components of your Tronsmart Mirtune C3 speaker.



Figure 1: Front view of the Tronsmart MirTune C3 speaker, showcasing its mesh grille and control buttons.

Omnidirectional Bold Sound

Optimized excursion driver combined with a separate tweeter delivers exceptionally rich sound.



Figure 2: Side view of the Tronsmart Mirtune C3 speaker, highlighting its portable strap for easy carrying.

SETUP

Charging the Speaker

Before first use, fully charge the speaker using the provided USB-C cable. The charging indicator light will show charging status.

Power On/Off

- To power on, press and hold the Power button for 2 seconds.
- To power off, press and hold the Power button for 2 seconds.

Bluetooth Pairing

Follow these steps to pair your Tronsmart Mirtune C3 speaker with a Bluetooth-enabled device:

1. Ensure the speaker is powered on and in pairing mode (Bluetooth indicator will flash).
2. On your device, enable Bluetooth and search for "Tronsmart Mirtune C3".
3. Select "Tronsmart Mirtune C3" from the list to connect. A voice prompt will confirm successful pairing.

Your browser does not support the video tag.

Video 1: Demonstrates how to power on the speaker and connect it via Bluetooth to a mobile device.

OPERATING INSTRUCTIONS

Music Playback

- **Play/Pause:** Press the Play/Pause button once to play or pause music.
- **Volume Up:** Press the '+' button once to increase volume.
- **Volume Down:** Press the '-' button once to decrease volume.
- **Next Track:** Press and hold the '+' button for 2 seconds to skip to the next track.
- **Previous Track:** Press and hold the '-' button for 2 seconds to skip to the previous track.

Your browser does not support the video tag.

Video 2: Illustrates how to control music playback, including play/pause, volume adjustment, and track skipping using the speaker's buttons.

Voice Assistant

Double-press the Play/Pause button to activate your device's voice assistant (e.g., Siri, Google Assistant).

Phone Calls

- **Answer/End Call:** Press the Play/Pause button once.
- **Reject Call:** Press and hold the Play/Pause button for 2 seconds.
- **Switch Audio:** During a call, press the Bluetooth button once to switch audio between the speaker and your phone.

Your browser does not support the video tag.

Video 3: Demonstrates how to manage phone calls (answer, end, reject) and switch audio output between the speaker and phone.

SoundPulse™ Technology & EQ Modes

The Mirtune C3 features SoundPulse™ technology for enhanced audio. You can switch between different EQ modes or customize them via the Tronsmart App.

- **Switch EQ Mode (Speaker):** Press the 'SoundPulse' button once to cycle through available EQ modes.
- **Customize EQ (App):** Download the Tronsmart App. Connect your speaker via the app. You can then adjust the equalizer settings or select preset modes like Default, SoundPulse, Deep Bass, Classical, Rock, or Custom.

Your browser does not support the video tag.

Video 4: Shows how to switch EQ modes directly on the speaker and how to customize EQ settings using the Tronsmart app.

True Wireless Stereo (TWS) Pairing

Pair two Mirtune C3 speakers for an immersive stereo sound experience.

1. Ensure both speakers are powered on.
2. On both speakers, press and hold the Bluetooth button for 3 seconds to enter TWS pairing mode. You will hear a prompt.
3. Once successfully paired, the Bluetooth indicator on one speaker will flash, and the other will be solid.
4. Connect your device to one of the speakers via Bluetooth. Both speakers will now play in stereo.
5. To exit TWS mode, press the Bluetooth button on either speaker once.

Your browser does not support the video tag.

Video 5: Guides users through the process of entering and exiting True Wireless Stereo (TWS) pairing mode with two Mirtune C3 speakers.

Maintenance

- **Cleaning:** Wipe the speaker with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Water Resistance:** The speaker is IPX7 waterproof, meaning it can be submerged in water up to 1 meter for 30 minutes. Ensure the charging port cover is securely closed before exposure to water. Do not expose to saltwater or other chemicals.
- **Storage:** Store the speaker in a cool, dry place away from extreme temperatures and direct sunlight.

IPX7 Waterproof

Ready to listen by the pool, worry-free about water spray.



Figure 3: The Tronsmart Mirtune C3 speaker demonstrating its IPX7 waterproof capability with water splashing on it.

Troubleshooting

| Problem | Solution |
|---------------------------|---|
| Speaker does not turn on. | Ensure the speaker is charged. Connect to a power source and try again. |

| Problem | Solution |
|--------------------------|---|
| Cannot pair with device. | <ul style="list-style-type: none">Ensure the speaker is in pairing mode (flashing Bluetooth indicator).Turn off and on Bluetooth on your device.Forget "Tronsmart Mirtune C3" from your device's Bluetooth list and try pairing again.Ensure the speaker is within 10 meters of your device. |
| No sound or low volume. | <ul style="list-style-type: none">Increase volume on both the speaker and your connected device.Ensure the speaker is properly connected via Bluetooth.Try playing a different audio source. |
| Speaker not responding. | Reset the speaker by pressing and holding the Bluetooth button for 8 seconds. |

SPECIFICATIONS

| Feature | Detail |
|-------------------------|-------------------------|
| Model Number | Mirtune C3 |
| Brand | Tronsmart |
| Speaker Output Power | 24 Watts |
| Frequency Response | 20 KHz |
| Connectivity Technology | Bluetooth 5.3 |
| Audio Output Mode | Stereo |
| Waterproof Rating | IPX7 |
| Product Dimensions | 21 x 8 x 21 cm |
| Weight | 640 g |
| Battery | 1 9V battery (included) |
| Country of Origin | China |

WARRANTY AND SUPPORT

Tronsmart products are designed and manufactured to the highest standards. For warranty information, technical support, or customer service inquiries, please refer to the warranty card included in your package or visit the official Tronsmart website. Keep your proof of purchase for warranty claims.

Related Documents - Mirtune C3

| | |
|---|---|
|  | <p>Tronsmart Mirtune S100 Portable Outdoor Speaker User Manual</p> <p>User manual for the Tronsmart Mirtune S100 portable outdoor speaker, covering button configuration, stereo pairing, dual audio modes, Tronsmart App connection, and specifications.</p> |
|  | <p>Tronsmart MIRTUNE C2 User Manual</p> <p>User manual for the Tronsmart MIRTUNE C2 portable outdoor speaker, including FCC statements and RF exposure information.</p> |
|  | <p>Tronsmart Element T2 Plus Wireless Speaker User Manual</p> <p>User manual for the Tronsmart Element T2 Plus Wireless Speaker, covering setup, Bluetooth connection, TWS pairing, NFC streaming, AUX-IN mode, TF card playback, charging, and specifications.</p> |
| | <p>Tronsmart Mirtune S100 Portable Outdoor Speaker User Manual</p> <p>This user manual provides instructions for the Tronsmart Mirtune S100 portable outdoor speaker, covering button configuration, stereo pairing, Bluetooth connection, and app usage.</p> |
|  | <p>Tronsmart Bang SE Portable Party Speaker User Manual</p> <p>User manual for the Tronsmart Bang SE Portable Party Speaker, detailing button configurations, usage instructions, Bluetooth connectivity, stereo pairing, and specifications.</p> |
|  | <p>Tronsmart Bang SE Portable Party Speaker FAQ</p> <p>Frequently asked questions about the Tronsmart Bang SE portable party speaker, covering charging, speakerphone functionality, stereo pairing, charging phones, microphone support, Bluetooth connections, usage while charging, USB playback, light synchronization, and resetting the device.</p> |

Page 1 of 34 FCC ID: 2AV3Z-MIRTUNECL3PLUS Report No.: LCSA09044158EB

FCC TEST REPORT

For

Shenzhen Geekbuy E-commerce Co., LTD.

Portable Outdoor Speaker

Test Model: Mirtune C3 Plus

Additional Model No.: Mirtune C3

Prepared for

Address

Shenzhen Geekbuy E-commerce Co., LTD.

Warehouse 101H, No. 49 Wuhe Avenue, Wuhe Community Bantian Street, Longgang District, Shenzhen, China

Shenzhen LCS Compliance Testing Laboratory Ltd.

101, 201 Building A & 301 Building C, Juj Industrial Park, Yantian District, Shenzhen, 518000, China

Phone: (+86)755-42591332

Fax: (+86)755-42591332

Web: www.lcs-test.com

Mail: webmaster@lcs-test.com

Date of receipt of test sample: September 12, 2024

Number of tested samples: 2

Sample No.: A24109082-1, A24109082-2

Serial number: Prototype

Date of test: September 12, 2024 - October 14, 2024

Date of Report: October 15, 2024

Shenzhen LCS Compliance Testing Laboratory Ltd.

Address: 101, 201 Building A & 301 Building C, Juj Industrial Park, Yantian District, Shenzhen, 518000, China

Tel: (+86)755-42591332 | E-mail: webmaster@lcs-test.com | Web: www.lcs-test.com

Code to check authenticity: 2AV3Z-MIRTUNECL3PLUS

[pdf] Test Report

FCC PART 15 news Test Report BT LE Shenzhen Geekbuy E commerce Co LTD MIRTUNECL3PLUS

Portable Outdoor Speaker 2AV3Z 2AV3ZMIRTUNECL3PLUS mirtunec3plus

Page 1 of 34 FCC ID: 2AV3Z-MIRTUNECL3PLUS Report No.: LCSA09044158EB FCC

TEST REPORT For Shenzhen Geekbuy E-commerce Co., LTD. Portable Outdoor

Speaker Test Model: **Mirtune C3** Plus Additional Model No.: **Mirtune C3** Prepared for

Address : Shenzhen Geekbuy E-commerce Co., LTD. : Warehouse 101H, No. 49...

lang:en score:17 filesize: 1.69 M page_count: 34 document date: 2024-11-08

Page 1 of 37 FCC ID: 2AV3Z-MIRTUNECL3PLUS Report No.: LCSA09044158EA

FCC TEST REPORT

FOR

Shenzhen Geekbuy E-commerce Co., LTD.

Portable Outdoor Speaker

Test Model: Mirtune C3 Plus

Additional Model No.: Mirtune C3

Prepared for

Address

Shenzhen Geekbuy E-commerce Co., LTD.

Warehouse 101H, No. 49 Wuhe Avenue, Wuhe Community Bantian Street, Longgang District, Shenzhen, China

Shenzhen LCS Compliance Testing Laboratory Ltd.

101, 201 Building A & 301 Building C, Juj Industrial Park, Yantian District, Shenzhen, 518000, China

Phone: (+86)755-42591332

Fax: (+86)755-42591332

Web: www.lcs-test.com

Mail: webmaster@lcs-test.com

Date of receipt of test sample: September 12, 2024

Number of tested samples: 2

Sample No.: A24109082-1, A24109082-2

Serial number: Prototype

Date of test: September 12, 2024 - October 14, 2024

Date of Report: October 15, 2024

Shenzhen LCS Compliance Testing Laboratory Ltd.

Address: 101, 201 Building A & 301 Building C, Juj Industrial Park, Yantian District, Shenzhen, 518000, China

Tel: (+86)755-42591332 | E-mail: webmaster@lcs-test.com | Web: www.lcs-test.com

Code to check authenticity: 2AV3Z-MIRTUNECL3PLUS

[pdf] Test Report

Shenzhen Sunspring Electronics Co Ltd Keyboard OJWCG107C Violet Wang Test Report BT Geekbuy E commerce LTD MIRTUNECL3PLUS 2AV3Z 2AV3ZMIRTUNECL3PLUS mirtunec3plus

Page 1 of 37 FCC ID: 2AV3Z-MIRTUNECL3PLUS Report No.: LCSA09044158EA FCC

TEST REPORT FOR Shenzhen Geekbuy E-commerce Co., LTD. Portable Outdoor

Speaker Test Model: **Mirtune C3** Plus Additional Model No.: **Mirtune C3** Prepared for

Address : Shenzhen Geekbuy E-commerce Co., LTD. : Warehouse 101H, No. ...

lang:en score:16 filesize: 1.34 M page_count: 37 document date: 2024-11-07