

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Nook](#) /
- › [Nook Barnes & Noble Nook Glowlight 4e eReader User Manual](#)

## Nook Nook Glowlight 4e

# Nook Glowlight 4e eReader User Manual

Model: Nook Glowlight 4e

## INTRODUCTION

The Nook Glowlight 4e is a compact and lightweight eReader designed for an immersive reading experience. Featuring a 6-inch high-resolution touchscreen with built-in glare, scratch, and fingerprint resistance, it offers a paper-like display. The device includes GlowLight illumination for comfortable reading in various lighting conditions, physical page-turning buttons, and 8GB of storage for thousands of titles. Its long battery life ensures weeks of reading on a single charge, making it ideal for travel.

## SETUP

### 1. Unboxing and Initial Charge

Upon unboxing your Nook Glowlight 4e, ensure all components are present. The package typically includes the Nook Glowlight 4e eReader and a charging cable. Before first use, it is recommended to fully charge the device. Connect the charging cable to the USB-C port located at the bottom of the eReader and plug the other end into a compatible USB power adapter (not included) or a computer's USB port.




Image: Top and bottom views of the Nook Glowlight 4e, highlighting the power button on top and the USB-C charging port on the bottom.

### 2. Powering On

To power on your Nook, press and hold the power button located on the top edge of the device until the screen illuminates.

### 3. Wi-Fi Connection

During the initial setup, you will be prompted to connect to a Wi-Fi network. This is essential for downloading books and accessing online features. Select your desired network from the list and enter the password if required. The Nook supports wireless

connectivity via Wi-Fi (802.11 b/g/n).

## 4. Account Setup

Follow the on-screen instructions to set up or log in to your Barnes & Noble account. This account is necessary to purchase and download content from the Barnes & Noble store.

# OPERATING YOUR NOOK GLOWLIGHT 4E

---

## 1. Basic Navigation

The Nook Glowlight 4e features both a touchscreen and physical page-turning buttons for navigation. You can swipe across the screen to turn pages or use the dedicated buttons on the side of the device. The home screen provides access to your library, the Barnes & Noble store, and other settings.




Image: Front view of the Nook Glowlight 4e, showing a book page displayed on its screen, with physical page-turn buttons visible on the sides.

## 2. Reading Experience

The 6-inch high-resolution screen provides a clear and comfortable reading experience. The built-in GlowLight illumination can be adjusted to suit your environment, allowing for comfortable reading in low light or bright sunlight. Tap the center of the screen while reading to access reading options, such as font size, line spacing, and GlowLight intensity.

## 3. Library Management

Your purchased and downloaded books are stored in your library. From the home screen, navigate to your library to view and open your titles. The 8GB of internal storage allows you to carry thousands of books with you.



Image: Angled view of the Nook Glowlight 4e, displaying the library interface with various book covers, demonstrating content browsing.

## 4. Adding Content

You can add new books to your Nook by purchasing them directly from the Barnes & Noble store via Wi-Fi. The Nook Glowlight 4e supports text file types such as ePub, PDF, Adobe DRM ePub, and PDF.

## 5. NOOK Cloud and Reading App

The free NOOK Reading App for iPhone, iPad, and Android devices allows you to synchronize your reading progress across multiple devices. Start reading on your Nook and continue seamlessly on your smartphone or tablet using the NOOK Cloud feature.

## 6. B&N Readouts

Explore B&N Readouts for a daily selection of free book excerpts, magazine articles, and curated blogs, offering quick reads and new discoveries.

# MAINTENANCE

---

## 1. Cleaning Your Device

To clean the screen and body of your Nook, use a soft, lint-free cloth. For stubborn smudges, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive materials, as these can damage the screen or finish.

## 2. Storage

Store your Nook in a cool, dry place away from direct sunlight and extreme temperatures. When not in use for extended periods, ensure the battery has some charge (around 50%) to prolong its lifespan.

## 3. Software Updates

Periodically check for software updates to ensure your Nook has the latest features and performance improvements. You can usually find this option in the device settings under "Software" or "About Nook."

## TROUBLESHOOTING

---

- **Device Not Responding:** If your Nook becomes unresponsive, try holding the power button for 15-20 seconds to perform a hard reset.
- **Wi-Fi Connection Issues:** Ensure your Wi-Fi network is active and you have entered the correct password. Try restarting your Nook and your Wi-Fi router.
- **Battery Draining Quickly:** Reduce GlowLight brightness, turn off Wi-Fi when not needed, and ensure no applications are running in the background. Battery life is rated for weeks on a single charge, but heavy usage of Wi-Fi and high brightness can reduce this.
- **Cannot Download Books:** Check your Wi-Fi connection and ensure you are logged into your Barnes & Noble account. Verify that your payment method is up to date if purchasing new content.
- **Screen Glitches/Flickering:** Try restarting the device. If the issue persists, contact Nook support.

## SPECIFICATIONS

---

<b>Model Name</b>	Nook Glowlight 4e
<b>Screen Size</b>	6 Inches
<b>Display Resolution</b>	1024 x 768 (212 dpi)
<b>Display Technology</b>	LED (with GlowLight Illumination)
<b>Memory Storage Capacity</b>	8 GB
<b>Connectivity Technology</b>	Wi-Fi (802.11 b/g/n)
<b>Battery Life</b>	Weeks on a single charge (typical usage)
<b>Product Dimensions</b>	6.11 x 0.32 x 4.72 inches
<b>Item Weight</b>	10.2 ounces
<b>Color</b>	Black
<b>Included Components</b>	Charging Cable
<b>Supported File Types</b>	ePub, PDF, Adobe DRM ePub and PDF




Image: Side view of the Nook Glowlight 4e, illustrating its compact dimensions of 6.11 inches in height, 0.32 inches in thickness, and 4.72 inches in width.

## WARRANTY AND SUPPORT

This Nook Glowlight 4e is a renewed product. Please refer to the specific warranty information provided at the time of purchase for details regarding coverage. Typically, renewed products come with a limited warranty from the seller or refurbisher. For general support, software updates, and additional resources, please visit the official Barnes & Noble Nook support website.

For issues related to your purchase, a 90-day return/replacement policy may apply. Please check your purchase details for specific terms.

For further assistance, you may contact Barnes & Noble Nook customer support through their official channels.