



Manuals.plus /

› VIZIO /

› VIZIO 75-Inch V-Series 4K UHD HDR Smart TV (Model V4K75C-0804) Instruction Manual

VIZIO V4K75C-0804

VIZIO 75-Inch V-Series 4K UHD HDR Smart TV Instruction Manual

Model: V4K75C-0804

INTRODUCTION

This manual provides essential information for the setup, operation, and maintenance of your VIZIO 75-Inch V-Series 4K UHD HDR Smart TV, Model V4K75C-0804. This television features stunning 4K HDR performance with Dolby Vision HDR10+ and HLG, DLED backlighting, advanced gaming features like Auto Low Latency Mode (ALLM) and Variable Refresh Rate (VRR), and WiFi 6 dual-band connectivity for seamless streaming.

WHAT'S IN THE BOX

Verify that all components are present:

- VIZIO 75-Inch V-Series 4K UHD HDR Smart TV
- Remote Control
- Power Cable
- TV Stand (2 legs)
- Quick Start Guide (this document)

SETUP

1. Unpacking and Placement

Carefully remove the TV from its packaging. It is recommended to have two people for safe handling due to the size and weight of the television. Place the TV on a stable, flat surface or prepare for wall mounting.

2. Stand Installation (Optional)

If using the included TV stand:

1. Place the TV screen-down on a soft, clean surface to prevent scratches.
2. Align each stand leg with the corresponding slots on the bottom of the TV.
3. Secure the legs using the provided screws. Ensure they are tightened firmly.

3. Wall Mounting (Optional)

If wall mounting, ensure you use a VESA-compatible wall mount (sold separately) that supports the TV's weight and size. Follow the instructions provided with your wall mount. The TV's VESA mounting pattern is typically 400mm x 200mm, but refer to the specifications for exact details.

4. Connecting Devices

Connect your external devices (cable box, Blu-ray player, gaming console, etc.) to the TV's input ports. Refer to the image below for port locations.



Figure 1: Close-up view of the VIZIO TV's input ports. This image displays the USB 2.0 port, HDMI 3, HDMI 2, HDMI 1 (eARC), Antenna input, and Optical Audio Out port, located on the side and rear of the television.

- **HDMI:** Connect high-definition devices using HDMI cables. The TV features multiple HDMI ports, including HDMI 1 with eARC support for enhanced audio return.
- **USB:** Use the USB 2.0 port for media playback or firmware updates.
- **Antenna:** Connect an antenna for over-the-air broadcast channels.
- **Optical Audio Out:** Connect to a soundbar or audio receiver for digital audio output.

5. Power Connection

Connect the power cable to the TV's power input and then to a working electrical outlet.

6. Initial Setup Wizard

Upon first power-on, the TV will guide you through an initial setup wizard. This includes selecting your language, connecting to your Wi-Fi network, and agreeing to terms and conditions. Follow the on-screen prompts to complete the setup.

OPERATING YOUR VIZIO SMART TV

1. Remote Control Overview

The included remote control provides quick access to various functions and streaming services. Familiarize yourself with the buttons for power, input selection, volume, channel, navigation, and dedicated app buttons.

2. SmartCast / Smart TV Features

Your VIZIO Smart TV comes with SmartCast, providing access to a wide array of streaming apps and content. The home screen displays trending content, recently used apps, and various collections. You can navigate through these options using the remote's directional pad.

3. Picture Settings

To optimize your viewing experience, access the picture settings menu. Here you can adjust:

- **Picture Modes:** Choose from various presets like Standard, Vivid, Calibrated, Game, or Custom.
- **HDR Settings:** The TV supports Dolby Vision HDR10+ and HLG, automatically enhancing contrast and color for compatible content.
- **Brightness, Contrast, Color, Tint, Sharpness:** Fine-tune these settings to your preference.

4. Audio Settings

The TV features DTS Virtual X for an immersive audio experience. Adjust audio settings through the menu to select sound modes (e.g., Standard, Music, Movie) or customize equalizer settings.

5. Gaming Features

For an enhanced gaming experience, the V-Series TV includes:

- **Auto Low Latency Mode (ALLM):** Automatically switches the TV to a low-latency mode when a gaming console is detected, reducing input lag.
- **Variable Refresh Rate (VRR):** Synchronizes the TV's refresh rate with the gaming console's frame rate, minimizing screen tearing and stuttering.

6. Connectivity

- **Wi-Fi 6 Dual-Band:** Connect to your home network for streaming and smart features. Wi-Fi 6 offers faster and more reliable performance.
- **Bluetooth:** Pair Bluetooth-compatible devices such as headphones for private listening or game controllers.
- **AirPlay:** Wirelessly share content from your iPhone, iPad, or Mac directly to your VIZIO TV.

MAINTENANCE

Cleaning the Screen

To clean the screen, first unplug the TV. Use a soft, lint-free cloth lightly dampened with water or a specialized

screen cleaner. Do not use harsh chemicals, abrasive cleaners, or paper towels, as these can damage the screen. Wipe gently to remove dust and smudges.

General Care

Keep the TV in a well-ventilated area, away from direct sunlight, heat sources, and excessive moisture. Avoid placing heavy objects on the TV or blocking ventilation openings. Regularly dust the TV's exterior and vents.

TROUBLESHOOTING

If you encounter issues with your VIZIO TV, try the following steps:

- **No Power:** Ensure the power cable is securely connected to both the TV and the electrical outlet. Try plugging another device into the outlet to confirm it's working.
- **No Picture/Sound:** Verify that the correct input source is selected on the TV. Check all cable connections (HDMI, audio) to ensure they are firm and correctly inserted.
- **Poor Picture Quality:** Adjust picture settings (brightness, contrast, sharpness). Ensure your content source is high-quality (e.g., 4K content for 4K display).
- **Remote Not Responding:** Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the TV's sensor.
- **Network Connectivity Issues:** Check your Wi-Fi router and modem. Restarting them can often resolve connection problems. Ensure the TV is within range of your Wi-Fi signal.
- **SmartCast App Issues:** Try restarting the TV by unplugging it for 30 seconds and plugging it back in. Ensure the TV's firmware is up to date.

If problems persist, consult the VIZIO support website or contact customer service.

SPECIFICATIONS

Feature	Detail
Brand	VIZIO
Model Name	V4K75C-0804
Screen Size	75 Inches
Display Technology	LED
Resolution	4K UHD
Product Dimensions (L x W x H)	13.44 x 65.7 x 40.52 inches
Item Weight	82.8 pounds
Aspect Ratio	16:9
Special Features	Auto Low Latency Mode (ALLM), Variable Refresh Rate (VRR), Flat Panel
Connectivity Technology	Bluetooth, Wi-Fi (WiFi 6 Dual-Band)
Included Components	Power Cable, Remote Control, TV Stand
Mounting Type	Table Mount, Wall Mount

WARRANTY AND SUPPORT

For detailed warranty information, please refer to the warranty card included with your product or visit the official VIZIO support website. For technical assistance, troubleshooting, or service inquiries, please contact VIZIO Customer Support.