JADEMALL Keyboard Case for Samsung Tab A9+/A9 Plus 11" (SM-X210/X215/X218)

JADEMALL Keyboard Case for Samsung Tab A9+/A9 Plus 11" - User Manual

Model: SM-X210/X215/X218

1. Product Overview

This manual provides instructions for the JADEMALL Keyboard Case designed for the Samsung Galaxy Tab A9+/A9 Plus 11-inch (2023) tablet. This accessory transforms your tablet into a versatile laptop-like device, enhancing productivity and user experience. The case features a detachable AZERTY Bluetooth keyboard and offers multiple viewing angles.
Key features include:

- Specifically designed for Samsung Tab A9+/A9 Plus 11" (SM-X210/X215/X218).
- AZERTY Bluetooth keyboard for quick and reliable connection.
- Magnetic detachable keyboard for flexible use.
- Three integrated grooves for comfortable viewing angles.
- Automatic wake/sleep function to conserve tablet battery.

2. Compatibility

This keyboard case is exclusively compatible with the**Samsung Tab A9+/A9 Plus 11-inch 2023 models (SM-X210/X215/X218)**. It is not compatible with other tablet models, including the Samsung Tab A9 8.7-inch. Please verify your tablet's model number before use.



Figure 2.1: Compatibility chart for Samsung Tab A9+/A9 Plus 11" models.

3. Setup Instructions

3.1 Installing the Tablet into the Case

1. Gently align your Samsung Tab A9+/A9 Plus 11" tablet with the case.
2. Insert the tablet into the protective shell, ensuring all edges are securely fitted.
3. Verify that all ports, buttons, and the camera are accessible through the precise cutouts.



Figure 3.1: Case with precise cutouts for charging port and camera.

3.2 Bluetooth Keyboard Pairing

The keyboard uses Bluetooth technology for wireless connection. Follow these steps to pair it with your tablet:

1. Ensure the keyboard is charged (refer to Section 5.1 for charging instructions).
2. Turn on the keyboard by sliding the **ON/OFF** switch to the "ON" position. The power indicator light will illuminate briefly.
3. Press the **"Connect"** button on the keyboard. The Bluetooth indicator light will start blinking, indicating it's in pairing mode.
4. On your Samsung Tab A9+/A9 Plus, go to **Settings > Connected devices > Bluetooth** and turn Bluetooth ON.
5. Your tablet will search for available Bluetooth devices. Select **"Bluetooth Keyboard"** (or similar name) from the list.
6. If prompted, enter the pairing code displayed on your tablet onto the keyboard and press **Enter**.
7. Once paired, the Bluetooth indicator light on the keyboard will turn off, and your tablet will show the keyboard as "Connected."



Figure 3.2: Magnetic Bluetooth keyboard and multi-device compatibility.



Figure 3.3: Keyboard controls and charging port.

4. Operating Instructions

4.1 Using the Keyboard

The AZERTY layout keyboard provides a familiar typing experience. It can be used for various tasks, from document creation to email communication.

- **Function Keys:** The top row of keys includes function keys (F1-F12) which may have secondary functions when pressed with the **Fn** key. Refer to your tablet's operating system for specific key mappings.
- **Special Characters:** To type special characters, use the **Alt Gr** key in combination with the desired key, as per standard AZERTY layout.

4.2 Adjusting Viewing Angles

The case features three integrated grooves that allow you to adjust the tablet's viewing angle for optimal comfort. Simply place the bottom edge of your tablet into one of the grooves to set the desired angle (110°, 120°, or 130°).




Figure 4.1: Adjustable viewing angles.

4.3 Detaching the Keyboard

The keyboard is magnetically attached to the case. You can easily detach it when not needed or if you prefer to use the tablet in a different orientation. The keyboard can also be used independently with other Bluetooth-enabled devices.



Figure 4.2: Tablet and detached keyboard in use.

5. Maintenance

5.1 Charging the Keyboard

The keyboard is powered by a rechargeable battery. When the battery is low, the charge indicator light will blink. To charge:

1. Connect the provided charging cable to the keyboard's charging port (as shown in Figure 3.3).
2. Connect the other end of the cable to a USB power source (e.g., computer, wall adapter).
3. The charge indicator light will illuminate during charging and turn off or change color when fully charged.

The keyboard features a long-lasting battery, providing extended usage time between charges.

5.2 Cleaning and Care

- To clean the keyboard and case, use a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- Keep the keyboard and case away from liquids and extreme temperatures.

- The keyboard is designed to be scratch-resistant, but proper care will prolong its appearance and functionality.

6. Troubleshooting

- **Keyboard not connecting:**
  - Ensure the keyboard is turned ON and fully charged.
  - Make sure Bluetooth is enabled on your tablet.
  - Press the "Connect" button on the keyboard to enter pairing mode.
  - Forget the keyboard from your tablet's Bluetooth settings and try pairing again.
  - Restart both your tablet and the keyboard.
- **Keys not responding:**
  - Check the keyboard's battery level and charge if necessary.
  - Ensure the keyboard is properly connected via Bluetooth.
  - Clean any debris from around the keys.
- **Tablet not waking/sleeping:**
  - Ensure the tablet is correctly seated in the case.
  - Check your tablet's settings for wake/sleep cover functionality.

7. Specifications

Brand	JADEMALL
Compatible Devices	Samsung Tab A9+/A9 Plus 11" (SM-X210/X215/X218), Other Bluetooth-enabled tablets/smartphones
Connectivity Technology	Bluetooth
Keyboard Description	Detachable Bluetooth
Keyboard Layout	AZERTY
Special Feature	Detachable Bluetooth
Material	Plastic
Power Source	Battery Powered (rechargeable)
Number of Keys	105
Operating System Compatibility	Android (Minimum Android 12.0 required for some features)
Water Resistance Level	Not waterproof

8. Warranty and Support

JADEMALL is committed to providing the best shopping experience for every customer. If you have any questions or encounter issues with your JADEMALL Keyboard Case for Samsung Tab A9+/A9 Plus 11", please do not hesitate to

contact us. We will provide a satisfactory solution and ensure a pleasant shopping experience.
For support, please refer to the contact information provided with your purchase or visit the official JADEMALL website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question