

Manuals.plus /

- › Netzu /
- › Netzu Loud Alarm Clock with Bed Shaker (Model 6208ZD) - User Manual

Netzu 6208ZD

Netzu Loud Alarm Clock with Bed Shaker

Model: 6208ZD

1. PRODUCT OVERVIEW

The Netzu Loud Alarm Clock is designed to provide effective wake-up solutions for heavy sleepers, individuals with hearing impairments, and anyone needing a reliable alarm. It features a vibrant RGB display, a powerful bed shaker, dual alarm settings, and adjustable brightness levels.



Image: The Netzu Loud Alarm Clock, a white digital alarm clock with a large, colorful display and a connected bed shaker.

2. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x Netzu Alarm Clock
- 1 x Power Cable
- 1 x Power Adapter
- 1 x User Manual



Image: A visual representation of the alarm clock, power cable, adapter, and manual included in the package.

3. SETUP

3.1 Power Connection

1. Connect the power cable to the alarm clock.
2. Plug the power adapter into a standard wall outlet. The clock display will illuminate.



Image: The alarm clock plugged into a wall outlet via its power adapter.

3.2 Battery Backup (Not Included)

The alarm clock requires 2*AAA batteries (not included) for memory function during power outages. These batteries maintain time settings but do not power the display or alarm functions.

- Open the battery compartment on the back of the clock.
- Insert 2 AAA batteries, observing polarity.
- Close the battery compartment.



Image: An illustration showing the alarm clock's battery compartment and the function of battery backup for time memory.

3.3 Bed Shaker Connection

Connect the bed shaker cable to the designated port on the alarm clock. Place the bed shaker under your pillow or mattress for optimal vibration.

4. OPERATING INSTRUCTIONS

4.1 Setting Time and 12/24H Format

1. Press the 'TIME SET' button (location may vary, refer to physical unit).
2. Use the '+' or '-' buttons to adjust hours and minutes.
3. Press 'TIME SET' again to confirm each step.
4. To switch between 12-hour and 24-hour format, press the '12/24H' button (or 'TIME SET' repeatedly until the option appears).



Image: The alarm clock showing time in both 12-hour (AM/PM) and 24-hour formats.

4.2 Setting Dual Alarms (A1 & A2)

The clock supports two independent alarms.

1. Press the 'ALARM 1' button. The hour display will flash.
2. Use the '+' or '-' buttons to set the desired alarm hour. Press 'ALARM 1' to confirm.
3. The minute display will flash. Use '+' or '-' to set the desired alarm minute. Press 'ALARM 1' to confirm.
4. Repeat the process for 'ALARM 2' using the 'ALARM 2' button.
5. To activate/deactivate an alarm, press the corresponding 'ALARM' button until the alarm icon (A1 or A2) appears/disappears on the display.

Loud Dual Alarm

Make sure you don't miss any more schedules



Image: The alarm clock displaying two separate alarm times, indicating its dual alarm capability.

4.3 Alarm Modes

Choose from three wake-up modes:

- **Vibration Only:** The bed shaker activates without sound.
- **Ringing Only:** The alarm sounds without vibration.
- **Ringing + Vibration:** Both the alarm sound and bed shaker activate simultaneously.

To select an alarm mode, press the 'MODE' button (or the 'ALARM' button repeatedly after setting the time) until the desired icon appears on the display.

3 Wake-up Modes for You



Vibration Only



Ringing Only



Ringing + Vibration



Image: A visual guide illustrating the three available alarm modes: vibration only, ringing only, and a combination of ringing and vibration.

4.4 Snooze Function

When the alarm sounds, gently touch the 'SNOOZE' area on top of the clock to activate the snooze function. The alarm will pause for 9 minutes and then sound again.



Image: A hand touching the top of the alarm clock to activate the snooze function.

4.5 Adjusting Display Brightness

The clock offers 5 levels of brightness, including an 'OFF' setting for the display.

1. Press the 'DIMMER' button (or a dedicated brightness button) to cycle through the brightness levels (Lv.4, Lv.3, Lv.2, Lv.1, OFF).
2. Select the desired brightness level.



Image: The alarm clock display shown at four different brightness levels (L1-L4) and completely off.

4.6 Changing RGB Display Colors

The alarm clock features an RGB display, allowing you to customize the color of the digits.

1. Press the 'COLOR' button (or a dedicated RGB button) to cycle through the available color options.
2. Stop at your preferred color.



Image: A grid of alarm clock displays, each showing the time in a different RGB color.

5. MAINTENANCE

To ensure the longevity and proper functioning of your alarm clock:

- Wipe the clock surface with a soft, dry cloth.
- Avoid using abrasive cleaners or solvents.
- Keep the device away from water and excessive humidity.
- Do not expose to direct sunlight or extreme temperatures.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock display is off.	No power or display brightness set to OFF.	Ensure power adapter is securely plugged in. Check brightness setting and adjust if set to OFF.
Alarm does not sound/vibrate.	Alarm not activated, incorrect mode, or bed shaker unplugged.	Verify alarm is set and activated (A1/A2 icon visible). Check alarm mode setting. Ensure bed shaker is securely plugged in.
Time is incorrect after power outage.	No battery backup or batteries are depleted.	Install 2 AAA batteries for memory function. Replace old batteries if necessary. Reset the time manually.
Snooze function not working.	Incorrect touch or button malfunction.	Ensure you are touching the designated 'SNOOZE' area. If issue persists, contact support.

7. SPECIFICATIONS

- **Brand:** Netzu
- **Model Number:** 6208ZD
- **Display Type:** Digital
- **Power Source:** Corded Electric
- **Battery Backup:** 2 x AAA (for memory function, not included)
- **Special Features:** Adjustable Brightness (5 levels), Adjustable Volume, Large Display, Loud Alarm (up to 115dB), Snooze, RGB Color Display, Bed Shaker
- **Product Dimensions:** 6.3"W x 2.9"H
- **Material:** Plastic
- **Room Type:** Bedroom, Home Office, Kid's Room, Living Room, Study Room

8. WARRANTY INFORMATION

This product comes with a standard manufacturer's warranty. Please refer to the product packaging or contact your retailer for specific warranty terms and conditions.

9. SUPPORT

For further assistance, technical support, or inquiries regarding your Netzu Loud Alarm Clock, please contact the retailer or visit the official Netzu website for customer service information.