

[Manuals.plus](#) /

› [BINBOND](#) /

› BINBOND Men's Waterproof Chronograph Quartz Watch Model 2521 Instruction Manual

BINBOND 2521

BINBOND Men's Waterproof Chronograph Quartz Watch Model 2521 Instruction Manual

Model: 2521 | Brand: BINBOND

INTRODUCTION

Thank you for choosing the BINBOND Model 2521 Men's Quartz Watch. This timepiece combines elegant design with practical features, including a luminous display, chronograph functionality, and water resistance. To ensure optimal performance and longevity, please read this instruction manual carefully before using your watch.

PRODUCT OVERVIEW



Figure 1: BINBOND Model 2521 watch on a wrist.

The BINBOND Model 2521 features a durable stainless steel case and band, a striking blue analog dial with luminous hands and markers, and a quartz movement for precise timekeeping. It includes a date display and is designed for everyday wear.

SETUP

1. Setting the Time and Date

1. **Pull out the crown:** Gently pull the crown (the knob on the side of the watch) to the first click position to set the date, or to the second click position to set the time.
2. **Adjust the date:** In the first click position, turn the crown clockwise or counter-clockwise to adjust the date. Avoid setting the date between 9 PM and 3 AM, as this can interfere with the automatic date change mechanism.
3. **Adjust the time:** In the second click position, turn the crown to move the hour and minute hands. Set the time to the desired hour, ensuring the AM/PM is correct for the date change.
4. **Push in the crown:** Once the time and date are set, push the crown back into its normal operating position to start the watch.

2. Adjusting the Stainless Steel Band

The watch comes with a link removal tool to adjust the band length for a comfortable fit. Carefully follow the instructions provided with the tool to remove or add links. If you are unsure, it is recommended to seek professional assistance to avoid damaging the band or watch.

Your browser does not support the video tag.

Video 1: This video demonstrates the appearance of the watch, including its band and clasp mechanism, which can assist in understanding band adjustment.

OPERATING THE WATCH

Luminous Function




Figure 2: Luminous display of the watch in low light.

The hands and hour markers of your BINBOND watch are coated with a luminous material. To activate the glow, expose the watch to a bright light source (natural or artificial) for a few minutes. The intensity and duration of the glow will depend on the exposure time and light intensity.

Chronograph Function

This watch features a chronograph (stopwatch) function. The specific operation of the chronograph sub-dials and pushers may vary. Refer to the detailed diagrams typically found in the included small manual for precise instructions on starting, stopping, and resetting the chronograph.

MAINTENANCE

Water Resistance



Figure 3: Water resistance feature of the watch.

Your BINBOND watch is rated for 30 meters (3 ATM) water resistance. This means it is suitable for daily use, such as splashes, rain, or brief immersion in water. It is **not** recommended for swimming, diving, or showering with hot water, as steam and temperature changes can compromise the seals. Always ensure the crown is fully pushed in before any contact with water.

Cleaning and Care

- Wipe the watch regularly with a soft, dry cloth to remove dust and smudges.

- For the stainless steel band, a slightly damp cloth can be used, followed by immediate drying.
- Avoid exposing the watch to extreme temperatures, direct sunlight for prolonged periods, or strong magnetic fields.
- Do not use chemical cleaners or abrasive materials on the watch.

Battery Replacement

The watch is powered by an LR44 battery. When the watch stops or the second hand begins to skip, it indicates a low battery. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and functionality.

TROUBLESHOOTING

- **Watch not running:** Check if the crown is fully pushed in. If it is, the battery may need replacement.
- **Incorrect time/date:** Refer to the "Setting the Time and Date" section to re-adjust. Ensure the crown is pulled out to the correct position for each adjustment.
- **Band adjustment issues:** If you experience difficulty with the link removal tool or if pins do not stay in place after adjustment, it is recommended to consult a professional jeweler or watch repair service.
- **Water ingress:** If water appears inside the watch, immediately take it to a professional for inspection and repair to prevent further damage.

SPECIFICATIONS

PRODUCT PARAMETERS

MODEL:2521
CASE:METAL
STRAP:WHITE STEEL
MOVEMENT:QUARTZ
STRAP LENGTH:260MM
DIAL DIAMETER:43MM
STRAP WIDTH:21MM
CASE THICKNESS:11MM
WATERPROOF:
30M LIFE WATERPROOF



Figure 4: Product parameters and dimensions.

Feature	Detail
Model Number	2521
Movement	Quartz
Case Material	Metal
Band Material	Stainless Steel
Dial Diameter	43 mm
Case Thickness	12 mm
Strap Length	260 mm
Water Resistance Depth	30 Meters (3 ATM)

Feature	Detail
Battery Type	LR44 (included)
Display Type	Analog

WARRANTY

Your BINBOND watch comes with a VIP Worldwide Warranty. Please refer to the warranty card included with your purchase for specific terms, conditions, and duration of coverage. Keep your proof of purchase for warranty claims.

SUPPORT

For further assistance, technical support, or inquiries regarding your BINBOND watch, please contact the manufacturer's customer service. Contact information can typically be found on the product packaging or the official BINBOND website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question