

OUKITEL C58 Pro

OUKITEL C58 Pro Unlocked Cell Phone User Manual

Model: C58 Pro | Brand: OUKITEL

1. INTRODUCTION

This manual provides essential instructions for setting up, operating, and maintaining your OUKITEL C58 Pro Unlocked Cell Phone. Please read this manual thoroughly to ensure proper usage and to maximize the features of your device.

2. PACKAGE CONTENTS

Upon opening the package, verify that all items listed below are present:

- OUKITEL C58 Pro Smartphone
- Charger
- Type-C Cable
- Maintenance Card
- Card Pin & Protective Case

50MP+8MP Camera

Capture the best moments



Image: Contents of the OUKITEL C58 Pro package, including the smartphone, charger, Type-C cable, SIM ejector tool, protective case, and documentation.

3. DEVICE OVERVIEW

Familiarize yourself with the physical components of your OUKITEL C58 Pro smartphone.



Image: Front and rear view of the OUKITEL C58 Pro smartphone, showcasing its design and camera setup.

3.1. Physical Components

- **Display:** 6.7-inch HD+ screen with 90Hz refresh rate.
- **Rear Camera:** 50MP main camera.
- **Front Camera:** 8MP for selfies and video calls.
- **Volume Buttons:** Located on the side for adjusting audio levels.
- **Power Button:** Used to power on/off the device and lock/unlock the screen.
- **SIM/TF Card Slot:** Supports two Nano SIM cards and one Micro SD/TF card for storage expansion.
- **USB Type-C Port:** For charging and data transfer.
- **3.5mm Audio Jack:** For connecting headphones.

C58 Pro Smartphone

It has everything you want.




Image: Key features of the OUKITEL C58 Pro, including its operating system, biometric security, card slots, navigation capabilities, and audio jack.

4. SETUP

4.1. Inserting SIM and TF Cards

1. Locate the SIM card tray on the side of your phone.
2. Insert the provided card pin into the small hole next to the tray to eject it.
3. Carefully place your Nano SIM card(s) and/or Micro SD/TF card into the designated slots on the tray. Ensure the cards are correctly oriented.
4. Gently push the tray back into the phone until it clicks into place.




Image: Illustration of the triple card slot for dual SIM and TF card expansion.

4.2. Initial Power On and Setup

1. Press and hold the Power button until the OUKITEL logo appears.
2. Follow the on-screen prompts to select your language, connect to Wi-Fi, and set up your Google account.
3. To activate the full 24GB RAM (6GB physical + 18GB virtual), navigate to **Settings > Memory Expansion** and restart your device as prompted.

5. OPERATING THE DEVICE

5.1. Display and Navigation

The 6.7-inch HD+ display offers vibrant colors and a smooth 90Hz refresh rate for an enhanced user experience. Navigate through the interface using touch gestures: tap to select, swipe to scroll, pinch to zoom.




Image: Visual comparison demonstrating the fluidity of the 90Hz display versus a standard 60Hz display.

5.2. Camera Usage

The OUKITEL C58 Pro features a 50MP main rear camera and an 8MP front camera. Open the Camera app to access various modes including photo, video, portrait, and beauty selfie mode. The sensor automatically adjusts to lighting conditions for optimal results.

Large 5150mAh Battery

OUKITEL C58 Pro is equipped with a large-capacity 5150mAh battery which provides endless battery life and can easily last a whole day



5150mAh
Battery



20H
Calling



7H
Video



20H
Music



8.75mm
Thickness



Image: Examples of photos taken with the OUKITEL C58 Pro's 50MP main camera and 8MP front camera, highlighting selfie capabilities.

5.3. Connectivity

- **4G Network:** The device supports 4G networks and is compatible with GSM carriers such as T-Mobile. (Note: Not compatible with CDMA carriers like AT&T, Cricket Wireless, Verizon, Straight Talk, or U.S. Cellular).
- **NFC:** Utilize NFC for instant payments and quick data exchange with compatible devices.
- **GPS:** Integrated GPS+GLONASS+Beidou+Galileo systems provide accurate location tracking and navigation.




Image: Demonstrating instant payments using the NFC feature of the smartphone.

5.4. Battery Management

The 5150mAh battery provides extended usage, offering up to 625 hours of standby time and 19.5 hours of continuous talk time. For optimal battery life, avoid extreme temperatures and use the provided charger and Type-C cable.




Image: Visual representation of the large 5150mAh battery and its features like OTG support and Type-C charging.

5.5. Security Features

The OUKITEL C58 Pro supports both Face Recognition and Fingerprint Unlocking for secure and convenient access to your device.

- **Face Recognition:** Advanced algorithms provide fast and accurate security, even in low light.
- **Fingerprint Unlocking:** Employs live fingerprint technology for quick unlocking in approximately 0.5 seconds.



Image: Visual guide to setting up and using face recognition and fingerprint unlocking for device security.

6. MAINTENANCE

- Keep your device clean by wiping it with a soft, dry cloth.
- Avoid exposing the phone to extreme temperatures, direct sunlight, or liquids.
- Regularly back up your data to prevent loss.
- Install system updates to ensure optimal performance and security.

7. TROUBLESHOOTING

Problem	Solution
Device does not power on	Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on again.
Poor network signal	Check if your SIM card is correctly inserted. Ensure you are within network coverage. Restart the device. Verify compatibility with your carrier (GSM networks only).
Applications are slow or unresponsive	Close unnecessary background applications. Clear app cache. Restart the device. Ensure RAM expansion is activated via Settings > Memory Expansion .
Battery drains quickly	Reduce screen brightness. Close unused apps. Disable Wi-Fi, Bluetooth, or GPS when not in use. Check for power-intensive apps in battery settings.

8. SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Model Name	OUKITEL C58 Pro
Operating System	Android 14
CPU Model	Unisoc T606 Octa-core
RAM Memory	24 GB (6GB physical + 18GB virtual)
Internal Storage (ROM)	256 GB (Expandable up to 1 TB via TF card)
Screen Size	6.7 Inches HD+
Resolution	1600 x 720
Refresh Rate	90 Hz
Battery Capacity	5150 mAh
Rear Camera	50 MP
Front Camera	8 MP
Connectivity	4G, Wi-Fi, Bluetooth, NFC, OTG
Navigation	GPS+GLONASS+Beidou+Galileo
Package Dimensions	9.92 x 7.36 x 2.32 inches
Item Weight	1.04 pounds

9. WARRANTY AND SUPPORT







OUKITEL offers a 2-year free maintenance service for this product. For any inquiries or assistance, please contact the OUKITEL official service team. Refer to the included Maintenance Card for detailed warranty information and contact methods.

10. PRODUCT OVERVIEW VIDEO

Your browser does not support the video tag.

Video: A general overview of the OUKITEL C58 Pro smartphone, showcasing its design and some features.

Related Documents - C58 Pro

	<p>OUKITEL C61 Series Smartphone User Manual Specs & Features</p> <p>Detailed user manual for the OUKITEL C61 Series smartphone, including specifications, features, safety information, and package contents. Learn about the 6.88-inch HD+ display, Android OS, Unisoc T606 processor, and 5150mAh battery.</p>
	<p>OUKITEL WP28 Rugged Smartphone FAQ - Features, Durability, and Specifications</p> <p>Comprehensive FAQ for the OUKITEL WP28 rugged smartphone. Learn about its IP68/IP69K durability, 10600mAh battery, Android 13, 256GB storage, and more.</p>
	<p>OUKITEL C61 Smartphone User Manual</p> <p>User manual for the OUKITEL C61 smartphone, detailing its features, specifications, and safety information. Includes overview, basic parameters, camera details, connectivity, dimensions, package contents, and warnings.</p>
	<p>OUKITEL P1 Pro Smartphone - Specifications and Overview</p> <p>Detailed specifications and overview of the OUKITEL P1 Pro smartphone, featuring an AMOLED display, 50MP camera, MediaTek Helio G99 processor, and comprehensive connectivity options. Includes package contents, safety warnings, and compliance information.</p>
	<p>OUKITEL WP27 Rugged Smartphone User Manual</p> <p>User manual for the OUKITEL WP27 rugged smartphone, covering device features, setup, battery, safety precautions, and maintenance. Learn how to insert SIM cards, boot the device, send messages, and manage settings.</p>
	<p>OUKITEL WP300 User Manual - Smartphone Guide</p> <p>Comprehensive user manual for the OUKITEL WP300 smartphone, covering setup, safety, features, maintenance, and troubleshooting. Learn how to use your OUKITEL WP300 effectively.</p>

