

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

### Manuals.plus /

› [DEVAISE](#) /

› DEVAISE Whole Piece Standing Desk, 48 x 24 Inch Electric Standing Desk with Adjustable Height, 3-Preset Memory Sit Stand up Desk, One Piece Desktop Computer Desk for Home, Office (White) 48 Inch-Whole Piece White - User Manual

## DEVAISE 48 Inch-Whole Piece White

# DEVAISE Electric Standing Desk User Manual

Model: 48 Inch-Whole Piece White | Brand: DEVAISE

## 1. INTRODUCTION

Thank you for choosing the DEVAISE Electric Standing Desk. This manual provides detailed instructions for the assembly, operation, and maintenance of your new adjustable height desk. Designed for both home and office environments, this desk features a seamless whole-piece desktop, a robust dual-motor lift system, and convenient memory presets for effortless height adjustments.

Please read this manual thoroughly before assembly and use to ensure proper function and safety.

## 2. SAFETY INSTRUCTIONS

- Ensure all components are securely fastened before use.
- Keep children and pets away from the desk during operation.
- Do not place hands or objects near moving parts during height adjustment.
- Avoid overloading the desk. The maximum weight capacity is 180 lbs.
- Do not modify the desk or its components. Use only original parts.
- Disconnect power before cleaning or performing any maintenance.
- Ensure the power cord is not pinched or damaged.
- The desk is equipped with anti-collision sensors. Do not intentionally obstruct its movement.

## 3. PACKAGE CONTENTS

Before beginning assembly, verify that all parts are present and undamaged. Refer to the image below for a visual representation of the components included in your package.

# 15 MINUTES QUICK INSTALLATION

All Holes Are Pre-Drilled And All Accessories Are Pre-Labeled Clearly



**Figure 3.1:** All components of the DEVAISE standing desk laid out for quick installation, including the desktop, leg frames, feet, control panel, and various hardware. All holes are pre-drilled and accessories are clearly labeled for easy identification.

The package includes the whole-piece desktop, dual leg frames, desk feet, the electric control box, digital control panel, power adapter, and all necessary screws and tools for assembly.

## 4. SETUP AND ASSEMBLY

The DEVAISE Electric Standing Desk is designed for quick and easy assembly, typically completed within 15 minutes. Follow these steps for a smooth setup:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Verify against the package contents list.
2. **Attach Leg Frames:** Secure the leg frames to the pre-drilled holes on the underside of the desktop using the provided screws. Ensure they are aligned correctly.
3. **Install Feet:** Attach the desk feet to the bottom of the leg frames.
4. **Mount Control Box and Panel:** Secure the electric control box and the digital control panel to the designated areas under the desktop.
5. **Connect Cables:** Connect all motor cables and the power cable to the control box. Ensure all connections

are firm.

6. **Cable Management:** Utilize the integrated cable holes on the desktop and any provided cable ties to manage wires neatly, preventing tangles and ensuring smooth operation.
7. **Power On:** Plug the power adapter into a wall outlet and then into the control box.

For visual guidance, refer to the assembly diagram in the included step-by-step user guide.

## 5. OPERATING INSTRUCTIONS

### 5.1 Digital Control Panel

Your DEVAISE standing desk is equipped with an intuitive digital control panel for easy height adjustments and memory functions. The panel features an LED display, up/down buttons, and three memory preset buttons.



Figure 5.1: The digital control panel allows for precise height adjustments and saving preferred positions.

- **LED Display:** Shows the current desk height in inches.
- **Up & Down Buttons (▲ / ▼):** Press and hold to smoothly adjust the desk height upwards or downwards. Release to stop at the desired height.

- **Memory Height Buttons (1, 2, 3):** These buttons allow you to save and recall up to three preferred desk heights.
- **'S' Button (Set):** Used to save a new memory preset.

## 5.2 Adjusting Height

To adjust the desk height, simply press and hold the Up (▲) or Down (▼) button until the desk reaches your desired position. The desk can be adjusted between 28.35 inches and 46.46 inches.



Figure 5.2: The desk offers a wide height adjustment range from 28.35 inches to 46.46 inches.

## 5.3 Setting Memory Presets

To save a specific height to a memory preset (1, 2, or 3):

1. Adjust the desk to your desired height using the Up/Down buttons.
2. Press the 'S' button. The LED display will show 'S-'.
3. Within 3 seconds, press the desired memory button (1, 2, or 3). The display will show 'S-1', 'S-2', or 'S-3' to confirm the setting.

To recall a saved height, simply press the corresponding memory button (1, 2, or 3). The desk will automatically move to the saved position.

## 5.4 Anti-Collision Feature

The desk is equipped with an anti-collision system. If the desk encounters an obstacle during height adjustment, it will automatically stop and reverse slightly to prevent damage. Ensure the area around the desk is clear before operation.

## 6. MAINTENANCE

---

- **Cleaning:** Wipe the desktop and frame with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Inspection:** Periodically check all screws and connections to ensure they are tight. Retighten if necessary.
- **Cable Management:** Ensure cables remain tidy and are not caught or pinched by moving parts.
- **Lubrication:** The lift mechanism is designed to be maintenance-free and does not require lubrication.

## 7. TROUBLESHOOTING

---

If you encounter any issues with your DEVAISE Electric Standing Desk, please refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Desk does not move.	Power cord disconnected; Control box not properly connected; Overload.	Check power connections. Ensure all cables are securely plugged into the control box. Reduce weight on the desk.
Desk moves unevenly or makes unusual noise.	Loose connections; Obstruction; Uneven weight distribution.	Check all screws and connections. Remove any obstructions. Distribute weight evenly on the desktop.
Error code displayed on control panel.	Specific system error.	Refer to the detailed error code list in the full user manual (if applicable) or contact customer support. Try unplugging and replugging the power after 30 seconds.
Anti-collision feature triggers too often.	Sensitivity setting; Obstruction.	Ensure no objects are in the path of the desk's movement. If the issue persists, contact customer support for potential sensitivity adjustment.

If the problem persists after attempting these solutions, please contact DEVAISE customer service for further assistance.

## 8. SPECIFICATIONS

---

# UPTO 30% STABLER

Durable, Spacious Single-Piece Desktop



Smooth, Single-Piece  
Desktop



Uneven Two-Piece  
Desktop

Figure 8.1: Key dimensions and weight capacity of the DEVAISE Electric Standing Desk.

Feature	Specification
Brand	DEVAISE
Product Dimensions	23.62"D x 47.24"W x 28.34"H
Color	White
Style	Classic
Base Material	Iron
Top Material Type	Engineered Wood
Finish Type	Unfinished
Special Features	3 Adjustable Height, Cable Hole, Electric, Ergonomic, Whole Piece Desktop

Feature	Specification
Room Type	Bedroom, Home, Office, Study Room, Writing
Recommended Uses	Working, Writing
Max Weight Capacity	180 lbs

## 9. WARRANTY AND SUPPORT

The DEVAISE Electric Standing Desk comes with a **1-year frame warranty**, ensuring peace of mind regarding the structural integrity of your product.

For any questions, concerns, or technical assistance, our **24/7 US-based customer service** team is available to help. Please have your model number and purchase information ready when contacting support.

You can reach DEVAISE customer service through the contact information provided on the official DEVAISE website or through your purchase platform.