

Manuals.plus /

› LBAXSXP /

› Instruction Manual for Compatible With Nissan Wingroad AD Wagon Y11 Car Headlight 1999-2005 Headlamp A Pair

LBAXSXP YongGangMaoYi SHOP

Instruction Manual for Nissan Wingroad AD Wagon Y11 Headlight Assembly

Brand: LBAXSXP

INTRODUCTION

This manual provides essential information for the installation, operation, maintenance, and troubleshooting of your new LBAXSXP Headlight Assembly, compatible with Nissan AD and Wingroad Y11 models from 1999-2005. This product is designed to be a direct replacement for OEM parts 26025WE411 and 26010WD026, ensuring a precise fit and reliable performance.



Image: A pair of LBAXSXP headlight assemblies, showcasing the clear lens and internal reflector design. These are the primary components for vehicle illumination.

SETUP AND INSTALLATION

The LBAXSXP Headlight Assembly is designed for easy replacement. Professional installation is recommended, but experienced individuals may perform the installation by following these general guidelines. Always ensure the vehicle's battery is disconnected before beginning any electrical work.

1. **Preparation:** Park the vehicle on a level surface and engage the parking brake. Open the hood.

2. **Access:** Depending on your vehicle model, you may need to remove the front bumper or grille to access the headlight mounting bolts. Refer to your vehicle's service manual for specific instructions.
3. **Disconnect Wiring:** Carefully disconnect the electrical connectors from the existing headlight assembly.
4. **Remove Old Headlight:** Unscrew all mounting bolts securing the old headlight assembly. Gently pull the assembly out of its housing.
5. **Install New Headlight:** Position the new LBAXSXP headlight assembly into the vehicle's housing. Ensure all mounting points align correctly.
6. **Secure and Connect:** Re-install all mounting bolts and tighten them securely. Reconnect the electrical connectors to the new headlight assembly.
7. **Test Functionality:** Reconnect the vehicle's battery. Turn on the headlights (low beam, high beam, turn signals, parking lights) to ensure all functions are working correctly.
8. **Alignment:** After installation, it is crucial to check and adjust the headlight beam alignment to ensure proper road illumination and to avoid blinding oncoming traffic. This may require professional assistance or specific tools.



Image: Rear view of a single headlight assembly, highlighting the bulb sockets and adjustment screws. This view is critical for understanding the electrical connections and mounting points during installation.



Image: Side profile of a single headlight assembly, illustrating its depth and the design of the housing. This perspective helps in understanding how the unit fits within the vehicle's fender.

OPERATING INSTRUCTIONS

The LBAXXP Headlight Assembly functions as a direct replacement for your vehicle's original headlights. Its operation is controlled by your vehicle's existing headlight switch and electrical system.

- **Low Beam:** Provides standard illumination for general driving conditions.
- **High Beam:** Offers increased illumination for driving in dark areas where no oncoming traffic is present.
- **Turn Signals:** Integrated into the assembly, these provide directional signaling.

- **Parking Lights:** Provide low-level illumination for visibility when parked.

Ensure your vehicle's electrical system is in good working order for optimal performance of the headlight assembly.

MAINTENANCE

Proper maintenance will extend the lifespan and maintain the clarity of your headlight assemblies.

- **Cleaning:** Regularly clean the outer lens with a soft cloth and mild automotive soap and water. Avoid abrasive cleaners or harsh chemicals that can damage the lens.
- **Inspection:** Periodically inspect the headlight assembly for any signs of cracks, moisture intrusion, or damage. Check the electrical connections for corrosion or looseness.
- **Bulb Replacement:** If a bulb fails, replace it promptly with a bulb of the correct type and wattage as specified by your vehicle manufacturer. Refer to your vehicle's manual for bulb replacement procedures.
- **Lens Restoration:** Over time, headlight lenses can become hazy due to UV exposure. Use a reputable headlight restoration kit if haziness occurs to restore clarity.

TROUBLESHOOTING

If you encounter issues with your headlight assembly, consider the following common problems and solutions:

Problem	Possible Cause	Solution
Headlight not illuminating	<ul style="list-style-type: none"> • Blown bulb • Faulty fuse • Loose or corroded electrical connection • Faulty headlight switch 	<ul style="list-style-type: none"> • Replace bulb • Check and replace fuse in vehicle's fuse box • Inspect and clean connections; ensure they are secure • Test headlight switch; replace if necessary
Dim or flickering light	<ul style="list-style-type: none"> • Weak electrical connection • Aging bulb • Voltage issue 	<ul style="list-style-type: none"> • Check and secure all electrical connections • Replace bulb • Have vehicle's electrical system checked by a professional
Moisture inside headlight	<ul style="list-style-type: none"> • Compromised seal • Condensation (minor and temporary) 	<ul style="list-style-type: none"> • Inspect for cracks or damage; seal if possible or replace assembly • If minor, it may dissipate. If persistent, indicates a seal issue.

If problems persist after attempting these solutions, consult a qualified automotive technician.

SPECIFICATIONS

Brand: LBAXSXP

Model: YongGangMaoYi SHOP (Manufacturer's internal model number)

Compatible Vehicles: Nissan AD (VENY11, VEY11, VFY11, VGY11, VHNY11, VY11, WFY11, WHNY11, WHY11, WPY11, WRY11), Nissan Wingroad (VENY11, VEY11, VFY11, VGY11, VHNY11, VY11, WFN11, WFY11, WHNY11, WHY11, WPY11, WRY11)

OEM Part Numbers: 26025WE411, 26010WD026

Material Type: ABS

Manufacturer Part Number: 16-33-320

Compatible With Lamp: Headlights

Origin: Mainland China

Item Weight: Approximately 1.76 ounces (per unit, as per product data)

Package Dimensions: Approximately 1.18 x 0.79 x 0.39 inches (as per product data, likely for a single component, not the full assembly)



Image: An angled view of both headlight assemblies, emphasizing their design and the clarity of the lens. This view helps in visualizing the product's appearance when installed.

WARRANTY INFORMATION

Specific warranty details for this product are not provided in the available documentation. Please refer to the seller's return policy or contact the seller directly for information regarding warranty coverage and terms.

SUPPORT

For technical assistance, installation queries, or any other support needs, please contact the seller directly through the platform where the product was purchased. The seller's contact information is typically available on your order details page or the product listing.

Manufacturer: YongGangMaoYi SHOP