

[Manuals.plus](#) /

› [PHILIPS](#) /

› Philips Norelco S9000 Prestige Electric Shaver User Manual

PHILIPS SP9883/83

Philips Norelco S9000 Prestige Electric Shaver User Manual

Model: SP9883/83

INTRODUCTION

This manual provides essential information for the safe and effective use of your Philips Norelco S9000 Prestige Electric Shaver. Please read all instructions carefully before first use and retain this manual for future reference.

The Philips Norelco S9000 Prestige is a premium electric shaver designed for both wet and dry use, featuring advanced SenseIQ technology, a Qi wireless charging pad, and a Quick Clean Pod for comprehensive maintenance. Its ergonomic design ensures a comfortable and secure grip, while the Dual Steel Precision blades and Hydro SkinGlide coating deliver a close and smooth shave.

SAFETY INFORMATION

It is crucial to adhere to the following safety guidelines to prevent injury or damage to the device:

- Always clean and dry the shaver after use to prevent bacterial growth.
- Exercise caution while shaving to avoid cuts and skin irritation.
- Do not use the shaver near water or while charging to prevent electrical hazards.
- Keep the appliance and its cord out of reach of children.
- Only use the charger supplied with the product.
- Do not disassemble, repair, or modify the appliance yourself.

PACKAGE CONTENTS

Upon unpacking, ensure all components are present:

- Philips Norelco S9000 Prestige Electric Shaver
- Qi Wireless Charging Pad
- Quick Clean Pod
- Beard Styler Attachment
- Premium Travel Case
- Cleaning Brush

- Power Cord
- User Manual (this document)



Image: The Philips Norelco S9000 Prestige Electric Shaver shown with its complete set of accessories, including the Qi wireless charging pad, Quick Clean Pod, beard styler attachment, and premium travel case.

SETUP

Charging the Shaver

Before first use, fully charge the shaver. The shaver can be charged wirelessly using the included Qi charging pad.

1. Connect the power cord to the Qi wireless charging pad and plug it into a wall outlet.
2. Place the shaver horizontally onto the Qi charging pad. Ensure the shaver's display faces upwards and is centered on the pad for optimal charging.
3. The battery indicator on the shaver's display will show the charging progress. A full charge takes approximately 3 hours and provides 60 minutes of cordless shaving. A quick 18-minute charge is sufficient for a single shave.



Image: The Philips Norelco S9000 Prestige Electric Shaver resting on its Qi wireless charging pad, indicating the charging process.

Attaching the Beard Styler

To use the beard styler attachment:

1. Ensure the shaver is turned off.
2. Remove the shaving head by pulling it upwards.
3. Align the beard styler attachment with the shaver body and push it down until it clicks into place.
4. Adjust the desired length setting using the integrated dial on the styler. The beard styler offers 5 length settings.

OPERATING INSTRUCTIONS

Basic Shaving

The S9000 Prestige can be used for both dry and wet shaving.

1. Press the power button to turn on the shaver. The intuitive digital display will show the battery level.
2. For dry shaving, ensure your skin is clean and dry. For wet shaving, you can use shaving foam or gel.
3. Move the shaver in small, circular motions over your skin. The SenseIQ technology and Ultraflex Suspension system will adapt to your facial contours and hair density for an efficient shave.
4. Apply gentle pressure. The Hydro SkinGlide coating ensures smooth gliding and reduces irritation.
5. After shaving, press the power button to turn off the shaver.



Image: A man using the Philips Norelco S9000 Prestige Electric Shaver to shave his face, demonstrating its ergonomic design and ease of use.

Using the Beard Styler

With the beard styler attachment, you can trim and style your beard.

1. Ensure the beard styler attachment is securely in place.
2. Select your desired hair length using the length settings on the styler.
3. Move the styler against the direction of hair growth for an even trim.
4. The rounded tips and combs are designed to prevent skin irritation.

MAINTENANCE

Cleaning the Shaver

Regular cleaning ensures optimal performance and hygiene.

Quick Clean (After Each Use)

1. Turn off the shaver.
2. Press the one-touch open button to release the shaving head.
3. Rinse the shaving head and the hair chamber under warm running water.
4. Shake off excess water and close the shaving head.

Deep Clean with Quick Clean Pod (Weekly)

The Quick Clean Pod provides a powerful 1-minute cleaning system that thoroughly cleans, lubricates, and maintains shaver performance while ensuring superior hygiene.

1. Ensure the Quick Clean Pod contains cleaning fluid.
2. Place the shaver upside down into the Quick Clean Pod.
3. The cleaning cycle will start automatically.
4. After the cycle, remove the shaver and let it air dry.

Replacing Shaving Heads

For best performance, replace the shaving heads approximately every 12 months. Replacement heads are available from authorized Philips Norelco retailers.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is depleted.	Charge the shaver fully using the Qi charging pad.
Poor shaving performance.	Shaving heads are dirty or worn.	Clean the shaving heads thoroughly or replace them if they are old.
Skin irritation after shaving.	Incorrect shaving technique or sensitive skin.	Ensure gentle pressure and circular motions. Consider wet shaving with foam/gel. Allow skin to adapt.
Shaver not charging.	Shaver not correctly placed on charging pad, or charging pad not powered.	Ensure shaver is centered on the Qi pad. Check power connection to the charging pad.

If the problem persists, please contact Philips Norelco customer support.

SPECIFICATIONS

- Model Name:** S9000 Prestige
- Model Number:** SP9883/83
- Power Source:** Battery Powered
- Battery Performance:** 60 minutes cordless shaving on full charge
- Charging Time:** 3 hours for full charge, 18 minutes for quick charge (single shave)
- Usage:** Wet and Dry
- Shaving System:** Dual Steel Precision blades, Hydro SkinGlide coating, Ultraflex Suspension, SenseIQ technology, Smart Hair Sensor
- Motor:** Top-spin digital motor
- Display:** Intuitive battery level indicator
- Cleaning System:** One-touch open, Fully washable, Cable-free Quick Clean Pod
- Item Weight:** 2.03 Pounds
- Manufacturer:** Philips

WARRANTY AND SUPPORT

Philips Norelco products are manufactured to the highest quality standards. This product comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions.

For technical support, replacement parts, or warranty claims, please visit the official Philips Norelco website or contact their customer service. Keep your proof of purchase for warranty validation.

Online Support: www.philips.com/support

Customer Service: Refer to your regional Philips Norelco contact information.

DISPOSAL

Do not dispose of the product with normal household waste at the end of its life. Instead, hand it over to an official collection point for recycling. By doing this, you help preserve the environment.