

MOUMON B0DQ4M16J3

MOUMON 4 Door Wardrobe with Shelves and Hanging Rod

Model: B0DQ4M16J3

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your MOUMON 4 Door Wardrobe. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

Safety Information

- Always assemble the wardrobe on a soft, clean surface to prevent scratches.
- Ensure all hardware is securely tightened before use. Periodically check and retighten as necessary.
- This wardrobe is designed for indoor use only.
- Due to the size and weight, **two people are required for safe assembly and movement**
- Utilize the provided anti-tip device to secure the wardrobe to a wall, preventing accidental tipping.

2. PACKAGE CONTENTS AND PRE-ASSEMBLY CHECK

Your MOUMON 4 Door Wardrobe will arrive in two separate packages due to its size and weight. The arrival times for these packages may vary. Please ensure you have received both packages before proceeding with assembly.

Before Assembly

- Unpack all components and lay them out on a clean, soft surface (e.g., a carpet or blanket) to prevent damage.
- Refer to the hardware/screws/boards list in the included instruction booklet to verify all parts are present and undamaged.
- If any parts are missing or damaged, do not proceed with assembly. Contact MOUMON customer support for assistance.

- Familiarize yourself with the assembly instructions provided in the separate booklet. Each part is labeled to assist with identification.




Figure 2.1: External dimensions and internal compartment layout of the wardrobe. This diagram illustrates the overall width (63 inches), depth (19.7 inches), and height (69.7 inches), along with the internal configuration of hanging rods and shelves.

3. ASSEMBLY INSTRUCTIONS

Follow the step-by-step instructions provided in the separate assembly booklet carefully. Assemble the item gently to avoid damage. Power tools are generally not recommended as they can overtighten screws and damage the MDF board.

Key Assembly Considerations:

- **Two-Person Assembly:** This product requires two individuals for safe and efficient assembly.
- **Part Identification:** All panels and hardware are labeled. Match labels to the diagrams in the instruction booklet.
- **Hinge Adjustment:** The wardrobe is equipped with adjustable hinges to ensure proper door alignment after assembly. Adjust as needed for smooth operation.
- **Anti-Tip Device:** Install the anti-tip device as instructed to secure the wardrobe to a wall. This is a critical

safety measure.



Figure 3.1: The MOUMON 4 Door Wardrobe fully assembled, showcasing its grey finish and wooden handles.

4. OPERATING AND FEATURES

The MOUMON 4 Door Wardrobe is designed for practical storage in bedrooms or guest rooms. It features a dual-compartment design to organize various clothing items and accessories.

Storage Configuration:

- The wardrobe functions as two distinct two-door cabinets.
- **Left Cabinet:** Equipped with a hanging rod, suitable for longer garments such as suits, dresses, and shirts.
- **Right Cabinet:** Features multiple shelves of varying sizes, providing space for folded clothing, bedding, and other accessories.



Figure 4.1: Interior view of the wardrobe, illustrating the dedicated hanging space and the adjustable shelving system.



Figure 4.2: A detailed view of the internal storage, demonstrating how clothing and accessories can be organized within the shelves and hanging area.

5. MAINTENANCE

Proper care and maintenance will extend the lifespan and preserve the appearance of your MOUMON wardrobe.

Cleaning Instructions:

- Wipe surfaces with a soft, damp cloth.
- For stubborn marks, use a mild, non-abrasive cleaner specifically designed for wood or laminate surfaces.
- Immediately dry all surfaces with a clean, dry cloth after cleaning to prevent moisture damage.
- Avoid using harsh chemicals, abrasive cleaners, or furniture polish containing silicone, as these can damage the veneer finish.

General Care:

- Periodically check all screws and fasteners to ensure they remain tight. Retighten as needed.

- Avoid placing hot items directly on the surface. Use coasters or protective pads.
- Keep the wardrobe away from direct sunlight and extreme temperature changes to prevent warping or fading.

6. TROUBLESHOOTING

This section addresses common issues you might encounter with your wardrobe.

Common Issues and Solutions:

Problem	Possible Cause	Solution
Doors are not aligned or close properly.	Hinges are not adjusted correctly.	Adjust the screws on the hinges to align the doors. Refer to the assembly manual for specific hinge adjustment instructions.
Wardrobe feels unstable or wobbly.	Fasteners are loose; anti-tip device not installed.	Ensure all assembly screws are tightened. Install the anti-tip device securely to a wall as per instructions. Ensure the wardrobe is on a level surface.
Parts are missing or damaged upon arrival.	Shipping damage or packaging error.	Do not proceed with assembly. Contact MOUMON customer support immediately with details of the missing or damaged parts.

7. SPECIFICATIONS

Feature	Detail
Brand	MOUMON
Model Number	B0DQ4M16J3
Color	Grey
Product Dimensions (D x W x H)	18.9"D x 63"W x 70.9"H
Material	MDF Board
Special Feature	Storage, Hanging Rod, Shelves
Mounting Type	Wall Mount (Anti-tip device included)
Room Type	Bedroom, Guest Room
Door Style	Flat Panel
Assembly Required	Yes (2-person assembly recommended)
Country of Origin	China

8. WARRANTY AND SUPPORT

For specific warranty information regarding your MOUMON 4 Door Wardrobe, please refer to the documentation

included with your purchase or contact MOUMON customer service directly. Warranty terms may vary.

Customer Support:

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact the seller or MOUMON customer support. Provide your model number (B0DQ4M16J3) and purchase date for faster service.

© 2025 MOUMON. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question