

HYSEYY YS-K 1302, YS-K 1315

HYSEYY Heavy Duty Multifunctional Clothing Rack Instruction Manual

Models: YS-K 1302, YS-K 1315

Brand: HYSEYY

1. INTRODUCTION

This manual provides essential instructions for the assembly, operation, and maintenance of your HYSEYY Heavy Duty Multifunctional Clothing Rack. Please read this manual thoroughly before assembly and use to ensure safe and efficient operation.

2. SAFETY INFORMATION

- Ensure all parts are securely fastened before use.
- Do not exceed the maximum load capacity of the rack. Overloading can cause instability and damage.
- Keep children and pets away from the rack during assembly.
- Place the rack on a flat, stable surface to prevent tipping.
- Regularly check for loose connections and tighten as necessary.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Main Frame Components (Vertical Rods, Horizontal Rods)
- Bottom Shelf Components
- Side Extension Rods
- Lockable Wheels (4 units)
- Assembly Hardware (Screws, Wrenches, etc.)
- Instruction Manual



Figure 1: Fully assembled HYSEYY Heavy Duty Multifunctional Clothing Rack, showcasing its double hanging rods, bottom shelf, and side extension rods. The rack is black with clothes and accessories displayed.

4. SETUP AND ASSEMBLY

Follow these steps to assemble your clothing rack. It is recommended to have two people for easier assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface.

2. **Attach Wheels:** Secure the four lockable wheels to the base of the vertical support rods. Ensure they are tightly fastened.
3. **Assemble Base Frame:** Connect the bottom horizontal rods to the vertical support rods to form the base of the rack.
4. **Install Bottom Shelf:** Place the bottom shelf onto the designated supports on the base frame.
5. **Attach Upper Vertical Rods:** Extend the upper vertical rods and secure them into the lower vertical rods. Adjust height as desired.
6. **Install Hanging Rods:** Attach the two main horizontal hanging rods to the upper vertical rods. Ensure they are level and secure.
7. **Add Side Extension Rods:** Insert the side extension rods into the designated slots on the main horizontal rods.
8. **Final Check:** Verify that all connections are tight and the rack is stable before placing any items on it.

5. OPERATING INSTRUCTIONS

5.1 Hanging Clothes

Utilize the two main horizontal rods for hanging garments such as dresses, coats, shirts, and pants. The double-rod design maximizes hanging space.

210LBS Load Capacity

Premium metal provides more loading capacity

2

Rods

80+

Clothing



Figure 2: The clothing rack demonstrating its capacity with two hanging rods, capable of holding over 80 clothing items. The image highlights the premium metal construction for enhanced loading capacity.

5.2 Using Side Extension Rods


The side extension rods provide additional storage for accessories. These are ideal for hanging bags, hats, belts, scarves, or umbrellas.

5.3 Bottom Shelf Storage

The sturdy bottom shelf is designed for storing shoes, storage boxes, suitcases, or other luggage items, helping to keep your space organized.

Multifunctional Clothing Rack

Great organizer for your room



Double Rods



Bottom Shelf



Side Rods

Figure 3: A visual representation of the rack's multifunctional design, detailing the double hanging rods for garments, the bottom shelf for shoes and boxes, and the side rods for accessories like scarves.

5.4 Utilizing Lockable Wheels

The rack is equipped with four wheels, two of which are lockable. To move the rack, ensure the locks are disengaged. To secure the rack in place, press down on the locking mechanism on the two lockable wheels with your foot until they click into position. This prevents unintended movement.



Figure 4: A detailed view of the lockable wheels, highlighting their 360-degree rotation capability and silent design for smooth movement. The lock icon indicates the locking mechanism.

6. MAINTENANCE

- **Cleaning:** Wipe the metal surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Tighten any loose fasteners to maintain stability.
- **Wheel Care:** Keep the wheels free of debris to ensure smooth rolling.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Rack is unstable or wobbly.	Loose connections; uneven surface; overloaded.	Ensure all screws are tightened. Move to a flat, level surface. Reduce load to within specifications.
Wheels do not roll smoothly.	Debris in wheels; wheels locked.	Clean wheels of any obstructions. Ensure wheel locks are disengaged.
Difficulty assembling parts.	Incorrect orientation; missing hardware.	Refer to assembly instructions carefully. Contact customer support if parts are missing.

8. SPECIFICATIONS

Brand: HYSEYY

Material: Metal

Color: Yellow

Model YS-K 1302 Dimensions: 40"D x 22"W x 4"H

Model YS-K 1315 Dimensions: 16.5"D x 44.3"W x 63"H

Load Capacity: Up to 210 lbs

Number of Shelves: 1

9. WARRANTY AND CUSTOMER SUPPORT

HYSEYY is committed to providing quality products and customer satisfaction. For any inquiries, technical support, or issues before or after your purchase, please contact our dedicated after-sales team.

Please reach out via the Amazon Message Center for assistance. Your satisfaction is our goal.

© 2024 HYSEYY. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question