

[Manuals.plus](#) /

› [Sakugi](#) /

› Sakugi Expandable Stainless Steel Dish Drying Rack - User Manual

Sakugi UK004

Sakugi Expandable Stainless Steel Dish Drying Rack - User Manual

Model: UK004

1. PRODUCT OVERVIEW

The Sakugi Expandable Stainless Steel Dish Drying Rack is designed to optimize kitchen space and streamline your dish-drying process. This versatile rack can be used inside the sink for efficient water drainage or extended to rest over the sink, freeing up valuable countertop space. It features a durable stainless steel construction with a food-safe coating, ensuring resistance to rust and scratches for long-lasting use.

Key features include a removable cutlery holder, three dedicated cup holders, and a spacious area for plates and bowls. Its expandable design allows it to fit a wide range of sink sizes, making it an ideal solution for various kitchen layouts, including small kitchens, apartments, RVs, and dorms.



Figure 1: Sakugi Dish Drying Rack in a kitchen sink, showcasing its capacity for various dishware.

2. SAFETY INFORMATION

- Ensure the rack is securely placed and stable before loading with dishes to prevent tipping or falling.
- Do not overload the rack beyond its intended capacity. Distribute weight evenly.
- Keep sharp utensils in the designated cutlery holder with points facing downwards to avoid injury.
- Avoid using abrasive cleaners or harsh chemicals, as they may damage the stainless steel finish and coating.
- Keep out of reach of small children to prevent accidents.

3. PACKAGE CONTENTS

Your Sakugi Dish Drying Rack package should include the following components:

- 1 x Expandable Stainless Steel Dish Drying Rack
- 1 x Removable Cutlery Holder
- 3 x Integrated Cup Holders (part of the main rack structure)

4. SETUP


Follow these steps to set up your Sakugi Dish Drying Rack:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Adjust Length:** The rack features adjustable supporting bars. Gently pull out the bars on both sides to extend the length from 15.4 inches to up to 24 inches. Adjust it to fit your sink's width.
3. **Placement:**
 - **Inside the Sink:** Place the rack directly inside your sink for efficient water drainage. Ensure the non-slip rubber covers on the bars provide a secure fit.
 - **Over the Sink:** Extend the supporting bars to rest the rack over the edges of your sink. The non-slip rubber covers will help prevent movement.
4. **Attach Cutlery Holder:** Hook the removable cutlery holder onto the side of the main rack where desired.
5. **Check Sink Compatibility:** Before purchase and setup, ensure your sink dimensions are compatible. The rack measures 15.4"L x 9.8"W x 3"H when compact, and expands to 24" in length. The depth of your sink must be above 3.5 inches for optimal use inside the sink.

Fits Most Household Sinks



check the applicable sink
range before purchase



NOTE: The depth of the sink must
be above 3.5 inch.

Figure 2: Illustration of sink compatibility and adjustable length.

Dimensions

extendable to fit the sink




Figure 3: Detailed product dimensions.

5. OPERATING INSTRUCTIONS

Using your Sakugi Dish Drying Rack is straightforward:

- **Dish Drying:** Place washed plates, bowls, and other dishware on the main rack for air drying. The open design allows for optimal airflow.

- **Cutlery:** Use the removable cutlery holder for forks, spoons, knives, and other small utensils.
- **Cups/Glasses:** Hang cups and glasses on the integrated cup holders for efficient drying and to prevent water spots.
- **Colander Function:** The rack can also function as a colander for rinsing fruits and vegetables directly over the sink.

6. MAINTENANCE

To ensure the longevity and pristine appearance of your Sakugi Dish Drying Rack, follow these maintenance guidelines:

- **Regular Cleaning:** Clean the rack regularly with mild dish soap and warm water. Use a soft cloth or sponge.
- **Rinse Thoroughly:** After cleaning, rinse the rack thoroughly to remove all soap residue.
- **Dry Immediately:** To prevent water spots and maintain the stainless steel finish, dry the rack immediately after washing with a clean, dry cloth.
- **Avoid Harsh Cleaners:** Do not use abrasive pads, steel wool, or harsh chemical cleaners, as these can scratch the surface or damage the protective coating.
- **Inspect Periodically:** Periodically check the non-slip rubber covers for wear and tear to ensure continued stability.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Rack slips or moves on sink edge.	Improper adjustment; wet or dirty non-slip covers; sink surface is slippery.	Ensure the expandable bars are fully extended and securely resting on the sink edges. Clean and dry the non-slip rubber covers and the sink surface before placement.
Rack does not fit my sink.	Sink dimensions are outside the rack's adjustable range.	Verify your sink's internal and external dimensions against the product specifications (15.4" to 24" length, 9.8" width). Ensure sink depth is adequate if placing inside.
Water spots or residue on the rack.	Improper drying after cleaning; hard water.	Always dry the rack immediately after washing. For hard water spots, use a solution of white vinegar and water, then rinse and dry.

8. SPECIFICATIONS

Model Number: UK004

Brand: Sakugi

Material: Stainless Steel

Color: Silver

Product Dimensions (Compact): 9.8"D x 15.4"W x 3"H

Expandable Length: 15.4" to 24"

Item Weight: 1.98 pounds

Special Feature: Expandable, Rust-Resistant, Scratch-Resistant Coating

Recommended Use: Dishware Drying, Fruit/Vegetable Rinsing

9. WARRANTY AND SUPPORT

For warranty information and customer support regarding your Sakugi Dish Drying Rack, please refer to the documentation included with your purchase or visit the official Sakugi website. You may also contact Sakugi customer service directly for assistance with product inquiries, troubleshooting, or replacement parts.

Manufacturer: Sakugi

For further assistance, please visit the [Sakugi Store on Amazon](#).

© 2025 Sakugi. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DQ4W86C3>

More documents and user manuals: <https://manuals.plus/>