

[Manuals.plus](#) /

› [Aechonow](#) /

› Aechonow Floor to Ceiling Cat Tree Instruction Manual (Model: floor to ceiling cat tree)

Aechonow floor to ceiling cat tree

Aechonow Floor to Ceiling Cat Tree Instruction Manual

Model: floor to ceiling cat tree

1. INTRODUCTION

Thank you for choosing the Aechonow Floor to Ceiling Cat Tree. This manual provides detailed instructions for the safe assembly, operation, and maintenance of your new cat tree. Designed for large cats, this adjustable height cat tower offers multiple levels for climbing, scratching, resting, and playing, enhancing your cat's environment.





Image 1: The Aecheonow Floor to Ceiling Cat Tree, showcasing its various platforms, hammock, and condo, occupied by several cats.

2. SAFETY INFORMATION

Please read and follow all safety instructions carefully to prevent injury to your pets or damage to the product.

- **Adult Assembly Required:** This product must be assembled by an adult.
- **Check Tightness:** Periodically check the tightness of all bolts and connections, especially the ceiling tension bolts, and reinforce them as needed. This ensures stability and safety for your cat.
- **Placement:** Place the cat tree on a flat, stable surface. Ensure adequate clearance from walls and furniture for safe climbing.
- **Weight Limit:** While designed for large cats, ensure the combined weight of multiple cats does not exceed the structural integrity of individual platforms.
- **Inspect for Damage:** Regularly inspect the cat tree for any signs of wear or damage. Discontinue use if any part is broken or compromised.

- **Children and Pets:** Keep small children away from the cat tree during assembly. Supervise children when they are near the cat tree to prevent accidents.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Main support pole sections (various lengths)
- Base plate
- Ceiling tension plate with 3 bolts
- Multiple climbing platforms/perches
- Cat condo/cave bed with plush mat
- Hammock with soft cushion
- Scratching post sections (sisal rope wrapped)
- Hardware kit (screws, bolts, Allen wrench)
- Instruction Manual (this document)



Image 2: Exploded view of the cat tree components, illustrating each part included in the package.

4. ASSEMBLY INSTRUCTIONS

Follow these steps carefully for proper assembly. It is recommended to have two adults for installation, especially when adjusting the height and securing to the ceiling.

1. **Prepare the Base:** Attach the lowest support pole section to the base plate using the provided hardware. Ensure it is securely fastened.
2. **Assemble Main Pole:** Connect the various support pole sections, including the sisal-wrapped scratching posts, in the desired order. The order of sections will determine the placement of platforms.
3. **Attach Platforms and Accessories:** Securely attach the cat condo, hammock, and various climbing platforms to the main pole at your preferred heights and orientations. Ensure all screws are tightened.
4. **Install Ceiling Tension Mechanism:** Attach the top ceiling tension plate to the uppermost pole section. This plate contains three adjustable bolts for securing the tree against the ceiling.
5. **Position the Cat Tree:** Carefully stand the assembled cat tree upright in its desired location. Ensure the base is stable on the floor.
6. **Adjust Height and Secure to Ceiling:** Extend the top pole section until the ceiling tension plate makes contact with the ceiling. Rotate the three tension bolts clockwise to apply pressure against the ceiling. Tighten them evenly until the cat tree is firmly secured and does not wobble. The felt cover on the ceiling plate protects your ceiling surface.

Stable Feature



3 Bolts

300%
support

VS

Others

Image 3: Detail of the stable ceiling tension feature, showing the three bolts that provide secure support against the ceiling.



Image 4: Step-by-step assembly guide illustrating the connection of pole segments and attachment of platforms.

5. OPERATING INSTRUCTIONS

The Aecheonow Floor to Ceiling Cat Tree is designed to provide a stimulating and comfortable environment for your cats. No specific 'operation' is required beyond ensuring its stable setup.

- **Encourage Use:** Introduce your cat to the tree by placing treats or toys on different levels.
- **Scratching:** The sisal-wrapped posts are intended for scratching. Encourage your cat to use them to maintain claw health and protect your furniture.
- **Resting:** The condo, hammock, and perches offer various comfortable spots for your cat to rest, observe, and sleep.
- **Climbing and Jumping:** The multi-level design allows for natural climbing and jumping behavior, providing exercise and mental stimulation.



Multilevel Tower Fun



Image 5: An overview of the cat tree highlighting its various features such as the spacious perch, plush hammock, enlarged springboard, and big cat condo.

6. MAINTENANCE

Regular maintenance will extend the life of your cat tree and ensure your cat's safety.

- **Cleaning:**

- Wipe wooden surfaces with a damp cloth. Avoid harsh chemicals.
- The plush mat in the condo and the hammock cushion can be removed for spot cleaning or gentle hand washing. Allow to air dry completely before reattaching.
- Vacuum sisal scratching posts to remove loose fibers and cat hair.
- **Stability Check:** At least once a month, check all connections, especially the ceiling tension bolts, to ensure they remain tight. Re-tighten if necessary.
- **Inspect for Wear:** Check sisal ropes for excessive fraying and platforms for any signs of cracking or instability. Replace worn parts if available, or consider replacing the unit if structural integrity is compromised.

7. TROUBLESHOOTING

Issue: Cat tree feels wobbly or unstable.

Solution: Ensure the base is on a flat, even surface. Re-tighten all three ceiling tension bolts evenly until the tree is firmly secured. Check all platform connections for tightness.

Issue: Cat is not using the tree.

Solution: Place treats, catnip, or favorite toys on different levels to encourage exploration. Spend time playing with your cat around the tree. Ensure the tree is in a location your cat feels safe and has a good view.

Issue: Parts are damaged during delivery or missing.

Solution: Contact Aecheonow customer support immediately with your purchase details for assistance.

8. SPECIFICATIONS

Model Name	floor to ceiling cat tree
Brand Name	Aecheonow
Adjustable Height	82.6 inches to 122 inches (210 cm to 310 cm)
Product Dimensions (LxWxH)	15.7 x 15.7 x 122 inches (maximum height)
Item Weight	43.7 pounds
Material	Wood (Multi-layer plywood), Sisal Rope, Plush Fabric
Condo Cave Diameter	13.7 inches
Top Perch Width	18.9 inches
Recommended Uses	Indoor climbing, jumping, scratching, resting for cats

Adjustable From 82.6in to 122in




Image 6: Visual representation of the cat tree's adjustable height, showing minimum (82.6") and maximum (122") settings.

Spacious Cat Tower

Adjustable Height
82"-122"



Image 7: A diagram providing specific measurements for various parts of the cat tree, such as perch widths and overall adjustable height.

9. WARRANTY AND SUPPORT

This Aecheonow product comes with a **2-Year Warranty** from the date of purchase. This warranty covers manufacturing defects and material flaws under normal use.

For warranty claims, technical support, or any questions regarding your Aecheonow Floor to Ceiling Cat Tree, please contact our customer service team:

- **Manufacturer:** Aecheonow
- **Contact Information:** Please refer to your purchase receipt or the Aecheonow official website for the most current customer support contact details.

When contacting support, please have your product model name (floor to ceiling cat tree) and purchase date available.