



[Manuals.plus](#) /

› [SOOWERY](#) /

› SOOWERY 8-Drawer Dresser with LED Lights and Charging Station User Manual

## SOOWERY Drawers Dresser 8W888

# SOOWERY 8-Drawer Dresser with LED Lights and Charging Station User Manual

Model: Drawers Dresser 8W888

## INTRODUCTION

---

Thank you for choosing the SOOWERY 8-Drawer Dresser. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. This dresser is designed to offer ample storage with eight fabric drawers, integrated LED lighting, and a convenient charging station. It can also serve as a TV stand for screens up to 60 inches.

Please read these instructions carefully before beginning assembly and retain this manual for future reference.

## SAFETY INFORMATION

---

- **Anti-Tip Device:** Always install the included anti-tip device to prevent the dresser from tipping over, especially in households with children. Failure to do so can result in serious injury.
- **Weight Limits:** Do not exceed the maximum weight capacity for the top surface (200 lbs) or individual drawers (10 lbs each). Overloading can compromise stability and cause damage.
- **Electrical Safety:** Ensure the charging station and LED lights are connected to a properly grounded power outlet. Do not use if cords are damaged. Keep liquids away from electrical components.
- **Assembly:** Assemble the dresser on a soft, clean surface to prevent scratches. Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as needed.
- **Placement:** Place the dresser on a level surface to ensure stability. Use the adjustable feet to compensate for uneven floors.

## PACKAGE CONTENTS


---

Before assembly, verify that all components listed below are present. If any parts are missing or damaged, please contact customer support.

- Dresser Frame Components (Particle board panels, metal frame parts)

- 8 Fabric Drawers
- LED Light Strip with Remote Control
- Built-in Charging Station (2 USB ports, 2 AC outlets)
- Hardware Pack (Screws, bolts, nuts, anti-tip kit)
- Assembly Tools (e.g., Allen wrench, screwdriver)
- Instruction Manual

# 3-Tier Design



**Not Easily deformed**



**Easily deformed**

**Figure 1: Drawer Material Construction.** This diagram illustrates the durable three-layer construction of the fabric drawers, comprising an outer fabric layer, an MDF board core, and a non-woven fabric lining, designed to resist deformation.

## SETUP AND ASSEMBLY

Follow these general steps for assembling your dresser. Refer to the detailed assembly instructions included in your package for specific diagrams and fastener identification.

### Preparation

1. Clear a spacious area for assembly.
2. Lay out all components and hardware, comparing them against the parts list.
3. Keep children and pets away from the assembly area.

## Assembly Steps

1. **Assemble the Metal Frame:** Connect the metal support bars and legs according to the instructions. Ensure all connections are secure.
2. **Attach Particle Board Panels:** Secure the top, side, and back particle board panels to the metal frame using the provided screws.
3. **Install Drawer Supports:** Attach the necessary supports for the fabric drawers within the frame structure.
4. **Insert Fabric Drawers:** Fold and assemble each fabric drawer, then slide them into their designated compartments.
5. **Install LED Light Strip:** Adhere the LED light strip to the designated area, typically under the top cubbies. Connect it to the power source as instructed.
6. **Connect Charging Station:** Ensure the charging station is properly integrated and its power cord is accessible.
7. **Attach Anti-Tip Kit:** Securely fasten the anti-tip device to the dresser and to a wall stud, following the specific instructions provided.
8. **Adjust Leveling Feet:** Adjust the four leveling feet at the bottom of the dresser to ensure it stands stable and level on your floor.



**Figure 2: Dresser Dimensions and Capacities.** This image provides detailed measurements of the dresser and its drawers, along with the maximum weight capacity for the top surface (200 lbs) and each fabric drawer (10 lbs).

## OPERATING INSTRUCTIONS

### Using the Drawers

The dresser features eight long fabric drawers designed for organizing clothes and other items. Each drawer has a handle for easy opening and closing. Ensure items are distributed evenly and do not exceed the 10 lbs weight limit per drawer to maintain smooth operation and prevent damage.

# SURPRISING AMOUNT OF STORAGE SPACE



**Figure 3: Ample Storage Space.** This image illustrates the significant storage capacity of the dresser, with all eight fabric drawers open and filled with various household items, showcasing its organizational potential.

## LED Lights Operation

The integrated RGB LED light strip offers customizable ambient lighting. Connect the LED strip's power cable to a wall outlet. Use the provided remote control to:

- Turn the lights On/Off.
- Change between multiple colors.
- Select different lighting modes (e.g., flash, fade, strobe).
- Adjust brightness levels.



**Figure 4: LED Lights and TV Stand Functionality.** This image shows the dresser with its LED lights illuminated in blue, serving as a media console for a television. The presence of a remote control icon highlights the customizable lighting features.

## Charging Station Usage

The dresser includes a built-in charging station with 2 USB ports and 2 standard AC outlets. To use:

1. Ensure the dresser's main power cord is plugged into a functional wall outlet.
2. Connect your devices to the USB ports or AC outlets as needed.



**Figure 5: Dresser with Charging Station and LED Lights.** This image provides a clear view of the dresser's top section, highlighting the integrated charging station in use with a smartphone, and the ambient green LED lighting in the open cubbies.

## Using as a TV Stand

The sturdy wood top of the dresser can support up to 200 lbs, making it suitable for televisions up to 60 inches. Place your TV centrally on the top surface to ensure stability. The open cubbies can store media devices or soundbars.



**Figure 6: Dresser as a Living Room TV Stand.** This image demonstrates the dresser's versatility, showcasing it as a functional and stylish TV stand in a modern living room setting, complemented by ambient purple LED lighting.

## MAINTENANCE

---

- **Cleaning:** Wipe the dresser surfaces with a dry cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Drawer Care:** If fabric drawers become soiled, spot clean with a mild detergent and allow to air dry completely. Do not machine wash.
- **Hardware Check:** Periodically inspect all screws and fasteners to ensure they remain tight. Re-tighten as necessary to maintain structural integrity.
- **Electrical Components:** Keep the charging station and LED lights free from dust and debris. Do not attempt to repair electrical components yourself.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
LED lights not turning on.	Power cable disconnected; remote control battery dead; LED strip damaged.	Ensure power cable is securely plugged in. Replace remote control battery. Contact support if LED strip is damaged.
Charging station not working.	Dresser power cord unplugged; device cable faulty; charging station damaged.	Verify dresser's main power cord is plugged into a live outlet. Try a different device cable. Contact support if charging station is faulty.
Drawers are difficult to open/close.	Overloaded drawer; items obstructing movement; drawer not assembled correctly.	Reduce weight in the drawer. Check for obstructions. Re-check drawer assembly.
Dresser is wobbly.	Uneven floor; loose fasteners; anti-tip device not installed.	Adjust leveling feet. Tighten all assembly fasteners. Install the anti-tip device securely.

## SPECIFICATIONS

Feature	Detail
Brand	SOOWERY
Model Name	Drawers Dresser 8W888
Product Dimensions	11.8"D x 47.2"W x 35.4"H
Color	White
Room Type	Bedroom, Guest Room, Home Office, Kids Room, Living Room
Furniture Finish	PU Finish, Particle board
Drawer Type	Fabric, Under Mounted Slide
Product Care Instructions	Wipe with Dry Cloth
Assembly Required	Yes
Item Weight	47.5 Pounds
Max Top Weight Capacity	200 lbs
Max Drawer Weight Capacity	10 lbs per drawer
Charging Station	2 USB ports, 2 AC outlets
Lighting	RGB LED Strip with Remote Control

## WARRANTY INFORMATION

SOOWERY products are manufactured with quality and care. This product is covered by a manufacturer's warranty against defects in materials and workmanship. Please refer to the warranty card included in your package or contact SOOWERY customer support for specific warranty terms and conditions.

## CUSTOMER SUPPORT

---

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact SOOWERY customer support. Our team is available to help you.

For more information and to explore other SOOWERY products, visit our official store:

**[Visit the SOOWERY Store on Amazon](#)**