Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HONEY JOY HJ-2794-CA

HONEY JOY Corner Kids Kitchen Playset (Model HJ-2794-CA) - Instruction Manual

1. Safety Information

No Warning Applicable. This product is designed for children aged 36 months to 8 years.

For the safety of your child, please observe the following:

- Always ensure adult supervision during play.
- Regularly check all screws and connections to ensure they are tight and secure. Loose parts can pose a hazard.
- Keep small parts, if any, away from children under 3 years old.
- Do not allow children to climb on the playset, as it may tip over.

2. Product Overview

The HONEY JOY Corner Kids Kitchen Playset is a comprehensive wooden play kitchen designed to provide an immersive culinary experience for toddlers and young children. This playset features multiple interactive areas, encouraging imaginative role-play and skill development.



Figure 2.1: Fully assembled HONEY JOY Corner Kids Kitchen Playset.

Key Features:

- **Multi-Area Design:** Features 4 distinct playing areas, allowing multiple children to play simultaneously.
- **Realistic Appliances:** Includes a range hood, microwave, ice maker, stoves with rotary knobs, sink, oven, and washing machine for an authentic play experience.
- **Ample Storage:** Integrated storage spaces help children develop organizational habits.
- **Durable Construction:** Made from carefully selected, BPA-free materials with a widened base for enhanced stability. Certified by ASTM and CPSIA.
- **Included Accessories:** Comes with a chef hat, apron, various utensils, and other kitchenware to enhance play.
- **Corner Design:** Optimizes space utilization in room corners.



Figure 2.2: Included accessories for the playset.

3. Setup and Assembly

3.1 Included Components

Your package should contain the following main component:

- 1 x Corner Play Kitchen (unassembled parts)

Note: Please refer to the detailed parts list in your packaging for all individual pieces and hardware.

3.2 Tools Required

- Phillips Head Screwdriver (not included)

3.3 Assembly Instructions

Follow the step-by-step instructions provided in the video below for proper assembly. It is recommended to assemble the

kitchen on a soft, clean surface to prevent scratches.

Your browser does not support the video tag.

Video 3.1: Assembly guide for the HONEY JOY Kids Kitchen Playset. This video demonstrates the step-by-step process of putting together the various components of the play kitchen, including attaching panels, securing hardware, and installing accessories.



Figure 3.1: Product dimensions for planning placement.

4. Operating Instructions

This section details how children can interact with the various features of the HONEY JOY Corner Kids Kitchen Playset.



Figure 4.1: Examples of realistic cooking role-play.

4.1 Using the Sink

The play sink features a faucet with rotary knobs for pretend hot and cold water. Children can place play food items in the sink basin for washing. The faucet can swivel for added realism.

4.2 Using the Stove Top

The stove top includes two burners with realistic graphics. Rotary knobs provide a satisfying*click* sound when turned, simulating the activation of burners. Children can place play pots and pans on the burners for pretend cooking.



Figure 4.2: Stove top with realistic sounds and lights.

4.3 Using the Oven

The oven features a door that opens and closes, allowing children to place play food items inside for pretend baking. The clear window allows them to 'check' on their creations.

4.4 Using the Microwave

The microwave has a door that opens and closes, and a pretend keypad for setting cooking times. Children can place play food inside for reheating.

4.5 Using the Ice Maker

The ice maker dispenser allows children to press a button or lever to simulate dispensing ice cubes into a cup (wooden ice cubes and cup included).

4.6 Using the Washing Machine

The washing machine features a front-loading door that opens and closes, and a rotary dial for selecting wash cycles.

Children can place small play clothes or accessories inside for pretend washing.



Figure 4.3: Detailed interactions with various kitchen components.



Figure 4.4: Further detailed interactions with kitchen appliances.

4.7 Storage Areas

The playset includes various shelves and cabinets for storing play food, utensils, and other accessories, helping children keep their play area tidy.



Figure 4.5: Various storage areas within the playset.

5. Maintenance

Proper maintenance will ensure the longevity and safety of your HONEY JOY Corner Kids Kitchen Playset.

- **Cleaning:** To clean the playset, wipe surfaces with a soft, damp cloth. A mild soap solution can be used for stubborn marks, followed by wiping with a clean, damp cloth. Avoid abrasive cleaners, harsh chemicals, or excessive moisture, as these can damage the wood finish.
- **Inspection:** Regularly inspect the playset for any loose parts, screws, or signs of damage.
- **Tightening:** Tighten screws as needed to maintain stability and structural integrity. Do not over-tighten.
- **Storage:** Store the playset indoors in a dry environment to prevent warping or damage from humidity.

6. Troubleshooting

If you encounter any issues with your playset, please refer to the following common solutions:

- **Loose Parts:** If any panels or components feel wobbly, check all associated screws and re-tighten them using a Phillips head screwdriver.
- **Damaged or Missing Parts:** If you find any parts are damaged upon arrival or go missing, please contact HONEY JOY customer support for assistance. Do not attempt to use damaged parts.

7. Specifications

Detailed specifications for the HONEY JOY Corner Kids Kitchen Playset (Model HJ-2794-CA).

Feature	Detail
Brand	HONEY JOY
Model Number	HJ-2794-CA
Color	Pink
Material Type	Engineered Wood

Item Dimensions (D x W x H)	11"D x 11.5"W x 37"H (approx. 27.9 cm D x 29.2 cm W x 94 cm H)
Recommended Age	36 months - 8 years
Included Components	1 x corner play kitchen (unassembled)



Figure 7.1: Visual representation of product specifications.

8. Warranty and Support

For warranty information, product support, or to order replacement parts, please contact HONEY JOY customer service. Refer to your purchase documentation for specific contact details or visit the official HONEY JOY website for the most up-to-date support information.

HONEY JOY Official Store: Visit the HONEY JOY Store on Amazon

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DQ7G6SBL

More documents and user manuals: **https://manuals.plus/**