Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MAHANCRIS PTBK14E01

MAHANCRIS PTBK14E01 Printer Stand

User Manual

1. Introduction

Thank you for choosing the MAHANCRIS PTBK14E01 Printer Stand. This versatile and sturdy stand is designed to optimize your workspace, providing dedicated storage for your printer, office supplies, and electronic devices. Its corner-friendly design and integrated charging station make it an efficient addition to any home or office environment. Please read this manual carefully before assembly and use to ensure proper installation and safe operation.



Figure 1.1: The MAHANCRIS PTBK14E01 Printer Stand, fully assembled and in use, showcasing its multi-tier storage and integrated charging station in a modern office environment.

2. Safety Information

- Always assemble the stand on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check for tightness.
- Do not exceed the maximum weight capacities for each shelf. Refer to the specifications section for details.
- Keep small parts and packaging materials away from children.
- Use the integrated charging station only for indoor use and with compatible devices.
- Avoid placing hot items directly on the stand's surfaces without protection.




Figure 2.1: Detailed diagram showing the dimensions and maximum weight capacities for each shelf of the printer stand. The top shelf supports up to 66 lbs, while the lower shelves each support up to 55 lbs.

3. Package Contents

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Top Shelf Panel (x1)
- Middle Shelf Mesh Panel (x1)
- Bottom Shelf Mesh Panel (x1)
- Metal Frame Legs (x4)
- Crossbars/Support Rods (various sizes)
- Integrated Power Strip with USB Ports (x1)
- Adjustable Feet (x6)

- Assembly Hardware (screws, Allen wrench)

4. Assembly Instructions

Follow these steps carefully to assemble your MAHANCRIS PTBK14E01 Printer Stand.

1. **Unpack and Identify Parts:** Lay out all components on a clean, soft surface. Refer to the package contents list to ensure everything is present.
2. **Assemble the Frame:** Attach the metal frame legs and crossbars using the provided screws. Ensure the frame is stable and square. Do not fully tighten screws until all parts are loosely connected.
3. **Install Lower Shelves:** Secure the middle and bottom mesh shelf panels to the assembled frame using the designated screws.
4. **Attach Top Shelf:** Place the top shelf panel onto the frame and secure it with screws. Ensure the cutout for the power strip is correctly oriented.
5. **Install Power Strip:** Insert the integrated power strip into the designated slot on the top shelf and secure it.
6. **Attach Adjustable Feet:** Screw the adjustable feet into the bottom of each leg.
7. **Final Tightening:** Once all parts are in place, systematically tighten all screws using the provided Allen wrench. Ensure the stand is firm and stable.
8. **Adjust Leveling:** Place the stand in its desired location. Adjust the height of the adjustable feet by rotating them until the stand is level and stable on uneven floors.



Figure 4.1: Close-up views highlighting key features such as the spacious top, 360-degree adjustable feet for leveling, the sturdy metal frame construction, and the multi-tier storage design.

5. Operating Instructions

5.1 Placement and Stability

The MAHANCRIS PTBK14E01 is designed with a unique corner shape to maximize space utilization. Position the stand in a corner or against a wall for optimal stability and aesthetic integration. Use the adjustable feet to ensure the stand is perfectly level on any surface.



Figure 5.1: The printer stand positioned in a corner, illustrating its space-saving design and the convenient access to the charging station on the top shelf.

5.2 Using the Charging Station

The integrated power strip on the top shelf provides convenient access to power outlets and USB charging ports. Plug the stand's power cord into a wall outlet. You can then plug in your printer, laptop, phone, or other electronic devices directly into the stand's outlets or USB ports.

- Ensure the power cord is fully inserted into a grounded wall outlet.
- Do not overload the power strip. Refer to the power strip's specifications for maximum wattage.
- The charging station is for indoor use only.



Figure 5.2: A detailed view of the integrated charging station, featuring two power outlets and two USB ports, actively charging a smartphone.

5.3 Storage and Organization

Utilize the multi-tier shelves to organize your office essentials. The top shelf is ideal for your printer or other frequently accessed devices. The lower mesh shelves are suitable for paper, binders, books, and other office supplies. Ensure items are distributed evenly to maintain stability.



Figure 5.3: The printer stand in an office setting, demonstrating its capacity to hold a printer, binders, and other office supplies on its multiple shelves.

6. Maintenance

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Fastener Check:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Power Cord Inspection:** Regularly inspect the power cord for any signs of damage or fraying. Discontinue use if damage is found and contact customer support.

7. Troubleshooting

- **Stand is Wobbly:**

- Ensure all assembly screws are fully tightened.
- Adjust the leveling feet at the bottom of each leg until the stand is stable on the floor.

- **Power Strip Not Working:**
  - Check if the stand's main power cord is securely plugged into a functional wall outlet.
  - Verify that the devices plugged into the power strip are working correctly.
  - Ensure the power strip itself is properly seated in its slot on the top shelf.

- **Missing or Damaged Parts:**
  - Refer to the 'Package Contents' section. If parts are missing or damaged upon arrival, contact MAHANCRIS customer support immediately.

8. Specifications

Brand	MAHANCRIS
Model Number	PTBK14E01
Colour	Black
Form Factor	Desk Stand
Recommended Uses	Desk, Printer Stand, Office Storage
Item Dimensions (L x W x H)	59.4 x 38.1 x 76.2 Centimeters (23.4 x 15 x 30 Inches)
Adjustable Length	No
Top Shelf Weight Capacity	66 lbs (approx. 30 kg)
Lower Shelf Weight Capacity	55 lbs (approx. 25 kg) per shelf
Country of Origin	USA

9. Warranty and Support

MAHANCRIS products are manufactured with quality and customer satisfaction in mind. For specific warranty information, please refer to the documentation included with your purchase or visit the official MAHANCRIS website. If you encounter any issues or have questions regarding your PTBK14E01 Printer Stand, please contact MAHANCRIS customer support for assistance.

Customer Support Contact: Please refer to your purchase receipt or the MAHANCRIS official website for the most up-to-date contact information.

© 2026 MAHANCRIS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DQ864R4V

More documents and user manuals: **https://manuals.plus/**