MIlse RX 580 8GB Graphics Card

MIlse RX 580 8GB Graphics Card User Manual

Model: RX 580 8GB Graphics Card
Brand: MIlse

1. Product Overview

The MIlse RX 580 8GB Graphics Card is a high-performance component designed for desktop computers, offering robust capabilities for gaming and demanding graphical tasks. Featuring 8GB of GDDR5 memory and a 256-bit memory interface, it provides efficient data processing for smooth visual experiences. The card supports PCIe 3.0 and includes multiple display outputs for versatile connectivity.



Image 1.1: The Mllse RX 580 8GB Graphics Card, presented alongside its retail packaging. This image illustrates the dual-fan cooling system and the overall design of the graphics card, emphasizing its readiness for installation.

2. Key Features

- **High Performance:** Equipped with 2048 stream processors and a boost engine clock of 1284 MHz, delivering up to 5.25 TFLOPS.
- **Ample Memory:** 8GB GDDR5 memory with a 256-bit memory interface and 224 GB/s memory bandwidth for demanding applications.
- **Efficient Cooling:** Features a dual-fan cooling system to maintain optimal operating temperatures during intensive use.
- **Multi-Display Support:** Capable of supporting up to three monitors simultaneously for enhanced productivity and immersive gaming.
- **Robust Design:** Includes a 1.5mm full-size backplate for increased rigidity and improved heat dissipation.

- **Versatile Connectivity:** Provides HDMI, DisplayPort, and DVI ports for broad compatibility with various display devices.




Image 2.1: Detailed technical specifications of the MIlse RX 580 Graphics Card, highlighting key performance metrics such as power interface (6-pin), stream processors (2048), memory clock (1750 MHz), boost engine clock (1284 MHz), TFLOPS (5.25), GDDR5 memory (8GB), memory bandwidth (224 GB/s), and memory interface (256-bit). It also notes support for DirectX 12, Vulkan, FreeSync 2 HDR, and Relive, indicating performance enhancements and 14nm technology.



Image 2.2: A performance chart illustrating the Frames Per Second (FPS) achieved by the Mllse RX 580 Graphics Card in various popular games at 1080p Max Settings. Games listed include PUBG, Fortnite, Shadow of the Tomb Raider, Monster Hunter World, Forza Horizon 4, and Call of Duty Black Ops 4, demonstrating the card's gaming capabilities.

3. Setup and Installation

3.1 System Requirements

- PCI Express x16 slot on motherboard.
- Minimum 500W power supply with one 6-pin PCIe power connector.
- Compatible operating system (Windows 7/10/11, Linux).
- At least 8GB of system RAM recommended.

3.2 Physical Installation

1. **Prepare Your System:** Power off your computer and unplug all cables. Open your computer case.
2. **Locate PCIe Slot:** Identify an available PCI Express x16 slot on your motherboard.

3. **Insert Graphics Card:** Gently align the graphics card with the PCIe slot and press down firmly until it clicks into place. Secure the card with the retention clip or screw.
4. **Connect Power:** Connect the 6-pin PCIe power cable from your power supply to the corresponding port on the graphics card. Ensure a secure connection.
5. **Close Case:** Close your computer case and reconnect all cables.



Image 3.1: A side view of the Mllse RX 580 Graphics Card, clearly showing the heat pipes and the 6-pin power connector. This view is crucial for identifying the power input required for proper operation during installation.

3.3 Driver Installation

After physical installation, you must install the latest drivers for optimal performance and stability.

1. **Power On:** Turn on your computer. The system may boot with a basic display driver.
2. **Download Drivers:** Visit the official AMD website (www.amd.com/en/support) and navigate to the driver download section. Select the Radeon RX 580 and download the latest recommended driver package for your operating system.
3. **Install Drivers:** Run the downloaded installer and follow the on-screen prompts. It is recommended to perform a clean installation to avoid conflicts with previous drivers.
4. **Restart:** Restart your computer after the installation is complete.

4. Operating the Graphics Card

4.1 Connecting Displays

The Mllse RX 580 offers multiple display output options:

- **DisplayPort (DP):** For high-resolution and high-refresh-rate monitors.
- **HDMI:** Standard for most modern displays, including TVs and monitors.
- **DVI:** For older monitors or specific professional displays.

Connect your monitor(s) to the appropriate ports on the graphics card. Ensure cables are securely fastened.



Image 4.1: An illustration of a multi-monitor display setup, demonstrating the Mllse RX 580 Graphics Card's capability to support multiple screens simultaneously. The image highlights the DisplayPort, HDMI, and DVI outputs available on the card for connecting various display types.

4.2 Multi-Monitor Configuration

To set up multiple monitors:

1. Connect all desired monitors to the graphics card.
2. Right-click on your desktop and select "Display settings" (Windows) or equivalent.
3. Detect and arrange your displays as needed. You can extend your desktop across multiple screens or duplicate displays.

5. Maintenance

Proper maintenance ensures the longevity and optimal performance of your graphics card.

- **Dust Removal:** Regularly clean dust from the graphics card fans and heatsink using compressed air. Ensure the

computer is powered off and unplugged before cleaning.

- **Airflow:** Ensure good airflow within your computer case. Keep cables tidy and ensure case fans are functioning correctly to prevent heat buildup.
- **Driver Updates:** Keep your graphics drivers updated. AMD frequently releases new drivers that include performance improvements and bug fixes.

6. Troubleshooting

6.1 No Display Output

- **Check Cables:** Ensure all display cables (HDMI, DP, DVI) are securely connected to both the graphics card and the monitor.
- **Power Connection:** Verify that the 6-pin PCIe power connector is firmly seated in the graphics card.
- **Monitor Input:** Confirm your monitor is set to the correct input source (e.g., HDMI 1, DisplayPort).
- **Reseat Card:** Power off and unplug your PC, then carefully remove and re-insert the graphics card into its PCIe slot.

6.2 Driver Issues or Instability

- **Clean Driver Installation:** If experiencing crashes or poor performance, try performing a clean installation of the latest drivers from the AMD website. Use a tool like Display Driver Uninstaller (DDU) in Safe Mode to completely remove old drivers before installing new ones.
- **Check System Compatibility:** Ensure your operating system and other hardware components meet the minimum requirements for the graphics card.

6.3 Overheating

- **Monitor Temperatures:** Use monitoring software (e.g., AMD Radeon Software) to check the GPU temperature during use.
- **Improve Airflow:** Ensure your PC case has adequate ventilation. Clean dust from fans and heatsinks.
- **Fan Operation:** Verify that the graphics card fans are spinning correctly when under load.

7. Specifications

Feature	Specification
Brand	Mllse
Graphics Coprocessor	AMD Radeon RX 580
Graphics RAM Size	8 GB GDDR5
GPU Clock Speed	1284 MHz (Boost)
Memory Interface	256-bit
Video Output Interface	DisplayPort, HDMI, DVI
Product Dimensions	8.58 x 4.8 x 0.1 inches
Item Weight	1.96 pounds

Feature	Specification
Manufacturer	MLLSE
Country of Origin	China
Date First Available	December 21, 2024



Image 7.1: A diagram illustrating the physical dimensions of the Mllse RX 580 Graphics Card, showing its length (218mm), height (122mm), and thickness (42mm). This information is useful for verifying compatibility with PC cases.

8. Warranty and Support

For information regarding warranty coverage, technical support, and service, please refer to the official Mllse website or contact their customer service directly. Keep your proof of purchase for warranty claims.

For additional resources and driver updates, visit the AMD support page:www.amd.com/en/support

© 2024 Mllse. All rights reserved.