



[Manuals.plus](#) /

› [Sweetcrispy](#) /

› Sweetcrispy Full Adjustable Bed Frame User Manual - Model HJ2-DDCFull

## Sweetcrispy HJ2-DDCFull

# Sweetcrispy Full Adjustable Bed Frame User Manual

MODEL: HJ2-DDCFULL

## Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your Sweetcrispy Full Adjustable Bed Frame, Model HJ2-DDCFull. Please read this manual thoroughly before assembly and use to ensure proper function and safety. Keep this manual for future reference.



Image: The Sweetcrispy Full Adjustable Bed Frame, shown with its head and foot sections slightly raised, positioned in a modern bedroom environment.

## Safety Information

---

### **WARNING:**

- Always follow assembly instructions carefully.
- Do not exceed the weight capacity of 750 lbs (approximately 340 kg).
- This product may pose a tip-over risk if not properly assembled or used.
- Keep children and pets away from the product during assembly and use.
- Ensure all electrical connections are secure and follow local electrical codes.
- Do not operate the bed if any part is damaged or malfunctioning. Contact customer support immediately.

## Package Contents

---

Before beginning assembly, verify that all parts are present. If any parts are missing or damaged, do not proceed with assembly and contact Sweetcrispy customer support.

- Adjustable Bed Base (pre-assembled sections)
- Legs (multiple sections for adjustable height)
- Mattress Retainer Bar(s)
- Wireless Remote Control
- Power Cord and Adapter
- Batteries for Remote Control (not included, typically AAA)
- User Manual (this document)

## Assembly Instructions

Assembly of the Sweetcrispy Adjustable Bed Frame is designed to be straightforward and requires no tools. It is recommended to have two people for easier handling due to the weight of the frame.

1. **Unfold the Bed Base:** Carefully unfold the pre-assembled bed base sections. Ensure it is placed on a flat, clear surface.
2. **Install the Legs:** Screw the legs into the threaded holes on the underside of the bed base. The legs may consist of two 6-inch sections, allowing for 6-inch or 12-inch height options. Ensure all legs are securely tightened.
3. **Connect Power:** Connect the power cord to the power supply adapter, then plug the adapter into the bed base. Finally, plug the power cord into a grounded electrical outlet.
4. **Insert Mattress Retainer Bar:** Locate the mattress retainer bar(s) and insert them into the designated slots at the foot of the bed base. This prevents the mattress from slipping.
5. **Install Remote Batteries:** Insert the required batteries (not included) into the wireless remote control.
6. **Test Functionality:** Before placing your mattress, test the remote control to ensure the head and foot sections move smoothly.




Image: Visual representation of the no-tools assembly process, showing unfolding the base, attaching legs, connecting power, inserting the mattress retainer bar, and the final setup.

**FULL**




Image: A front perspective of the assembled adjustable bed frame, highlighting its structural design and material finish.

## Operating Instructions

Your Sweetcrispy Adjustable Bed Frame is operated using a wireless remote control, offering various comfort positions and features.

## Wireless Remote Control Functions

# Features

- 1 Head Up
- 2 Head Down
- 3 Foot Up
- 4 Foot Down
- 5 Flat




Image: The wireless remote control with clearly labeled buttons for adjusting the bed's position.

- **Head Up/Down:** Use the corresponding buttons to raise or lower the head section of the bed. The head can be elevated from 0 to 60 degrees.
- **Foot Up/Down:** Use the corresponding buttons to raise or lower the foot section of the bed. The foot can be elevated from 0 to 40 degrees.
- **Flat:** Press this button to return the bed to a completely flat position.
- **Zero Gravity:** Activates a preset position that elevates both the head and feet to reduce pressure on the back and improve circulation, simulating a feeling of weightlessness.
- **Anti-Snore:** Activates a preset position that slightly raises the head to open airways, potentially reducing snoring.
- **Reading Setting:** Activates a preset position that raises the head and slightly the feet for comfortable reading or watching television.

**0-60°**  
**Head Incline**

**0-40°**  
**Foot Incline**




**Non-slip Bedding Fabric**

Image: Illustration detailing the range of head and foot incline adjustments available on the bed frame, along with its weight capacity.


### **USB Charging Ports**

The bed frame is equipped with two USB ports (1x USB-A, 1x USB-B) located near the head area, allowing you to charge your devices conveniently.

# Suitable for Most Mattresses



Memory foam



Hybrid



Innerspring



Latex

## Tips: Recommended for mattresses under 14

Image: Close-up view of the USB charging ports on the side of the bed frame, demonstrating a device being charged.

### Maintenance

Regular maintenance helps ensure the longevity and optimal performance of your adjustable bed frame.

- **Cleaning:** Wipe the frame with a damp cloth. Avoid harsh chemicals or abrasive cleaners. For fabric parts, use a mild fabric cleaner if necessary.
- **Inspections:** Periodically check all bolts, screws, and connections to ensure they are tight. Re-tighten if necessary.
- **Electrical Components:** Ensure the power cord and adapter are free from damage. Do not expose electrical components to moisture.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 750 lbs.

### Troubleshooting

If you encounter any issues with your adjustable bed frame, refer to the following common problems and solutions:

- **Bed does not respond to remote control:**

- Check if the power cord is securely plugged into both the bed base and the wall outlet.
- Ensure the wall outlet is functional by plugging in another device.
- Replace the batteries in the wireless remote control.
- Ensure there are no obstructions preventing the bed's movement.

- **Motor makes noise but bed does not move:**

- Check for any obstructions under the bed that might be blocking the mechanism.
- Verify that the bed is not overloaded beyond its 750 lbs weight capacity.

- **Uneven movement of head or foot section:**

- Ensure the bed is on a flat and level surface.
- Check for any loose connections or damaged parts.

If the problem persists after attempting these solutions, please contact Sweetcrispy customer support.

## Specifications

<b>Brand:</b>	Sweetcrispy
<b>Model Number:</b>	HJ2-DDCFull
<b>Size:</b>	Full Size
<b>Product Dimensions (L x W x H):</b>	75 x 54 x 13.7 inches
<b>Item Weight:</b>	119.3 pounds
<b>Material:</b>	Metal
<b>Special Feature:</b>	Adjustable, Wireless Remote, USB Ports
<b>Head Incline Range:</b>	0 to 60 degrees
<b>Foot Incline Range:</b>	0 to 40 degrees
<b>Maximum Weight Capacity:</b>	750 lbs
<b>Compatible Mattress Types:</b>	Latex, Hybrid Foam, Gel Foam, Memory Foam (recommended under 14 inches)
<b>UPC:</b>	719406413528

# Provides a Comfortable Sleeping Experience

Effectively Relieves Back and Neck Fatigue



Image: Visual guide to compatible mattress types, including memory foam, hybrid, and latex, with a recommendation for mattresses under 14 inches thick.

## Warranty and Support

For warranty information, product support, or to order replacement parts, please refer to the Sweetcrispy official website or contact their customer service department directly. Keep your purchase receipt as proof of purchase.

**Sweetcrispy Customer Support:** Refer to your purchase documentation or the Sweetcrispy official website for contact details.