

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [SVAKOM](#) /

› [SVAKOM Beatrice S137B Personal Massager User Manual](#)

## SVAKOM S137B

# SVAKOM Beatrice S137B Personal Massager User Manual

Brand: SVAKOM | Model: S137B

## INTRODUCTION

This manual provides detailed instructions for the safe and effective use of your SVAKOM Beatrice S137B personal massager. Please read this manual thoroughly before first use and retain it for future reference.

The SVAKOM Beatrice S137B is a versatile 4-in-1 personal massager designed for targeted stimulation, featuring two detachable silicone heads, 10 vibration patterns, and 5 intensity levels. It is constructed from high-grade silicone and is IPX7 waterproof.

## IMPORTANT SAFETY INFORMATION


- **Age Restriction:** This product is intended for use by individuals 18 years of age or older.
- **Lubrication:** Always use with water-based lubricants. Oil-based lubricants may damage the silicone material.
- **Cleaning:** Clean the device thoroughly before and after each use with warm water and mild soap, or a specialized toy cleaner.
- **Waterproof:** The device is IPX7 waterproof, meaning it can be submerged in water up to 1 meter for 30 minutes. Ensure the charging port is securely sealed before water exposure.
- **Charging:** Use only the provided charging cable. Do not use the device while charging.
- **Storage:** Store in a cool, dry place away from direct sunlight and extreme temperatures. Keep out of reach of children.
- **Discontinue Use:** If you experience any discomfort, irritation, or pain during use, discontinue immediately and consult a healthcare professional.
- **Material:** Made from high-grade silicone, which is CE/ROSH certified for safety.

## PRODUCT OVERVIEW

The SVAKOM Beatrice S137B is designed for versatile pleasure, offering multiple stimulation options with its unique design and interchangeable heads.



**Image 1:** SVAKOM Beatrice S137B main unit with two detachable silicone heads. The main unit is purple with a gold-colored tip, and the two heads are also purple silicone.



**Image 2:** The SVAKOM Beatrice S137B with one silicone head attached, illustrating its multiple stimulation capabilities for G-spot and clitoral areas.

## Pinpoint Stimulation




2 Different Replaceable  
Silicone Heads

C

**Image 3:** A side view of the SVAKOM Beatrice S137B, emphasizing its streamlined shape for comfortable use.

## 10 VIBRATIONS

Clitoral & G Spot  
Precise Intensive Stimulation



**Image 4:** Close-up view of the SVAKOM Beatrice S137B's detachable silicone heads, designed for precise pinpoint stimulation.

### Key Features:

- **4-in-1 Functionality:** Designed for clitoral, G-spot, nipple, and anal stimulation.
- **Interchangeable Heads:** Includes two distinct silicone heads for varied sensations.
- **Multiple Vibration Settings:** 10 unique vibration patterns with 5 adjustable intensity levels.
- **Powerful Motors:** Delivers up to 12,000 rotations per minute for intense sensations.
- **IPX7 Waterproof:** Fully submersible for easy cleaning and use in water.
- **Whisper Quiet:** Operates at a low noise level (under 40dB).
- **Body-Safe Material:** Made from high-grade, CE/ROSH certified silicone.

### SETUP

## 1. Initial Charge:

Before first use, fully charge your SVAKOM Beatrice S137B. The charging time is approximately 0.8-1 hour for up to 2 hours of pleasure time.

1. Locate the charging port, usually at the base of the device.
2. Insert the provided USB charging cable into the port.
3. Connect the other end of the USB cable to a compatible USB power source (e.g., computer, wall adapter).
4. The indicator light will illuminate during charging and change when fully charged.



Image 5: The SVAKOM Beatrice S137B connected to its charging cable, illustrating the pinhole charging method.

## 2. Attaching/Changing Silicone Heads:

The SVAKOM Beatrice S137B comes with two interchangeable silicone heads for varied experiences.

1. Gently pull off the currently attached head from the gold-colored tip of the device.
2. Select your desired silicone head.
3. Align the opening of the new head with the gold-colored tip and push it firmly until it is securely in place.

# Squirting Queen

2 headgears

X

Pinpoint

X

Penetration



**Image 6:** The Svakom Beatrice S137B main unit alongside its two distinct detachable silicone heads, ready for attachment.

## OPERATING INSTRUCTIONS

### 1. Power On/Off:

- To power on, press and hold the power button (usually marked with a circle or power symbol) for 2-3 seconds until the device vibrates and the indicator light illuminates.
- To power off, press and hold the power button for 2-3 seconds until the device stops vibrating and the light turns off.

### 2. Changing Vibration Patterns and Intensity:

- Once powered on, short press the mode button to cycle through the 5 intensity levels for the current vibration pattern.
- Double-click the mode button to switch between the 10 available vibration patterns.

- Experiment to find the pattern and intensity that best suits your preference.



**Image 7:** A visual representation of the 10 distinct vibration patterns available on the Svakom Beatrice S137B.

### 3. Recommended Use:

- Apply a generous amount of water-based lubricant to the device and the desired area of stimulation.
- Start with a low intensity and gentle movements, gradually increasing intensity and exploring different patterns as desired.
- The flexible design and interchangeable heads allow for precise targeting of sensitive areas such as the clitoris, G-spot, and nipples.

Your browser does not support the video tag.

**Video 1:** Official Svakom video demonstrating the use and features of the Beatrice Squirt Queen Dildo Vibrator. This video shows the device being charged, heads being swapped, and its waterproof capabilities.

Your browser does not support the video tag.

**Video 2:** Official Svakom video showcasing the Beatrice Pinpoint Clit Dildo Vibrator. This video highlights the device's design, interchangeable heads, and various vibration settings.

## MAINTENANCE

### 1. Cleaning:

Proper cleaning ensures hygiene and prolongs the lifespan of your device.

- Always clean the device immediately after each use.
- Wash with warm water and a mild, toy-safe soap or a dedicated toy cleaner.
- Rinse thoroughly to remove all soap residue.
- Pat dry with a lint-free cloth or allow to air dry completely before storing.
- Ensure the charging port cover is closed during cleaning if submerging.

### 2. Storage:

- Store the SVAKOM Beatrice S137B in a clean, dry, and dust-free environment.
- Keep it away from direct sunlight, extreme temperatures, and other toys made of different materials to prevent damage or reactions.
- The discreet package or a dedicated storage pouch (if included) is ideal for storage.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	Low battery or not charged.	Charge the device fully using the provided USB cable. Ensure the charging cable is properly connected.
Weak vibrations.	Low battery or incorrect intensity setting.	Recharge the device. Adjust the intensity level using the control buttons.
Device stops working during use.	Battery depleted.	Recharge the device.
Heads are difficult to attach/detach.	Dry silicone or improper alignment.	Ensure the silicone is dry. Align carefully and apply gentle, firm pressure. Do not force.

If problems persist, please contact SVAKOM customer support for assistance.

## SPECIFICATIONS

Feature	Detail
Product Name	Beatrice
Model Number	S137B
Brand	SVAKOM

Feature	Detail
Material	Silicone, Metals, ABS
Dimensions (L x W x H)	8.27 x 1.42 x 1.3 inches (209 x 44.3 x 32.5 mm)
Weight	11.68 ounces (96.5g + 10g)
Battery Type	Polymer lithium battery
Battery Capacity	300mAh
Charging Time	0.8 - 1 hour
Working Time	Up to 2 hours
Waterproof Rating	IPX7
Vibration Modes	10 patterns (5x5 modes for clitoral and vibration)
Noise Level	Below 40dB

## WARRANTY AND SUPPORT

### 1. 1-Year Protection:

The SVAKOM Beatrice S137B comes with a 1-year protection plan starting from the date of purchase. This warranty covers problems caused by material flaws, manufacturing flaws, and parts that influence normal functioning. For any issues during this period, you may be eligible for a free replacement.

### 2. Customer Support:

For any questions, concerns, or warranty claims, please contact SVAKOM customer support directly. Refer to the product packaging or the official SVAKOM website for contact information.

**Legal Disclaimer:** Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.