Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Pamapic 8840

Pamapic 7-Piece Outdoor Dining Set User Manual

Model: 8840

Introduction Safety Information Package Contents Setup & Assembly Operation Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

Thank you for choosing the Pamapic 7-Piece Outdoor Dining Set. This set is designed to provide a comfortable and stylish outdoor dining experience, perfect for patios, decks, gardens, or poolside areas. It includes a rectangular dining table, two rattan swivel chairs, and four regular chairs, all with soft, removable cushions.

This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure you get the most out of your new furniture set. Please read this manual thoroughly before assembly and use, and retain it for future reference.



Image: The complete Pamapic 7-Piece Outdoor Dining Set, featuring a rectangular table, two swivel chairs, and four fixed chairs, all with grey cushions.

2. Safety Information

WARNING: Failure to follow these safety instructions could result in injury or damage to the product.

- Always assemble the product on a soft, clean surface to prevent scratches.
- Ensure all bolts and screws are securely tightened before use. Periodically check and re-tighten fasteners.
- Do not exceed the maximum weight capacity of 330 lbs (150 kg) per chair.
- Keep children away from the assembly area. Small parts can be a choking hazard.
- Do not stand on the chairs or table.
- Use caution when rocking or swiveling chairs to avoid tipping.
- Protect the furniture from extreme weather conditions (heavy rain, snow, strong winds) to prolong its lifespan. Consider using a furniture cover when not in use.
- Do not place hot items directly on the table surface without protection.

3. Package Contents

Your Pamapic 7-Piece Outdoor Dining Set is delivered in 3 separate boxes. Please verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support immediately.

Box 1: Rectangular Dining Table (1)

Box 2: Swivel Chairs (2), Cushions (2)

Box 3: Fixed Chairs (4), Cushions (4)

Hardware Pack: Bolts, washers, nuts, and assembly tools (e.g., Allen wrench).



Image: Diagram showing the dimensions of the table and chairs, and indicating that the product is delivered in 3 separate boxes (1 for table, 2 for swivel chairs, 3 for fixed chairs).

4. Setup & Assembly

Assembly is required for this furniture set. It is recommended to have two people for assembly. Lay out all parts on a soft, non-abrasive surface to prevent damage.

4.1. Table Assembly

1. Unpack all table components: tabletop, legs, and support bars.
2. Attach the legs to the tabletop using the provided bolts and washers. Do not fully tighten yet.
3. Connect the support bars between the legs.
4. Once all components are loosely assembled, place the table upright and gently rock it to ensure it's level.
5. Gradually tighten all bolts evenly until secure.
6. Adjust the non-slip adjustable feet pads on the table legs to ensure stability on uneven surfaces.



Image: Detailed view of the table features, including the iron slat tabletop, umbrella hole, fixed hole, and non-slip adjustable feet pads.

4.2. Chair Assembly (Fixed & Swivel)

The assembly process for both fixed and swivel chairs is similar. Note that some users have reported difficulty with screw alignment; ensure not to fully tighten any screws until all are in place.

1. Unpack all chair components: seat frame, backrest, armrests, and base (for swivel chairs).
2. Attach the backrest to the seat frame.
3. Attach the armrests to the seat frame and backrest.
4. For swivel chairs, attach the assembled chair body to the swivel base.
5. Insert all bolts loosely before tightening any. This allows for minor adjustments to align holes.
6. Once all bolts are in place, gradually tighten them evenly until secure.
7. Place the cushions onto the chairs. The cushions are equipped with strong adhesive Velcro to prevent slipping.



Image: Close-up details of the product, highlighting the exquisite hand-woven PE rattan, high-quality Olefin fabric and high-density sponge cushions, and strong adhesive Velcro for cushion attachment.

5. Operation

5.1. Swivel Chairs

The two swivel chairs feature a smooth 360-degree rotation mechanism, allowing for easy maneuverability and flexible seating positions. They also offer a gentle 10-degree rocking motion for added relaxation.

- To swivel: Simply rotate the chair in any direction.
- To rock: Lean back gently to engage the rocking motion.



Image: Visual representation of the 360-degree swivel and 10-degree gentle rocking capabilities of the swivel chairs.

5.2. Dining Table

The rectangular dining table is designed for outdoor meals and gatherings. It features an iron slat tabletop for durability and easy cleaning. A 2-inch (5.1 cm) umbrella hole is integrated into the center of the table, allowing you to add a patio umbrella for shade.

- To use with an umbrella: Insert the umbrella pole into the central hole. Ensure the umbrella base is stable and secure.
- Adjustable feet: Use the adjustable feet pads on the table legs to stabilize the table on uneven surfaces.

6. Maintenance

Regular maintenance will help preserve the appearance and extend the lifespan of your Pamapic outdoor dining set.

6.1. Cleaning

- **Frame and Rattan:** Wipe down with a soft cloth dampened with mild soap and water. Rinse thoroughly with clean water and dry completely to prevent water spots and rust. Avoid harsh chemicals or abrasive cleaners.
- **Cushions:** The cushion covers are made of Olifan fabric and are removable and machine washable for easy care. Wash in cold water on a gentle cycle with mild detergent. Air dry or tumble dry on low. Do not bleach.
- **Tabletop:** The iron slat tabletop is dirt-resistant and easy to clean. Wipe with a damp cloth. For stubborn stains, use a mild cleaner designed for outdoor furniture.

6.2. Storage and Protection

- During periods of non-use or harsh weather conditions (e.g., heavy rain, snow, strong winds), it is recommended to cover the furniture with a protective outdoor furniture cover.
- Store cushions indoors during inclement weather or when not in use to prevent mildew and fading.
- If storing the entire set for an extended period, choose a cool, dry location.

7. Troubleshooting

Problem	Possible Cause	Solution
Difficulty aligning screw holes during assembly.	Screws tightened too early; parts not perfectly aligned.	Loosen all screws on the component, align holes, insert all screws loosely, then gradually tighten them evenly.
Table or chairs wobble.	Uneven surface; loose fasteners.	Adjust the non-slip adjustable feet pads on the table/chair legs. Check and re-tighten all bolts and screws.
Cushions slide off chairs.	Velcro not properly attached or worn.	Ensure the strong adhesive Velcro on the cushions is securely attached to the chair frame. Clean Velcro if dirty.
Rattan appears damaged or unraveling.	Wear and tear; shipping damage.	For minor unraveling, carefully tuck the strand back into place. For significant damage, contact customer support.
Product arrived in multiple boxes, but not all arrived at once.	Standard shipping practice for multi-box items.	This is normal. Please allow a few extra days for all boxes to arrive. If a box is significantly delayed, contact the shipping carrier or customer support.

8. Specifications

Feature	Detail
Brand	Pamapic
Model Number	8840
Color	Grey
Material	Metal frame, PE Rattan, Olefin Fabric cushions
Table Dimensions (L x W x H)	59.8" x 35.1" x 28.6" (151.89 x 89.15 x 72.64 cm)

Feature	Detail
Swivel Chair Dimensions (L x W x H)	23.8" x 21.6" x 36.5" (59.8 x 55.6 x 91.7 cm)
Fixed Chair Dimensions (L x W x H)	23" x 21.3" x 35.4" (58 x 54 x 90 cm)
Cushion Thickness	2.4" (6.1 cm)
Chair Weight Capacity	330 lbs (150 kg)
Total Item Weight	45.2 lbs (20.5 kg) *(Note: This is likely the weight of one component, not the full set, which ships in 3 boxes.)*
Assembly Required	Yes
UPC	850052829612

9. Warranty & Support

Pamapic stands behind the quality of its products. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official Pamapic website.
If you encounter any issues during assembly or use, or if you have questions about your product, please contact Pamapic customer support. Have your model number (8840) and purchase details ready when contacting support.
Customer Support Contact:

Website: Visit the Pamapic Store on Amazon (for general inquiries and product information)

Email: Refer to your product packaging or warranty card.

Phone: Refer to your product packaging or warranty card.

If you find any damage caused during transportation, please contact us immediately for assistance.

© 2024 Pamapic. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DQCWLGMY

More documents and user manuals: **https://manuals.plus/**