

Tastyle K320IT

Tastyle Single Serve Coffee Maker K320IT Instruction Manual

Brand: Tastyle | Model: K320IT

1. INTRODUCTION

This manual provides detailed instructions for the safe and efficient operation, maintenance, and troubleshooting of your new Tastyle Single Serve Coffee Maker K320IT. Please read this manual thoroughly before first use and keep it for future reference.

Key Features:

- **Versatile Brewing Options:** Enjoy 4 distinct brew styles: Hot, Bold, Over Ice Coffee, and Over Ice Tea. The machine supports K-Cups, ground coffee, and tea leaves with included accessories.
- **Adjustable Brew Sizes:** Brews any cup size between 6 to 16 ounces. The machine brews all water added to the non-removable reservoir, ensuring fresh water for each brew.
- **Splatter-Preventing Design:** Features a removable heightened drip tray to minimize splashing, accommodating cups up to 7.3 inches tall when removed.
- **Compact and Space-Saving:** With dimensions of 9.2"D x 4.6"W x 12"H, this coffee maker is ideal for small countertops, offices, or dorm rooms.
- **User-Friendly & Easy Maintenance:** Equipped with a built-in descale reminder and cleaning function for extended longevity. Constructed from safe, BPA-free plastic and ETL certified.

2. IMPORTANT SAFETY INFORMATION

Please read and follow all safety instructions to prevent electric shock, fire, or injury. Keep this manual in a safe place for future reference.

- Do not immerse the appliance, cord, or plug in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.

- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Extreme caution must be used when moving an appliance containing hot liquids.
- Ensure the lid is securely closed before operating.
- Do not open the top cover during brewing.

3. PACKAGE CONTENTS

Upon unpacking, please ensure all items listed below are present and in good condition:

- Tastyle Single Serve Coffee Maker K320IT
- K-Cup Holder
- Reusable Ground Coffee Filter
- Patented Tea Holder
- Removable Drip Tray
- Recipe Book
- Instruction Manual
- One-year Warranty Card



Image: The Tastyle Single Serve Coffee Maker K320IT shown with its various accessories for K-Cups, ground coffee, and tea leaves, alongside a hot coffee and an iced coffee.

Enjoy 4 Brewing Styles

Versatility Meets Freshness



Image: The coffee maker highlighting its four brewing styles: Over Ice Tea, Over Ice Coffee, Classic Coffee, and Strong Coffee, with a note about included recipes.

Your browser does not support the video tag.

Video: A demonstration of the Tastyle Single Serve Coffee Maker, showcasing its ability to brew K-Cup, ground coffee, and tea.

4. SETUP

Initial Setup:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Placement:** Place the coffee maker on a stable, flat, and heat-resistant surface. Ensure it is near a power outlet.
3. **Drip Tray:** Install the removable drip tray. You can adjust its height or remove it entirely to accommodate taller travel mugs (up to 7.3 inches).
4. **Initial Cleaning Cycle:** Before first use, perform a cleaning cycle. Fill the water reservoir with clean water (up to 16 oz), close the top cover, and place an empty mug on the drip tray. Press the "HOT BREW" button to run a cycle without any

coffee or tea. Discard the water.

Single Cup **16 oz** Reservoir

Easy-to-view water window
Brew all the water added for fresh coffee or tea



Compact Design
For easy cleanup



Travel Mugs Friendly
Up to 7.3"



Removable Drip Trays
For easy cleanup



Image: The coffee maker highlighting its compact design, 16 oz water reservoir with level indicators, and removable drip trays for travel mugs.



Add fresh water for each brew.

Brews any cup size between 6-16 oz, depending on the amount of water poured into the reservoir.



Image: A hand pouring fresh water into the coffee maker's reservoir, with water level markings from 6 oz to 16 oz visible.

5. OPERATING INSTRUCTIONS

General Brewing Steps:

1. **Add Water:** Open the top cover and pour fresh water into the reservoir. Fill between 6 to 16 ounces, depending on your desired brew size. The machine will brew all the water added.
2. **Insert Ingredient:** Choose your preferred brewing method:
 - For K-Cups: Place a K-Cup into the K-Cup holder.
 - For Ground Coffee: Fill the reusable ground coffee filter with your desired amount of ground coffee (up to 1.0 oz / 30g for bold brew).
 - For Tea Leaves: Fill the patented tea holder with loose leaf tea or a tea bag.
3. **Place Cup:** Place your mug or travel cup on the drip tray. Adjust the drip tray height if necessary.
4. **Select Brew Style:** Close the top cover securely. Select your desired brew style by pressing one of the following buttons: "HOT BREW", "BOLD", "OVER ICE", or "ICED TEA".
5. **Brewing:** The machine will begin brewing. Brewing typically takes 2-4 minutes.
6. **Enjoy:** Once brewing is complete, carefully remove your cup and enjoy your beverage.

Specific Brew Styles:

- **Hot Brew:** For a standard hot coffee or tea.
- **Bold Brew:** For a stronger, richer hot coffee.
- **Over Ice Coffee / Iced Tea:** **Important:** Always place ice in your mug before selecting this option. The recommended ice to water ratio is 1:1 for optimal results.



Compatible with American Standard K-Pod

Image: A hand inserting a K-Pod into the coffee maker, demonstrating compatibility with American Standard K-Pods.

Spacious Ground Coffee Filter

Holds up to 30g/1.1oz grounds to
brew bolder coffee



Image: A hand scooping ground coffee into the spacious reusable ground coffee filter, which can hold up to 30g (1.1 oz) for bolder brews.

Exclusively Patented Tea Holder with Innovative Extraction Technology

Fully infuse tea leaves for 45s, enhancing the richness of the tea aroma, then automatically dispense



Patent Support



Can brew using either loose leaf tea or tea bags

Image: The patented tea holder for the Tastyle coffee maker, designed to fully infuse tea leaves for 45 seconds before dispensing, enhancing aroma. It can be used with loose leaf tea or tea bags.



One-Button Operation

Easy single-touch brewing for your perfect cup.



Image: A hand pressing one of the intuitive buttons on the Tastyle coffee maker, illustrating its simple one-button operation for brewing.

Your browser does not support the video tag.

Video: A demonstration of the Tastyle Single Serve Coffee Maker in action, highlighting its ease of use and various brewing capabilities.

6. MAINTENANCE

Cleaning:

- **Removable Parts:** The K-Cup holder, reusable ground coffee filter, patented tea holder, and drip tray are dishwasher safe or can be easily rinsed under running water.
- **Exterior:** Wipe the exterior of the coffee maker with a damp cloth. Do not use abrasive cleaners or immerse the unit in water.

Easy Maintenance of Accessories

Dishwasher safe or easily rinsed under the tap.



Image: A visual guide demonstrating the easy maintenance of accessories, showing them being cleaned in a dishwasher and rinsed under a tap.

Descaling:

Over time, mineral deposits can build up in your coffee maker, affecting performance. The built-in descaling reminder will alert you when descaling is needed.

1. **Reminder:** The "DESCALE" light will turn red when descaling is required.

2. **Process:** Fill the water reservoir with a descaling solution (e.g., vinegar and water mixture, or a commercial descaling agent as per product instructions). Place an empty mug on the drip tray.
3. **Start Descaling:** Press and hold the "HOT BREW" button for 3 seconds to initiate the descaling cycle.
4. **Rinse:** After the descaling cycle is complete, run 2-3 cycles with fresh, clean water to rinse out any remaining solution.



Image: The control panel of the coffee maker, indicating the Descal light that turns red when cleaning is needed, and the Hot Brew button used to start the descaling process.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Coffee maker does not turn on.	Not plugged in; power outage; circuit breaker tripped.	Ensure the power cord is securely plugged into a working outlet. Check your home's circuit breaker.
No water dispenses or brewing is slow.	Insufficient water in reservoir; mineral buildup (needs descaling); clogged needle.	Add fresh water to the reservoir. Perform a descaling cycle. Clean the needle using a paper clip if necessary (refer to manual for detailed cleaning).
Coffee grounds in cup.	Ground coffee filter overfilled; fine grind used with K-Cup adapter; K-Cup not properly sealed.	Do not overfill the ground coffee filter. Use a coarser grind for ground coffee. Ensure K-Cups are properly seated and sealed.
Water leaks from the machine.	Reservoir overfilled; drip tray not correctly placed; K-Cup/filter not seated properly.	Do not exceed the MAX fill line in the reservoir. Ensure the drip tray is correctly positioned. Verify K-Cup or filter is securely in place.
Beverage is not hot enough.	Machine needs descaling; cold cup used.	Perform a descaling cycle. Preheat your mug with hot water before brewing.

8. SPECIFICATIONS

- **Brand:** Tastyle
- **Model Name:** K320IT
- **Color:** Black

- **Product Dimensions:** 9.3"D x 4.6"W x 12"H
- **Item Weight:** 2.77 pounds
- **Coffee Maker Type:** Drip Coffee Machine
- **Style:** 4 Brew Styles (Hot, Bold, Over Ice Coffee, Over Ice Tea)
- **Coffee Input Type:** Ground, Pod (K-Cup compatible)
- **Operation Mode:** Fully Automatic
- **Voltage:** 120 Volts
- **Power Source:** AC adapter
- **Special Feature:** Splash-Proof Design, Descale Reminder, Built-in Cleaning
- **Included Components:** K-Cup Holder, Reusable Ground Coffee Filter, Patented Tea Holder, Removable Drip Tray
- **Certifications:** ETL Certified, BPA-Free Materials

9. WARRANTY & SUPPORT

One-Year Limited Warranty:

Your Tastyle Single Serve Coffee Maker K320IT is covered by a one-year limited warranty from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

Please retain your proof of purchase for warranty claims. Do not return the product to the retailer without first contacting customer support.

Customer Support:

For any questions, concerns, or warranty claims, please contact our customer support team:

- **Email:** support@mytastyle.com
- **Phone (US):** 1-972-467-4438
- **Hours:** Monday - Friday, 9:00 AM - 5:00 PM CST

Your browser does not support the video tag.

Video: An unboxing video showcasing all components included with the Tastyle Single Serve Coffee Maker, including the warranty card and recipe book.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question