Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Dreo DR-HPF006

Dreo TurboPoly Fan 306 User Manual

Model: DR-HPF006 | Brand: Dreo

1. Introduction

Thank you for choosing the Dreo TurboPoly Fan 306. This oscillating pedestal fan is designed to provide powerful and quiet air circulation for your home or office. With its advanced features, including adjustable height, multiple speed settings, and remote control, it ensures optimal comfort and convenience. Please read this manual thoroughly before use and retain it for future reference.



Image: The Dreo TurboPoly Fan 306, showcasing its sleek design, included remote control, and the innovative aroma pad feature.

2. Important Safety Instructions

- Always place the fan on a stable, flat surface to prevent tipping.
- Do not insert fingers or foreign objects into the fan grille when it is operating.
- Unplug the fan from the power outlet before cleaning, moving, or performing any maintenance.
- Keep the power cord away from heated surfaces.
- Do not operate the fan with a damaged cord or plug.
- This appliance is for indoor use only. Do not use outdoors or in wet conditions.
- Supervise children when the fan is in use.
- Ensure the voltage specified on the fan matches your local power supply.

3. Package Contents

Please check the package for the following items:

- Dreo TurboPoly Fan 306 (Main Unit)
- Pedestal Stand (Base and Pole)
- Remote Control
- User Manual
- Screwdriver (for assembly)

4. Product Overview

Familiarize yourself with the components of your Dreo TurboPoly Fan 306.



Image: Front view of the Dreo TurboPoly Fan 306, highlighting the fan head and grille.



Image: Side view of the Dreo TurboPoly Fan 306, showing the adjustable pole and stable base.



Image: Back view of the Dreo TurboPoly Fan 306, illustrating the control panel and rear grille.

5. Setup and Assembly

Follow these steps to assemble your Dreo TurboPoly Fan 306:

1. Carefully unpack all components from the box.

2. Attach the pedestal pole to the base using the provided screws and screwdriver. Ensure it is securely fastened.
3. Connect the fan head unit to the top of the assembled pole. Align the connectors and twist or click into place until secure.
4. Adjust the height of the fan by loosening the height adjustment knob on the pole, extending or retracting the inner pole, and then tightening the knob. The adjustable height range is approximately 33.8 to 41.3 inches.
5. Plug the power cord into a suitable electrical outlet.

6. Operating Instructions

Your Dreo TurboPoly Fan 306 can be controlled via the top panel or the included remote control.

6.1 Control Panel and Remote Control




Image: Overview of the fan's features, including the control panel buttons, remote control, adjustable height mechanism, and aroma pad container.

- **Power Button:** Turns the fan On/Off.
- **Speed Settings:** Cycle through 3 wind speeds (Low, Medium, High).
- **Oscillation Button:** Activates or deactivates 80° horizontal oscillation.
- **Mode Button:** Select between different modes (e.g., Normal, Auto). In Auto mode, the fan automatically adjusts

speed based on room temperature, increasing wind speed by 1 level for every 3°F temperature rise.

- **Timer Button:** Set a timer for automatic shutdown.
- **Mute Button (Remote Only):** Mutes the beep sounds for quiet operation, especially useful at night.

Your browser does not support the video tag.

Video: A short demonstration of the TurboPoly Fan 306's room-filling air circulation capabilities, highlighting its powerful airflow.

6.2 Airflow and Quietness

The fan features advanced airflow technology, circulating air up to 80 feet away and refreshing a room in under 3 minutes. Its bionic blade design ensures smooth air movement at an ultra-quiet 25dB, making it suitable for bedrooms and quiet environments.



Image: The Dreo fan effectively circulating air across a living space, demonstrating its wide coverage.



Image: The Dreo fan operating quietly in a bedroom, emphasizing its low noise level of 25dB for undisturbed comfort.

6.3 Adjustable Air Direction

In addition to 80° horizontal oscillation, the fan head can be manually tilted up to 90° vertically, allowing you to direct airflow precisely where needed. The adjustable height feature (33.8"–41.3") further enhances versatility.



Image: The fan demonstrating its 80-degree horizontal oscillation and 90-degree manual vertical tilt capabilities, allowing for precise airflow direction.

7. Maintenance and Cleaning

Regular cleaning helps maintain the fan's performance and extends its lifespan.

- Always unplug the fan before cleaning.

- The fan features a detachable design, allowing you to remove the front and rear grilles and the blade for thorough cleaning.
- Use a soft, damp cloth to wipe the exterior surfaces. For stubborn dirt, a mild soap solution can be used.
- Ensure all parts are completely dry before reassembling and operating the fan.
- **Aroma Pad:** The built-in aroma pad allows you to add fragrances. To clean or replace the pad, gently open the aroma pad container, remove the old pad, and insert a new one or clean the existing one.




Image: A visual guide to the fan's detachable components for easy cleaning, including the front and rear grilles and the fan blade, along with the aroma pad container.

8. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Fan does not turn on.	Not plugged in; Power outlet malfunction; Power button not pressed.	Ensure the fan is securely plugged into a working outlet. Press the power button.
Weak airflow.	Fan speed too low; Grille or blades are dirty.	Increase fan speed. Clean the fan grilles and blades as per maintenance instructions.
Fan is noisy.	Fan not on a flat surface; Loose parts; Obstruction.	Place the fan on a stable, flat surface. Check for any loose parts or obstructions and remove them.
Remote control not working.	Batteries are dead; Obstruction between remote and fan; Remote too far.	Replace the remote control battery (1 C battery required). Ensure there is no obstruction. Move closer to the fan.

9. Specifications

Feature	Detail
Brand	Dreo
Model Name	DR-HPF006
Color	Black
Electric Fan Design	Floor Fan
Power Source	AC
Product Dimensions	11.81"D x 11.81"W x 41.34"H
Noise Level	25 dB
Air Flow Capacity	885 Cubic Feet Per Minute
Voltage	230 Volts (AC)
Number of Power Levels	3
Control Method	Remote, Touch
Item Weight	13.35 pounds
Batteries Required	1 C battery (included for remote)

10. Warranty and Support

Dreo provides a limited warranty for this product. For detailed warranty information, please refer to the warranty card included with your purchase or contact Dreo customer support.

Customer Support:

Email: support@dreo.com

Phone: (888) 290-1688

Please have your model number (DR-HPF006) and purchase information ready when contacting support.

© 2025 Dreo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DQDQVTT3

More documents and user manuals: **https://manuals.plus/**