

[manuals.plus](#) /

› [Dreo](#) /

› [Dreo TurboPoly Fan 306 Instruction Manual \(DR-HPF006\)](#)

Dreo DR-HPF006

Dreo TurboPoly Fan 306 Instruction Manual (DR-HPF006)

Model: DR-HPF006

1. SETUP AND ASSEMBLY

The Dreo TurboPoly Fan 306 is designed for straightforward assembly. Follow these steps to get your fan ready for use:

- 1. Attach the Column to the Base:** Turn the column upside down. Align the column's bottom cutout onto the center jutting point of the base, then push it in.
- 2. Secure the Column:** Place the flat washer first, insert the screw, then tighten clockwise with the included screwdriver to secure the column to the base.
- 3. Insert Fan Body:** Turn the assembled base and column right side up. Insert the fan body to the column, and rotate clockwise until tightened.
- 4. Adjust Height:** Rotate the adjustment collar counterclockwise to adjust the height, then clockwise to secure it in place. The fan's height is adjustable between 33.8 and 41.3 inches.
- 5. Attach Remote Holder:** Attach the remote control holder below the fan head and pedestal joint for convenient storage.




Figure 1: Quick Start Guide for Dreo Pedestal Air Circulator Fan, illustrating the five-step assembly process from attaching the column to the base to securing the fan body and remote holder.

DREO | TurboPoly™ Fan 306

Room-filling Air Circulation



Figure 2: Fully assembled Dreo TurboPoly Fan 306, showcasing its adjustable height and sleek design.

The fan's detachable design allows for easy assembly and disassembly, simplifying initial setup and future maintenance.

2. OPERATING INSTRUCTIONS

The Dreo TurboPoly Fan 306 offers intuitive controls both on its top panel and via a convenient remote control. Familiarize yourself with the functions to optimize your comfort.

Control Panel & Remote Control Functions:

- **Power Button:** Turns the fan on/off. Long press for 10 seconds to restore factory settings.
- **Fan Speed Button (1-3 Levels):** Adjusts fan speed. Long press for 3 seconds to enter Auto Mode.
- **Oscillation Button:** Press to activate or deactivate horizontal oscillation (80°).
- **Mute/Unmute:** Silences or enables button beep sounds.
- **Timer:** Sets a timer for automatic fan shutdown.

Working Modes:

- **Normal Mode:** Fan runs at the fixed speed you select (1-3).
- **Auto Mode:** Fan automatically increases speed when room temperature rises and decreases speed when temperature is lower. This mode provides a seamless comfort experience, increasing 1 wind speed whenever room temperature goes up 3°F.

Adjusting Airflow Direction:

In addition to 80° horizontal oscillation, the fan head can be manually adjusted vertically up to 90° (0°/15°/30°/45°/60°/75°/90°) to direct airflow precisely where needed.



Figure 3: Detailed guide to the fan's control panel and remote control, showing buttons for power, speed, oscillation, mute, and timer, along with explanations of Normal and Auto modes.

Quiet Operation:

The Dreo TurboPoly Fan 306 operates at a low noise level of only 25dB, making it quieter than a whisper. This ultra-quiet performance ensures minimal disturbance, ideal for bedrooms, offices, or any space requiring peaceful air circulation.

Official Product Video: How to Turn on Dreo Fan TWO WAYS!

Your browser does not support the video tag.

Video 1: Demonstrates how to power on the Dreo fan using both the integrated control panel and the remote control, highlighting speed and oscillation functions.

3. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and longevity of your Dreo TurboPoly Fan 306. The fan features a detachable design for easy access to components.

Cleaning the Fan Components:

- 1. Disassemble the Front Grill:** Tilt the fan head all the way back. Locate the screw on the bottom of the fan head and remove it using a Phillips screwdriver. Twist the front grill counter-clockwise until the notch aligns with the open circle indicator, then gently pull it off.
- 2. Remove the Fan Blade:** Twist the fan blade cap counter-clockwise to loosen and remove it. Then, carefully pull the fan blade off the motor shaft.
- 3. Remove the Rear Grill:** Locate the two buttons on the sides of the motor housing. Push them both towards the center and twist the rear grill counter-clockwise to detach it.
- 4. Clean Components:** The front grill, fan blade, and rear grill can be washed with mild soap and water. Ensure all soap residue is thoroughly rinsed off and components are completely dry before reassembly.
- 5. Clean Motor Housing:** Wipe down the motor housing carefully with a damp cloth, ensuring no water or cleaning solution enters the motor.
- 6. Reassemble:** Follow the disassembly steps in reverse order. Ensure all parts are securely reattached and the front grill is locked into place by twisting it clockwise until the notch aligns with the solid circle indicator. Replace the screw on the bottom of the fan head.

Aroma Pad Maintenance:

The fan includes a built-in aroma pad for adding fragrances. To access it, twist the center cap on the front grill counter-clockwise and pull it out. The aroma pad can be cleaned by rinsing it under water. Ensure it is completely dry before reinserting or adding essential oils.



Figure 4: Illustration of the fan's detachable front and rear grills, and fan blade, highlighting the ease of disassembly for thorough cleaning.



Figure 5: Close-up of the fan's aroma pad container, showing how to add fragrances for a fresher air experience.

Official Product Video: Let Me Show You How to Take it Completely Apart and Clean It!

Your browser does not support the video tag.

Video 2: A step-by-step demonstration on how to fully disassemble the Dreo fan for thorough cleaning of its components, including the front grill, fan blades, and rear grill.

4. TROUBLESHOOTING

If you encounter any issues with your Dreo TurboPoly Fan 306, please refer to the following common troubleshooting tips:

- **Fan does not turn on:**

- Ensure the power cord is securely plugged into a working electrical outlet.
- Check if the power button on the fan or remote control has been pressed.
- Verify there is no power outage in your area.

- **Weak or no airflow:**

- Increase the fan speed setting.
- Ensure the fan grills and blades are clean and free from dust or obstructions. Refer to the Maintenance section for cleaning instructions.
- Check if the fan head is properly tilted and oscillating to cover the desired area.

- **Unusual noise or rattling:**

- Ensure all fan components (grills, blades, base) are securely assembled and tightened.
- Check for any foreign objects caught within the fan blades or grills.
- If the noise persists after checking these points, contact Dreo Support.

- **Remote control not working:**

- Check and replace the battery in the remote control (1 C battery required, included).
- Ensure there are no obstructions between the remote control and the fan's receiver.
- Try operating the fan using the control panel directly to confirm fan functionality.

For further assistance, please contact Dreo Support using the information provided in the Warranty & Support section.

5. SPECIFICATIONS

| Feature | Detail |
|-------------------------|-----------------------------|
| Brand | Dreo |
| Model Name | DR-HPF006 |
| Color | White |
| Electric Fan Design | Floor Fan |
| Power Source | AC |
| Product Dimensions | 11.81"D x 11.81"W x 41.34"H |
| Adjustable Height Range | 33.8" - 41.3" |

| | |
|------------------------|---|
| Room Type | Bedroom, Home Office, Kitchen, Living Room |
| Special Features | Adjustable Height, Adjustable Tilt, Oscillating, Remote Controlled, Timer |
| Recommended Uses | Air Circulation |
| Noise Level | 25 Decibels |
| Wattage | 60 watts |
| Voltage | 120.0 V |
| Switch Type | Push Button |
| Item Weight | 11.44 pounds (5.2 Kilograms) |
| Included Components | Remote |
| Indoor/Outdoor Usage | Indoor |
| Control Method | Remote, Touch |
| Number of Power Levels | 4 |
| Motor Type | Brushless |
| UPC | 810142852029 |
| Batteries | 1 C battery required (included) |

6. WARRANTY & SUPPORT

Dreo is committed to providing excellent customer support and product satisfaction. If you have any questions, concerns, or require assistance with your Dreo TurboPoly Fan 306, please reach out to our support team.

DREO Support Center:

- **Email:** support@dreo.com
- **Website:** www.dreo.com
- **Phone:** (888) 290-1688 (Mon-Fri, 9:00 AM - 5:00 PM PST/PDT)

Extend Your Warranty:

You can extend your product warranty to 30 months for free. Scan the QR code on the Quick Start Guide or visit dreo.com/warranty to register your product.