

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Goldtouch](#) /

› [Goldtouch Elite Numeric Keypad User Manual](#)

Goldtouch GTC-ELITE

Goldtouch Elite Numeric Keypad User Manual

Model: GTC-ELITE

PRODUCT OVERVIEW

The Goldtouch Elite Numeric Keypad is a compact, wired numeric keypad designed to enhance data entry efficiency for both PC and Mac users. It features industry-leading Cherry MX Red mechanical keys for a tactile and responsive typing experience. Its plug-and-play USB connectivity ensures easy setup and immediate use.



Figure 1: Top-down view of the Goldtouch Elite Numeric Keypad, showcasing its compact design and key layout.

SETUP

The Goldtouch Elite Numeric Keypad is designed for simple plug-and-play installation. No additional drivers are typically required for basic functionality on compatible operating systems.

Connecting the Keypad

1. Locate the USB-A to USB-C cable included with your keypad.
2. Connect the USB-C end of the cable to the USB-C port on the Goldtouch Elite Numeric Keypad.
3. Connect the USB-A end of the cable to an available USB-A port on your computer (PC or Mac).
4. For Mac users, ensure the switch on the side of the keypad is set to 'MAC'. For PC users, set it to 'PC'.



Figure 2: The Goldtouch Elite Numeric Keypad connected via its USB-A to USB-C cable.



Figure 3: Side view illustrating the Mac/PC compatibility switch and the USB-C port for connection.

Your operating system should automatically detect the keypad, and it will be ready for use.

OPERATING INSTRUCTIONS

The Goldtouch Elite Numeric Keypad functions as a standard numeric input device, compatible with most applications requiring numerical data entry.

Basic Keypad Functions

- **Numeric Input:** Use the number keys (0-9) for numerical data entry.
- **Arithmetic Operations:** Utilize the +, -, *, / keys for calculations.
- **Enter Key:** Functions as a standard Enter key for confirming input or moving to the next field.
- **Num Lock:** The 'NUM' key toggles the numeric lock function, enabling or disabling the numeric input. An indicator light on the keypad will show its status.
- **Special Keys:** Keys like 'ESC', 'TAB', 'DEL', 'INS', 'HOME', 'END', 'PGUP', 'PGDN' provide additional functionality commonly found on full-size keyboards.

PC and Mac Compatibility

The keypad includes a physical switch to optimize its functionality for either PC or Mac operating systems. Ensure this switch is set correctly for your system to ensure proper key mapping and performance.

The Elite Duo

The Goldtouch Elite Numeric Keypad is the perfect companion for the Elite Keyboard.

Position it next to your keyboard when doing data entry, and easily swap it out with your mouse when not in use.



Goldtouch

If It Isn't **Adjustable**, It Isn't **Ergonomic**.™

Figure 4: The Goldtouch Elite Numeric Keypad positioned for use alongside an ergonomic keyboard, demonstrating its integration into a workspace.

MAINTENANCE

Proper maintenance will extend the lifespan of your Goldtouch Elite Numeric Keypad.

- Cleaning:** Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution to wipe the surface of the keypad. Avoid harsh chemicals, abrasive cleaners, or excessive moisture.
- Dust Removal:** Use compressed air to remove dust and debris from between the keys.
- Storage:** When not in use for extended periods, store the keypad in a clean, dry environment away from extreme temperatures.
- Cable Care:** Avoid sharp bends or kinks in the USB cable to prevent internal damage.

TROUBLESHOOTING

If you encounter issues with your Goldtouch Elite Numeric Keypad, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Keypad not recognized by computer.	Loose USB connection, incorrect Mac/PC switch setting, faulty USB port.	<ul style="list-style-type: none">Ensure the USB cable is securely connected to both the keypad and the computer.Try connecting the keypad to a different USB port on your computer.Verify the Mac/PC switch on the side of the keypad is set to the correct operating system.Restart your computer.

Problem	Possible Cause	Solution
Keys are not responding or typing incorrect characters.	Num Lock is off, software conflict, debris under keys.	<ul style="list-style-type: none"> Press the 'NUM' key to ensure Num Lock is active (check indicator light). Clean the keypad to remove any debris that might be obstructing key presses. Test the keypad on another computer to rule out software issues.
Keypad disconnects intermittently.	Loose cable, power management settings, faulty cable.	<ul style="list-style-type: none"> Ensure the USB cable is firmly connected. Check your computer's power management settings to ensure USB ports are not being turned off to save power. Try using a different USB-C to USB-A cable if available.

SPECIFICATIONS

Detailed technical specifications for the Goldtouch Elite Numeric Keypad:

Model Number	GTC-ELITE
Product Dimensions	5.75" L x 3.5" W x 1" H (14.6 cm x 8.9 cm x 2.5 cm)
Item Weight	8 ounces (226.8 grams)
Connectivity Technology	Wired USB-A (via USB-C port on keypad)
Key Type	Cherry MX Red Mechanical Keys
Compatible Devices	Laptop, PC (Windows), Mac
Color	Black
Material	Plastic
Included Components	USB-A to USB-C cable

Elite Numeric Keypad



PC+Mac users can use the included USB-A to USB-C cable.

PC+Mac users with USB-C only ports can use a straight USB-C to USB-C cable (not included).

Goldtouch
Type Smarter

Figure 5: Dimensional diagram of the Goldtouch Elite Numeric Keypad, including width, depth, height, weight, and cable length.

WARRANTY AND SUPPORT

Goldtouch products are designed for durability and performance. For information regarding product warranty, please refer to the warranty card included with your purchase or visit the official Goldtouch website.

For technical support, troubleshooting assistance beyond this manual, or to inquire about replacement parts, please contact Goldtouch customer service through their official support channels. Contact information can typically be found on the Goldtouch website or on the product packaging.

Online Resources:

- [Goldtouch Support Page](#)
- [Contact Goldtouch](#)