

[Manuals.plus](#) /

> [RATION](#) /

> RATION Pre-Heat Glow Plug Instruction Manual for Iseki Tractors (Models TX1300, TX1410, TX1500, TX1510)

RATION TX1300, TX1410, TX1500, TX1510

RATION Pre-Heat Glow Plug Instruction Manual

For Iseki Tractor Models: TX1300, TX1410, TX1500, TX1510

Part Number: 5650-040-1621-0

1. INTRODUCTION

This manual provides essential information for the proper installation, operation, and maintenance of your RATION Pre-Heat Glow Plug. Designed for specific Iseki Tractor models, this glow plug is a critical component for ensuring reliable engine starting, especially in cold weather conditions. Please read this manual thoroughly before installation and use to ensure safety and optimal performance.



Image 1: The RATION Pre-Heat Glow Plug. This component is designed to heat the combustion chamber, aiding in engine ignition.

2. COMPATIBILITY

The RATION Pre-Heat Glow Plug (Part Number: 5650-040-1621-0) is specifically designed for the following Iseki Tractor models:

- Iseki TX1300
- Iseki TX1410
- Iseki TX1500
- Iseki TX1510

Always verify the part number and compatibility with your tractor's specifications before installation.

3. PRODUCT FEATURES

- Designed for Iseki Tractor models TX1300, TX1410, TX1500, and TX1510.
- Ensures smooth engine starting in cold weather conditions.
- Contributes to improved engine performance and fuel efficiency.
- Precision-engineered for reliable operation.

4. SAFETY INFORMATION

WARNING: Always prioritize safety when working with tractor engines and electrical systems. Failure to follow safety precautions can result in serious injury or damage to equipment.

- Ensure the tractor engine is completely off and cooled down before beginning any work.
- Disconnect the battery's negative terminal to prevent accidental starting or electrical shorts.
- Wear appropriate personal protective equipment (PPE), including safety glasses and gloves.
- Avoid touching hot engine components.
- Keep children and unauthorized personnel away from the work area.
- If you are unsure about any step, consult a qualified mechanic or your tractor's service manual.

5. SETUP AND INSTALLATION

Follow these general steps for replacing a glow plug. Refer to your specific Iseki Tractor service manual for detailed instructions and torque specifications.

1. **Prepare the Tractor:** Park the tractor on a level surface, engage the parking brake, and turn off the engine. Allow the engine to cool completely. Disconnect the negative (-) terminal of the battery to prevent electrical hazards.
2. **Locate Glow Plugs:** Identify the location of the glow plugs on your tractor's engine. They are typically found on the cylinder head.
3. **Remove Wiring:** Carefully disconnect the electrical wiring or bus bar from the top of the glow plug. Note the orientation for reassembly.
4. **Remove Old Glow Plug:** Using an appropriately sized glow plug wrench or socket, carefully unscrew the old glow plug. Apply steady pressure to avoid stripping the threads.
5. **Inspect and Clean:** Inspect the glow plug bore for carbon buildup or debris. Clean if necessary, ensuring no foreign material falls into the combustion chamber.
6. **Install New Glow Plug:** Hand-thread the new RATION glow plug into the cylinder head to ensure it starts correctly. Once hand-tight, use a torque wrench to tighten it to the manufacturer's specified torque setting. **Do not overtighten**, as this can damage the glow plug or cylinder head threads.
7. **Reconnect Wiring:** Reattach the electrical wiring or bus bar to the new glow plug, ensuring a secure

connection.

8. **Reconnect Battery:** Reconnect the negative (-) battery terminal.
9. **Test:** Start the tractor and check for proper operation and any warning lights.

6. OPERATING INSTRUCTIONS

The RATION Pre-Heat Glow Plug operates automatically as part of your tractor's starting system. When starting the engine, especially in cold conditions:

- Turn the ignition key to the