

[Manuals.plus](#) /

› [DERCASS](#) /

› DERCASS Platform Bed with Storage, Charging Station, and Upholstered Headboard (Full, Grey) - Instruction Manual

DERCASS GX002107A

DERCASS Platform Bed with Storage, Charging Station, and Upholstered Headboard (Full, Grey) - Instruction Manual

Model: GX002107A | Brand: DERCASS

INTRODUCTION

Thank you for choosing the DERCASS Platform Bed. This manual provides essential information for the safe assembly, operation, and maintenance of your new bed frame. Please read these instructions carefully before beginning assembly and retain them for future reference.



Overall view of the DERCASS Platform Bed, showcasing its design with integrated storage and upholstered headboard.


SAFETY INFORMATION

- Always follow assembly instructions carefully. Incorrect assembly can lead to instability and injury.
- Ensure all bolts and screws are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not exceed the recommended weight capacity of 400 lbs for the bed.
- Keep small parts and packaging materials away from children during assembly to prevent choking hazards.
- Use on a level surface to prevent tipping.
- Do not stand on the bed frame or use it as a ladder.
- For the integrated charging station, ensure the power cord is not pinched or damaged. Do not overload the outlets.

INCLUDED COMPONENTS

Before assembly, verify that all components listed below are present in your package. If any parts are missing or damaged, please contact customer support.

- Platform Bed Frame (Pine Wood + MDF construction)
- Upholstered Headboard (Linen fabric)
- Storage Shelves (Integrated into headboard/side structure)
- Two Under-bed Drawers
- Charging Station (with 2 standard outlets & 2 USB ports)
- Bed Slats (10 pieces)
- Assembly Hardware (screws, bolts, tools if included)
- Instruction Manual




View of the bed frame's internal structure, including the slat system and integrated storage compartments.

SETUP AND ASSEMBLY INSTRUCTIONS

Assembly is required for this platform bed. It is recommended to have two people for assembly. All necessary parts and a step-by-step installation manual are included in your package. Please follow the provided manual for detailed instructions.

1. **Unpack and Organize:** Carefully unpack all components and lay them out on a clean, soft surface to prevent scratches. Identify all parts against the included parts list.
2. **Assemble the Main Frame:** Begin by connecting the main frame components as per the detailed diagrams in your separate assembly manual. Ensure all connections are secure but do not fully tighten bolts until the frame is mostly assembled.
3. **Install Storage Shelves and Headboard:** Attach the integrated storage shelves and the upholstered headboard to the main frame. Pay attention to the orientation of the headboard.
4. **Insert Bed Slats:** Place the 10 bed slats evenly across the bed frame. Secure them according to the instructions to ensure proper mattress support.
5. **Assemble and Insert Drawers:** Assemble the two under-bed drawers. Once assembled, slide them into their designated positions under the bed frame.
6. **Connect Charging Station:** Integrate the charging station into its designated slot within the storage area. Ensure the power cord is routed safely and is accessible for connection to a wall outlet.
7. **Final Tightening:** Once all components are in place, go back and fully tighten all bolts and screws. Do not overtighten.

SIZE:INCH



Dimensional diagram of the DERCASS Platform Bed, providing key measurements for assembly and placement.



OPERATING INSTRUCTIONS

Charging Station

The integrated charging station provides convenient access to power for your electronic devices. It includes two standard plug outlets and two USB ports.

- Connect the charging station's power cord to a functional wall outlet.
- Plug your devices into the available outlets or USB ports.
- Avoid overloading the charging station. Do not plug in high-power appliances.
- Ensure the power cord is not damaged or pinched by the bed frame.




Detail of the charging station, providing power and USB connectivity.

Storage Drawers and Shelves

The bed features multiple storage options to help keep your bedroom organized.

- **Under-bed Drawers:** Gently pull the drawers out to access storage space for bedding, clothing, or other items. Push them back in until fully closed.
- **Integrated Shelves:** Use the shelves in the headboard and side structure for books, decorative items, or personal belongings.
- Do not overload drawers or shelves beyond their reasonable capacity to prevent damage.



The under-bed drawers shown in an open position, illustrating accessible storage.

MAINTENANCE

- **Cleaning:** Wipe the wood and MDF surfaces with a dry cloth. For the upholstered headboard, use a soft, damp cloth with mild soap if necessary, and blot dry. Avoid harsh chemicals or abrasive cleaners.
- **Hardware Check:** Periodically inspect all bolts, screws, and connections to ensure they remain tight. Re-tighten as needed to maintain stability and safety.
- **Charging Station:** Keep the charging station free of dust and debris. Do not attempt to disassemble or repair the charging unit yourself.

TROUBLESHOOTING

- **Bed feels wobbly:** Ensure all assembly hardware is fully tightened. Check that the bed is on a level surface.
- **Drawers do not slide smoothly:** Check for any obstructions in the drawer glides. Ensure the drawers were assembled correctly and are aligned.
- **Charging station not working:** Verify the power cord is securely plugged into both the charging station and a functional wall outlet. Check if the wall outlet is working by plugging in another device. Do not attempt to repair the charging station yourself.
- **Missing parts or damaged components:** Refer to the "Included Components" section. If parts are missing or damaged upon arrival, contact customer support immediately.

PRODUCT SPECIFICATIONS

Brand	DERCASS
Model Number	GX002107A
Size	Full
Color	Grey
Material	Linen, MDF, Pine Wood
Overall Product Dimensions	88.3"L x 65.1"W x 29.3"H
Bed Weight Capacity	400 lbs
Number of Bed Slats	10
Recommended Mattress Thickness	8 inches
Assembly Required	Yes
Special Features	Charging Station, Drawers, Storage Shelves, Upholstered Headboard, No Box Spring Needed
Item Weight	144 pounds
UPC	717073464423

WARRANTY INFORMATION

Specific warranty details for the DERCASS Platform Bed are typically provided with your purchase documentation. Please refer to the warranty card or contact the retailer where the product was purchased for comprehensive information regarding warranty coverage and terms.

CUSTOMER SUPPORT

If you have any questions regarding the assembly, operation, or maintenance of your DERCASS Platform Bed, or if you encounter any issues, please do not hesitate to contact our customer support team. We are committed to assisting you and will do our best to resolve any concerns.

Please have your model number (GX002107A) and purchase information ready when contacting support.
For contact information, please refer to your purchase receipt or the retailer's website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DQJMR3SV>

More documents and user manuals: **<https://manuals.plus/>**