

[Manuals.plus](#) /

› [DERCASS](#) /

› DERCASS Platform Bed with Storage, Charging Station, and Upholstered Headboard (Twin, Cream) - Instruction Manual

DERCASS GX002107A

DERCASS Platform Bed Instruction Manual

Model: GX002107A | Brand: DERCASS

IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before beginning assembly and use. Keep this manual for future reference. Failure to follow these instructions may result in injury or damage to the product.

- Ensure all parts are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Assemble the bed on a soft, clean surface to prevent scratches.
- Tighten all fasteners securely, but do not overtighten. Periodically check and retighten fasteners as needed.
- Do not allow children to climb on or play with the bed frame during assembly or use.
- Distribute weight evenly on the bed. The maximum weight capacity for this Twin bed is 250 lbs.
- Only use the charging station for compatible electronic devices. Do not overload the outlets.

PACKAGE CONTENTS

Your DERCASS Platform Bed is shipped in two packages. Please verify that all components are present before starting assembly. A detailed parts list and hardware pack are included within the packaging.

- Bed Frame Components (Pine Wood, MDF)
- Upholstered Headboard (Linen, High-Density Foam)
- Bed Slats (10 pieces)
- Storage Drawers (2 pieces)
- Charging Station Unit (2 standard outlets, 2 USB ports)
- Assembly Hardware and Tools (if applicable)
- Step-by-step Installation Manual

SETUP AND ASSEMBLY

Assembly is required for this platform bed. Please refer to the separate, detailed installation manual included in your package for step-by-step instructions and diagrams. Ensure you have adequate space and any necessary tools before beginning.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a protected surface.
2. **Identify Parts:** Match each component with the parts list provided in the installation manual.
3. **Assemble Frame:** Follow the manual to construct the main bed frame, ensuring all connections are secure.
4. **Install Storage Shelves:** Attach the integrated storage shelves as directed.
5. **Insert Bed Slats:** Place the 10 bed slats evenly across the frame. This bed does not require a box spring.
6. **Attach Headboard:** Secure the upholstered headboard to the frame.
7. **Install Drawers:** Assemble and insert the two under-bed storage drawers.
8. **Connect Charging Station:** Integrate the charging station into the designated shelf area and plug it into a wall outlet.

SIZE:INCH




Image: Dimension diagram of the DERCASS Platform Bed, illustrating the overall length of 88.3 inches, width of 49.8 inches, and height of 29.5 inches, along with detailed measurements for the storage shelves, drawers, and headboard.



Image: Front view of the DERCASS Platform Bed, showcasing the two under-bed storage drawers and the integrated headboard with shelves and charging station. The bed slats are visible.



Image: Angled view of the DERCASS Platform Bed, providing a comprehensive look at the integrated side storage unit, the upholstered headboard, and the two pull-out drawers beneath the bed frame.

OPERATING INSTRUCTIONS

This platform bed is designed for comfort and convenience with multiple integrated features.

- **Charging Station:** The headboard features a built-in charging station with 2 standard power outlets and 2 USB ports. Plug the bed's power cord into a wall outlet to activate. Use these ports to conveniently charge your electronic devices while relaxing in bed.
- **Storage Shelves:** Utilize the integrated shelves within the headboard and side unit for storing books, decor, or personal items.
- **Under-Bed Drawers:** The two pull-out drawers located under the bed provide additional storage space for bedding, clothing, or other belongings. Gently pull the handles to open and push to close.
- **Upholstered Headboard:** The padded, linen-upholstered headboard offers comfortable back support for reading or watching television.



Image: Close-up view of the DERCASS Platform Bed's upholstered headboard, showing the tufted linen fabric and the integrated charging station with power outlets and USB ports within the shelf.



Image: Detailed view of the side storage shelves on the DERCASS Platform Bed, illustrating the multi-level compartments suitable for various items.



Image: An open under-bed storage drawer from the DERCASS Platform Bed, showing its interior capacity for storing personal belongings.

MAINTENANCE

Proper care will ensure the longevity and appearance of your DERCASS Platform Bed.

- **Cleaning:** Wipe the wood and MDF surfaces with a dry, soft cloth. For the upholstered headboard, use a soft brush or vacuum with an upholstery attachment to remove dust. Spot clean any stains on the fabric with a mild upholstery cleaner, testing on an inconspicuous area first.
- **Fasteners:** Periodically check all bolts and screws to ensure they remain tight. Retighten as necessary to maintain stability.
- **Charging Station:** Keep the charging ports free of dust and debris. Do not expose the charging station to liquids.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, strong detergents, or chemical sprays on any part of the bed, as these can damage the finish or fabric.

TROUBLESHOOTING

If you encounter any issues with your DERCASS Platform Bed, please refer to the following common solutions or contact customer support.

- **Bed feels wobbly:** Check all assembly bolts and screws. Ensure they are fully tightened. Verify that the bed is on a level surface.
- **Drawers do not slide smoothly:** Ensure the drawer slides are properly aligned and free of obstructions. Check for any loose screws on the drawer runners.
- **Charging station not working:** Verify that the bed's power cord is securely plugged into a functional wall outlet. Check if the devices you are trying to charge are compatible and their cables are working.
- **Missing parts:** If you find any parts missing during assembly, do not proceed. Contact customer support immediately for assistance.

SPECIFICATIONS

Model Number	GX002107A
Size	Twin
Color	Cream
Product Dimensions	88.3"L x 49.8"W x 29.3"H
Material	Pine Wood, MDF, Linen
Weight Capacity	250 lbs
Recommended Mattress Thickness	8 inches
Number of Bed Slats	10
Special Features	Charging Station (2 outlets, 2 USB), Storage Shelves, 2 Drawers, Upholstered Headboard, No Box Spring Required
Assembly Required	Yes
UPC	717073464430

WARRANTY INFORMATION

Specific warranty details for the DERCASS Platform Bed are typically provided at the point of purchase or within the product packaging. Please consult your retailer or the manufacturer's official documentation for comprehensive warranty terms and conditions. Keep your proof of purchase for any warranty claims.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or encounter any issues not covered in this manual, please do not hesitate to contact DERCASS customer support. Refer to the contact information provided with your purchase or visit the official DERCASS website for support options.

© 2024 DERCASS. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DQJN6L4D>

More documents and user manuals: <https://manuals.plus/>

