

## Vivo Y300 5G V2416 / Vivo V40 Lite 5G Compatible Flip Case

### Instruction Manual

#### GENERIC FLIP CASE FOR VIVO Y300 5G V2416 / VIVO V40 LITE 5G

Model: Vivo Y300 5G V2416 / Vivo V40 Lite 5G Compatible Flip Case

#### Introduction

Thank you for choosing the Generic Slim Fit Card Holder Flip Stand Magnetic Closure Case. This protective case is designed to provide comprehensive protection and enhanced functionality for your Vivo Y300 5G V2416 or Vivo V40 Lite 5G smartphone. It features a durable construction, integrated card slots, a convenient kickstand, and a secure magnetic closure.

#### Setup

1. **Unpack the Case:** Carefully remove the flip case from its packaging.

2. **Insert Your Phone:**

- Open the flip cover of the case.
- Align your Vivo Y300 5G V2416 or Vivo V40 Lite 5G phone with the internal TPU soft shell.
- Gently press the phone into the shell, ensuring all edges are securely seated. Verify that all ports, buttons, and camera cutouts align correctly with the case openings.
- Close the flip cover.



Image: Open case showing the internal TPU shell for phone insertion.



Image: Phone securely installed in the flip case, held by hand.

## Operating Instructions

### 1. Using the Flip Cover and Magnetic Closure:

- To open the case, gently lift the front cover.
- To close, simply fold the front cover back over the screen; the integrated magnetic closure will secure it in place.

### 2. Utilizing the Card Holder Function:

- Open the flip cover to reveal the interior.
- Locate the card slots on the inside of the front cover. Insert your ID, credit cards, or other small items into the designated slots.

### 3. Activating the Kickstand Function:

- Open the flip cover.
- Fold the back of the case to create a triangular stand. Position your phone horizontally for hands-free viewing of videos or video calls.



Image: Case configured as a kickstand for horizontal viewing.

The case features precision cutouts for the camera, charging port, and speakers, ensuring full access to all phone functions without removing the case.



Image: Close-up of the case showing precise speaker cutout.

## Maintenance

- **Cleaning:** Wipe the exterior PU leather surface with a soft, slightly damp cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture. For the internal TPU shell, a dry or lightly damp cloth can be used.
- **Storage:** When not in use, store the case in a cool, dry place away from direct sunlight to prevent material degradation.

