

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Bissell](#) /
- › [BISSELL Little Green Mini Cordless Deep Cleaner User Manual](#)

Bissell 4015

BISSELL Little Green Mini Cordless Portable Carpet and Upholstery Deep Cleaner

Model: 4015 | Brand: Bissell

IMPORTANT SAFETY INFORMATION

Please read all instructions before using your BISSELL Little Green Mini Cordless cleaner. Failure to follow the warnings and instructions may result in electric shock, fire, and/or serious injury.

- Always use a properly grounded outlet.
- Do not immerse the unit in water or use it in wet conditions.
- Use only BISSELL cleaning formulas designed for this machine to prevent damage to internal components.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Unplug from outlet when not in use and before cleaning or servicing.
- Store the appliance indoors in a dry place.

PRODUCT OVERVIEW

The BISSELL Little Green Mini Cordless is a lightweight and portable deep cleaner designed for effective spot and stain removal on carpets, upholstery, and car interiors. Its cordless design offers freedom of movement, allowing you to tackle messes anywhere.

Key Features:

- **Cordless Freedom:** Lightweight and compact at only 7 lbs, providing easy access to messes indoors and outdoors without cord limitations.
- **BatteryBoost+ Technology:** Offers up to 20 minutes of cordless cleaning, with an energy-efficient mode to preserve battery life.
- **Strong Suction:** Effectively extracts tough pet stains, embedded dirt, and everyday spills.
- **HydroRinse Self-Cleaning Tool:** Simplifies hose maintenance by allowing easy flushing after use.

- **Included Accessories:** Comes with a 4-inch Tough Stain Tool with Removable Lens and an 8 oz. BISSELL Little Green Formula.

Components:

Familiarize yourself with the main components of your Little Green Mini Cordless cleaner:

- Clean Water Tank (for water and cleaning formula)
- Dirty Water Tank (for collected dirty water)
- Power Button
- Battery Indicator Button
- BatteryBoost+ Mode Button
- Flexible Hose
- 4-inch Tough Stain Tool
- HydroRinse Self-Cleaning Tool



The BISSELL Little Green Mini Cordless cleaner, shown with its included 4-inch Tough Stain Tool, HydroRinse Self-Cleaning Tool, and an 8 oz. bottle of BISSELL Little Green OXY Spot & Stain formula.



This image illustrates the compact design of the Little Green Mini Cordless, emphasizing its portability and the integrated storage for the 4-inch Tough Stain Tool and HydroRinse Self-Cleaning Tool.

SETUP

Charging the Battery:

Before first use, fully charge the unit. Connect the charging cable to the charging port on the unit. The battery indicator lights will illuminate to show charging progress. A full charge provides up to 20 minutes of run time in BatteryBoost+ mode.

BISSELL

BatteryBoost+ Technology

longer battery life

BISSELL
LITTLE GREEN
MINI CORDLESS

next level cleaning

The cleaner features BatteryBoost+ Technology for extended battery life, providing up to 20 minutes of cleaning power on a single charge.

Filling the Clean Water Tank:

1. Remove the clean water tank from the unit.
2. Unscrew the cap.
3. Fill with water up to the indicated water line (marked with a water droplet icon).
4. Add the BISSELL Little Green cleaning formula up to the indicated formula line (marked with a bottle icon). Do not exceed the maximum temperature of 140°F (60°C) for water.
5. Securely screw the cap back on.
6. Place the filled tank back into the unit, ensuring it clicks into place.



The included OXY Spot & Stain formula is designed to remove tough stains, eliminate odors, and provide StainProtect™ Technology for future stain protection.

Attaching the Cleaning Tool:

Attach your desired cleaning tool (e.g., 4-inch Tough Stain Tool) to the end of the hose grip until it clicks securely into place.

OPERATING INSTRUCTIONS

Powering On:


Press the power button to turn on the machine. It will start in Standard Mode for quick spot and stain removal, offering a run time of up to 15 minutes.

Cleaning Modes:

- **Standard Mode:** Ideal for quick spot and stain removal. Run time: Up to 15 minutes.
- **BatteryBoost+ Mode:** For cleaning larger areas such as car interiors, stairs, or full pieces of furniture. Press the BatteryBoost+ button to activate. The light will flash during use; wait for the light to turn solid and the motor to idle before resuming cleaning. Run time: Up to 20 minutes.

Cleaning Process:

1. Hold the cleaning tool approximately one inch above the stained surface.
2. Press the spray trigger to apply cleaning solution to the stain.
3. Gently scrub the stained area with the brush on the cleaning tool.
4. Release the spray trigger and apply downward pressure on the tool while pulling it slowly over the stained area to suction up the dirty solution.
5. Repeat steps as necessary until the stain is removed.



The cleaner effectively sprays cleaning solution, scrubs away dirt with its brush, and suctions up the dirty liquid, leaving surfaces clean.



Its compact size and powerful suction make it ideal for cleaning large areas like car interiors or entire couches, demonstrating 'mega portability' and 'mega power'.

MAINTENANCE

Emptying and Cleaning the Dirty Water Tank:

After each use, or when the dirty water tank reaches its maximum fill line, it must be emptied and rinsed.

1. Remove the dirty water tank from the unit.
2. Carefully open the tank and pour out the dirty water.
3. Rinse the tank thoroughly with clean water.
4. Allow the tank to air dry before reattaching it to the unit.


Cleaning the Hose with HydroRinse Tool:

To prevent odors and maintain optimal performance, use the HydroRinse Self-Cleaning Tool to flush the hose after each use.

1. Ensure the clean water tank has sufficient clean water.
2. Attach the HydroRinse Self-Cleaning Tool to the end of the hose.
3. Place the tool into a sink or bucket.


- Turn on the machine and press the spray trigger on the hose grip to flush clean water through the hose. Continue until the water running through the tool is clear.
- Turn off the machine and detach the HydroRinse tool.

What's in the box?




Little Green™ with OXY Formula (8 oz)

Trial-sized formula permanently removes tough stains, eliminates odors, & protects against future stains with StainProtect® Technology.



4" Tough Stain Tool

Spray, scrub & suction away tough spots, stains, and spills throughout your home and more.



HydroRinse Self-Cleaning Hose Tool

Easily rinse out your machine's hose after each use.

The product package includes the Little Green™ with OXY Formula (8 oz.) for permanent stain removal and odor elimination, the 4-inch Tough Stain Tool for spraying, scrubbing, and suctioning, and the HydroRinse Self-Cleaning Hose Tool for easy hose maintenance.

TROUBLESHOOTING

BatteryBoost+ Light Flashes During Use:

If the BatteryBoost+ light flashes during use, it indicates the machine is recalibrating. Wait for the light to turn solid and the motor to idle before resuming cleaning. This is normal operation.


For other issues, refer to the full user manual or contact BISSELL customer support.

SPECIFICATIONS

Attribute	Detail
Brand	Bissell
Model Name	Little Green Mini Cordless
Model Number	4015
Power Source	Battery Powered
Item Weight	7 Pounds
Product Dimensions	11"D x 19.25"W x 13.4"H
Clean Water Capacity	16 ounces
Included Components	4" Tough Stain Tool, HydroRinse Self-Cleaning Hose Tool, 8 oz. BISSELL Little Green Formula

WARRANTY AND SUPPORT

For warranty information, product registration, or further assistance, please visit the official Bissell website or contact their customer support. Keep your purchase receipt for warranty claims.



**Your purchase. Our purpose.
Until every pet has a home.**

Founded by Cathy Bissell in 2011, BISSELL Pet Foundation® is a national animal welfare organization dedicated to ending pet homelessness around the world. Since 2011, BISSELL® has donated more than \$28 million dollars to BISSELL Pet Foundation. Thanks to purchases of BISSELL products and the lifesaving work of BISSELL Pet Foundation, over 939,000 pet lives have been saved.

**Every
Purchase
Saves
Pets™**

Bissell supports the BISSELL Pet Foundation®, with every purchase contributing to their mission of saving pets in need. Since 2011, over \$26 million has been donated.