



[Manuals.plus](#) /

› [GeekTale](#) /

› GeekTale Fingerprint Deadbolt with Passage Door Knob (Model F08) User Manual

GeekTale F08

GeekTale Fingerprint Deadbolt with Passage Door Knob (Model F08) User Manual

Model: F08

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your GeekTale Fingerprint Deadbolt with Passage Door Knob (Model F08). Please read this manual thoroughly before installation and use to ensure proper function and safety. Keep this manual for future reference.

SETUP AND INSTALLATION

The GeekTale Fingerprint Deadbolt is designed for easy installation on standard doors. Follow these steps for a successful setup.

1. Check Door Compatibility and Dimensions

Before installation, verify that your door dimensions are compatible with the lock. The deadbolt is designed to fit standard door preparations.

Check the Lock Size




Image: Diagram illustrating the dimensions of the deadbolt and passage door knob components, along with the required door bore holes. Ensure your door matches these specifications for proper fit.

2. Installation Steps

The installation process is designed to be quick and hassle-free. Refer to the included installation guide for detailed diagrams and step-by-step instructions.




Image: Visual representation of the easy installation process for the GeekTale Fingerprint Deadbolt, highlighting the simplicity of assembly.

3. Initial Battery Charge

The lock features a built-in rechargeable battery. Before first use, ensure the lock is fully charged. A full charge typically lasts up to 6-8 months.

Built-in Rechargeable Battery

Up to 8 Months Battery Life



Image: The GeekTale deadbolt connected to a USB-C charging cable, illustrating the built-in rechargeable battery feature.

4. App Download and Fingerprint Registration

Download the dedicated mobile application to manage your lock. Follow the in-app instructions to register fingerprints (up to 20) and set up other access methods.

Fingerprint Quick Unlock



Image: A hand placing a finger on the deadbolt's sensor, demonstrating the quick fingerprint unlock feature with a 0.3-second recognition speed.

OPERATING INSTRUCTIONS

Your GeekTale Smart Lock offers multiple convenient ways to access your property.

1. Access Methods

- **Fingerprint:** Place your registered finger on the sensor for quick unlocking. The lock recognizes fingerprints in approximately 0.3 seconds.
- **Mobile App:** Use the dedicated mobile application to unlock the door via Bluetooth.
- **Physical Key:** In case of battery depletion or other issues, use the provided physical keys as a backup.

3 Ways to Unlock



Image: A visual guide showing the three primary methods to unlock the deadbolt: fingerprint recognition (up to 20 fingerprints), Bluetooth control via the app, and traditional physical keys.

2. Twist to Lock & Unlock Mechanism

After unlocking via fingerprint or app, twist the exterior knob to open the door. To lock the door, twist the interior panel.

Twist to Unlock & Lock



Image: A split image showing the exterior knob being twisted to unlock and the interior panel being twisted to lock the door, highlighting the intuitive mechanism.

3. Smart App Control Features

The mobile application provides comprehensive control and monitoring capabilities for your lock.

- **Manage Users:** Add or remove authorized users and their fingerprints.
- **View Access Log:** Review a history of who accessed the lock and when.
- **Low Battery Alert:** Receive timely notifications when the battery level is low, typically around 20%.
- **Sound Settings:** Adjust or mute the lock's operational sounds.

Smart App Control

Bluetooth Distance: 10m



Manage Users



View Access Log



Low Battery Alert



Image: A smartphone displaying the lock's mobile app interface, which allows users to manage access, view historical logs, and receive low battery alerts.

4. Remote Unlock with Gateway (Sold Separately)

For remote unlocking and voice control features, a compatible gateway device (sold separately) is required. This gateway connects the lock to your home Wi-Fi network, enabling remote management and real-time notifications.

Remote Unlock with Gateway (Sold Separately)



Image: A diagram illustrating the connection between the smart deadbolt, a gateway device (plugged into an outlet), and a smartphone, enabling remote unlocking and control.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your smart lock.

1. Battery Charging

The built-in rechargeable battery provides power for up to 6-8 months on a single charge. When the low battery alert is received, charge the lock using a USB-C cable. A full charge takes approximately 3 hours.

2. Cleaning

Clean the lock's exterior with a soft, dry cloth. Avoid using abrasive cleaners or solvents, as these can damage the finish and electronic components. Keep the fingerprint sensor clean for accurate recognition.

3. Physical Key Storage

Store the two unique physical keys in a secure location outside your home, accessible only to trusted individuals, for emergency backup access.

TROUBLESHOOTING

If you encounter issues with your GeekTale Fingerprint Deadbolt, refer to the following common solutions.

- **Lock not responding:** Check the battery level. If low, recharge the lock. If fully charged, try using a physical key.
- **Fingerprint not recognized:** Ensure your finger is clean and dry. Try re-registering your fingerprint through the app. Ensure the sensor is clean.
- **App connectivity issues:** Ensure Bluetooth is enabled on your smartphone and you are within range (approximately 10 meters). Try restarting the app or your phone. If using a gateway, ensure it is powered on and connected to Wi-Fi.
- **Lock not charging:** Verify the USB-C cable and power adapter are functioning correctly. Ensure the charging port on the lock is free of debris.
- **Lock not operating in cold weather:** Extreme cold can affect electronic devices. If experiencing issues in low temperatures, consider using the physical key.

If problems persist after attempting these solutions, please contact GeekTale customer support for further assistance.

SPECIFICATIONS

Brand	GeekTale
Model Number	F08
Lock Type	Deadbolt
Material	Aluminum
Color	Black
Item Dimensions (L x W x H)	2.56 x 2.56 x 3.03 inches
Special Features	Store 20 Fingerprints, App Control, Twist to Unlock & Lock, Rechargeable Battery, Easy Install
Control Method	App, Touch
Connectivity Protocol	Bluetooth
Battery Life	Up to 6-8 months on a single charge

WARRANTY INFORMATION

GeekTale products typically come with a limited manufacturer's warranty. For specific details regarding your product's warranty period and terms, please refer to the warranty card included in your product packaging or visit the official GeekTale website.

CUSTOMER SUPPORT

If you require further assistance, have questions about your product, or need to report an issue, please contact GeekTale

customer support. Contact information can typically be found on the official GeekTale website or in your product packaging.

Online Support: Visit the GeekTale official website for FAQs, troubleshooting guides, and contact forms.

Email Support: Refer to your product documentation for the customer service email address.