

boAt Stone Opus

boAt Stone Opus Bluetooth Speaker User Manual

Model: Stone Opus

1. INTRODUCTION

Thank you for purchasing the boAt Stone Opus Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker. Please read it carefully to ensure optimal performance and longevity of your device.

The boAt Stone Opus delivers 80W boAt Signature Sound with a built-in subwoofer, offering a rich audio experience. It features versatile connectivity options, TWS functionality, and up to 12 hours of playback.

2. WHAT'S IN THE BOX

- boAt Stone Opus Speaker
- 1 x Charging Cable
- User Manual

3. PRODUCT OVERVIEW

Familiarize yourself with the main components and controls of your boAt Stone Opus speaker.

80W | boAt SIGNATURE SOUND



Image: Top view of the boAt Stone Opus speaker, highlighting the control panel with knobs for bass, treble, and volume, and buttons for playback and TWS functions.

TYPE - C CHARGING



MULTI - CONNECTIVITY

BT v5.3, AUX, USB, TF CARD



Image: Rear view of the boAt Stone Opus speaker, displaying the Type-C charging port, USB port, AUX input, and TF card slot for various connectivity options.

4. SETUP

4.1 Charging the Speaker

Before first use, fully charge your boAt Stone Opus speaker. Use the provided Type-C charging cable.

1. Connect the Type-C end of the charging cable to the speaker's charging port.
2. Connect the USB-A end to a compatible USB power adapter (not included).
3. The charging indicator light will illuminate. It will turn off or change color once fully charged.

A full charge provides up to 12 hours of playback, depending on volume levels and usage.

4.2 Powering On/Off

- **To Power On:** Press and hold the Power button located on the control panel until the indicator light turns on and you

hear an audible prompt.

- **To Power Off:** Press and hold the Power button until the indicator light turns off and you hear an audible prompt.

5. OPERATING THE SPEAKER

5.1 Bluetooth Pairing

The boAt Stone Opus uses Bluetooth v5.3 for wireless connectivity.

1. Ensure the speaker is powered on and in Bluetooth pairing mode (indicator light will flash).
2. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
3. Select "boAt Stone Opus" from the list of devices.
4. Once connected, you will hear a confirmation tone, and the indicator light will become solid.

5.2 Multilink Connectivity

The Multilink feature allows you to connect the Stone Opus to two devices simultaneously and switch between them seamlessly.

1. Connect the first device to the speaker via Bluetooth as described in section 5.1.
2. Connect the second device to the speaker via Bluetooth. The speaker will automatically prioritize the last connected device for audio playback.
3. To switch between devices, simply pause playback on the current device and start playback on the other connected device.

MULTI LINK

CONNECT & SWITCH BETWEEN 2 DEVICES WITH EASE



LAPTOP



MOBILE




Image: Illustration of the Multilink feature, demonstrating how the boAt Stone Opus can connect to and switch audio sources between a laptop and a mobile phone.

5.3 True Wireless Stereo (TWS) Function

Connect two boAt Stone Opus speakers wirelessly to create a stereo sound experience.

1. Ensure both Stone Opus speakers are powered on and not connected to any other Bluetooth device.
2. On one speaker (this will be the primary speaker), press and hold the TWS button. You will hear an audible prompt indicating TWS pairing mode.
3. The primary speaker will automatically search for the secondary speaker.
4. Once connected, you will hear a confirmation tone, and the indicator lights on both speakers will synchronize.
5. Now, connect your device to the primary speaker via Bluetooth. Audio will play through both speakers in stereo.
6. To disconnect TWS, press and hold the TWS button on either speaker.

TWS FEATURE

CONNECT 2 SPEAKERS IN ONE GO



Image: Two boAt Stone Opus speakers positioned to demonstrate the True Wireless Stereo (TWS) feature, allowing them to connect for a synchronized audio experience.

5.4 Multi-Compatibility (AUX, USB, TF Card)

In addition to Bluetooth, the Stone Opus supports playback via AUX, USB, and TF card.

- **AUX Mode:** Connect an audio device using a 3.5mm AUX cable (not included) to the AUX input port. The speaker will automatically switch to AUX mode.
- **USB Mode:** Insert a USB flash drive containing audio files into the USB port. The speaker will automatically detect and play audio from the drive.
- **TF Card Mode:** Insert a TF (microSD) card containing audio files into the TF card slot. The speaker will automatically detect and play audio from the card.

5.5 Controls

The boAt Stone Opus features intuitive touch controls and rotary knobs for audio adjustment.

- **Volume Knob:** Rotate clockwise to increase volume, counter-clockwise to decrease.
- **Bass Knob:** Adjusts the bass level.
- **Treble Knob:** Adjusts the treble level.
- **Play/Pause Button:** Press once to play or pause audio.
- **Previous/Next Track Buttons:** Press to skip to the previous or next track.
- **TWS Button:** Used for True Wireless Stereo pairing (see section 5.3).

6. MAINTENANCE

Proper care ensures the longevity of your speaker.

- **Cleaning:** Use a soft, dry cloth to clean the speaker's surface. Do not use abrasive cleaners or solvents.
- **Water Exposure:** This speaker is **not waterproof**. Avoid exposure to water, rain, or excessive moisture.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To preserve battery life, charge the speaker regularly, even if not in use for extended periods. Avoid fully discharging the battery frequently.

7. TROUBLESHOOTING

If you encounter issues with your boAt Stone Opus, refer to the following common solutions:

Problem	Solution
Speaker does not power on.	Ensure the battery is charged. Connect the speaker to a power source using the Type-C cable.
Cannot pair via Bluetooth.	Ensure the speaker is in pairing mode. Turn off and on your device's Bluetooth. Clear previous Bluetooth connections on your device. Move closer to the speaker.
No sound from speaker.	Check volume levels on both the speaker and your connected device. Ensure the correct input mode (Bluetooth, AUX, USB, TF) is selected. Check if the speaker is paused.
TWS pairing fails.	Ensure both speakers are powered on and not connected to any other device. Place speakers close to each other during pairing.
Poor audio quality.	Ensure the speaker is within Bluetooth range. Check for interference from other wireless devices. Adjust bass and treble knobs.

8. SPECIFICATIONS

Feature	Detail
Model Name	Stone Opus
Speaker Type	Portable Speaker

Feature	Detail
Speaker Maximum Output Power	80 Watts
Wireless Communication Technology	Bluetooth v5.3
Connectivity Technology	Bluetooth, USB, AUX, TF card
Audio Output Mode	Stereo (with TWS)
Control Method	Touch, Rotary Knobs
Battery Average Life	12 Hours
Battery Type	Lithium Polymer (1 x 12V battery included)
Product Dimensions	26.5D x 17.2W x 15H Centimeters
Item Weight	3 kg
Waterproof	No

9. WARRANTY AND SUPPORT

The boAt Stone Opus Bluetooth Speaker comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal use.

For warranty claims, technical support, or any product-related inquiries, please contact boAt customer service through their official website or the retailer where the product was purchased. Please retain your purchase receipt for warranty validation.

© 2024 boAt. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question