

## CANMOV 635198a9-7cd3-4c2d-b6ed-6c452792ca2e

# CANMOV Manual Recliner Chair User Manual

Brand: CANMOV | Model: 635198a9-7cd3-4c2d-b6ed-6c452792ca2e

## 1. INTRODUCTION

Thank you for choosing the CANMOV Manual Recliner Chair. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your new recliner. Please read these instructions thoroughly before use and retain them for future reference.

The CANMOV Manual Recliner Chair is designed for comfort and relaxation in living rooms, bedrooms, and home theaters. It features a classic and traditional design with comfortable arms and back, upholstered in premium short plush fabric.

## 2. SAFETY INFORMATION

**WARNING: To prevent injury or damage, please adhere to the following safety guidelines:**

- Do not lean to one side or lean forward when the chair is in the open (reclined) position. This can cause instability and lead to falls.
- Do not exceed the maximum weight capacity of 300 lbs (136 kg).
- Keep children and pets away from the reclining mechanism to prevent pinching or injury.
- Ensure all parts are securely assembled before using the chair.
- Place the chair on a level surface to ensure stability.

## 3. PACKAGE CONTENTS

Before assembly, please ensure all components are present. The package typically includes:

- Main Recliner Body (Seat and Backrest)
- Two Side Armrest Pieces (often referred to as 'ears')

*Note: The side armrest pieces (ears) are often packaged within the main body of the chair for shipping. Please check inside the bottom part of the chair or under the seat's metal frame for these components.*

## PRODUCT FUNCTIONS



**Image Description:** A diagram illustrating the packaging of the recliner. It shows the main chair body in a box, with arrows pointing to where the left and right armrest pieces (referred to as 'ears') are typically stored: the left ear at the bottom of the seat's metal frame, and the right ear on the back of the seat. Text advises patience and careful searching for these components.

### 4. SETUP AND ASSEMBLY

The CANMOV Manual Recliner Chair is designed for quick and easy assembly. No special tools are required.

1. **Unpack Components:** Carefully remove all parts from the packaging. Locate the main recliner body and the two side armrest pieces.
2. **Attach Side Armrests:** Align the metal brackets on the side armrest pieces with the corresponding slots on the main recliner body. Slide the armrests down firmly until they click securely into place. Ensure both armrests are stable and do not wobble.
3. **Verify Stability:** Once assembled, gently rock the chair to ensure all connections are secure and the chair is stable on a flat surface.



**Image Description:** A front view of the fully assembled CANMOV Manual Recliner Chair, upholstered in a white-grey fabric, positioned in a living room setting.

## 5. OPERATING INSTRUCTIONS

---

Your manual recliner offers two reclining positions for optimal comfort.

1. **Engaging the Footrest (Standard TV Position):** Locate the lever on the side of the armrest. Pull this lever outwards to raise the footrest. The chair will adjust to a standard TV viewing position.
2. **Full Recline Position:** From the standard TV position, gently lean back against the backrest. Apply slight pressure to push the backrest further back to a maximum of 140 degrees for a full recline.
3. **Returning to Upright Position:** To retract the footrest and return to an upright sitting position, lean forward slightly and use your heels to press against the middle of the footrest. The footrest will lock back into place.



**Image Description:** A diagram illustrating the two-step reclining process. The first step shows pulling a side handle to raise the footrest. The second step shows exerting pressure on the backrest to achieve a deeper recline.

# MULTIPLE ANGLES



**Image Description:** A collage of images demonstrating the recliner in various usage positions: upright for reading, partially reclined for watching television, and fully reclined for napping.

## 6. MAINTENANCE

Proper care will extend the life and appearance of your recliner.

- **Regular Cleaning:** For general cleaning, gently wipe the short plush fabric with a soft, damp cloth. For spills, blot immediately with a clean, dry cloth. Avoid harsh chemicals or abrasive cleaners.
- **Vacuuming:** Periodically vacuum the chair using a soft brush attachment to remove dust and debris.
- **Mechanism Check:** Occasionally inspect the reclining mechanism for any loose screws or components. Tighten as necessary.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading of the fabric. Position your chair away from direct sunlight when possible.

## 7. TROUBLESHOOTING

If you encounter any issues with your recliner, please refer to the following common solutions:

- **Footrest Not Engaging/Retracting:** Ensure the side lever is fully pulled or pushed. Sometimes, a firm


push with the heels on the footrest is needed to fully retract it. Check for any obstructions under the footrest mechanism.

- **Chair Feels Unstable:** Verify that all assembly connections, especially the armrests, are securely fastened. Ensure the chair is on a flat, even surface.
- **Unusual Noises During Reclining:** This may indicate a need for lubrication of the metal parts in the reclining mechanism. Use a silicone-based lubricant sparingly on moving joints.

If the problem persists, please contact CANMOV customer service for assistance.

## 8. SPECIFICATIONS

Feature	Detail
Brand	CANMOV
Model Number	635198a9-7cd3-4c2d-b6ed-6c452792ca2e
Overall Dimensions (W x D x H)	41" x 37" x 40"
Expanded Length	65"
Seat Dimensions (W x D)	21" x 20"
Seat Height	19"
Weight Capacity	300 lbs
Material	Short Plush Fabric, Cotton, Foam, Polyester Fill
Frame Material	Solid Wood
Finish Type	Wood Stain with Metallic Accents (Brass rivets)
Reclining Positions	2 (Standard TV, Full Recline up to 140 degrees)



**Image Description:** A visual representation of the recliner's dimensions, including overall width (41"), depth (37"), height (40"), expanded length (65"), seat width (21"), seat depth (20"), and seat height (19").

## 9. WARRANTY AND SUPPORT

CANMOV provides a **1-year warranty guarantee** for quality problems, damaged, and missing parts. For any purchase-related inquiries or issues, please do not hesitate to contact CANMOV customer service. We are committed to providing helpful, prompt, and friendly customer service.

For support, please visit the [CANMOV Store on Amazon](#) or contact us directly through your purchase platform.