



[Manuals.plus](#) /

> [AINLARRY](#) /

> AINLARRY 36" x 80" Solid Core Pine Wood Bifold Closet Door Instruction Manual

AINLARRY 36" x 80" Solid Core Pine Wood Bifold Closet Door (B0DQL8B57Z)

AINLARRY Solid Core Pine Wood Bifold Closet Door

Model: 36" x 80" (ASIN: B0DQL8B57Z)

1. INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, and maintenance of your AINLARRY 36" x 80" Solid Core Pine Wood Bifold Closet Door. Please read this manual thoroughly before beginning installation or use to ensure proper function and safety.



Image: The AINLARRY 36" x 80" Solid Core Pine Wood Bifold Closet Door in a closed position, showcasing its natural pine finish and classic design.

2. SAFETY INFORMATION

- Always wear appropriate personal protective equipment (PPE) such as safety glasses and gloves during installation.
- Ensure the door opening is properly prepared and free of obstructions before installation.
- Handle door panels with care to avoid injury or damage. They are heavy and require at least two people for safe handling.
- Keep small children and pets away from the installation area.
- Do not hang on the door or apply excessive force, as this may damage the door or hardware.

3. COMPONENTS LIST

Verify that all components are present before beginning installation:

- Preassembled Door Panels (2 panels, each 17.75" W x 77.75" H x 0.85" T)
- Top Pivot
- Bottom Pivot
- Roller
- Knob
- Hinges (pre-attached to panels)
- Top Track with Fascia
- Installation Hardware (screws, anchors, etc.)

4. SETUP AND INSTALLATION

This bifold door is designed for 36" x 80.5" openings. The actual door panel height is 77.75 inches. The top track requires remaining 1-3/4 inches with an additional adjustable range of 3/4 inches. The lower jamb pivot requires 7/8 inches.

4.1 Pre-Installation Checks

1. Measure your door opening carefully. Ensure it is within the recommended dimensions of 36" wide and 80.5" high.
2. Inspect all components for any damage or missing parts.
3. Gather necessary tools: measuring tape, level, drill, screwdriver, pencil.

4.2 Installation Steps

1. **Install Top Track:** Secure the top track with the fascia into the top of the door frame. Ensure it is level and centered. The fascia helps ensure a perfect fit without gaps.
2. **Install Pivots:** Install the top pivot into the pre-drilled hole on the top edge of the door panel. Install the bottom pivot into the floor or bottom jamb, ensuring it is vertically aligned with the top pivot. This vertical alignment is crucial for door stability and smooth sliding.
3. **Attach Roller:** Insert the roller into the top edge of the door panel, near the pivot.
4. **Mount Door Panels:** Carefully lift the door panels and engage the top pivot into the top track. Then, lower the bottom pivot into its receptacle. Engage the roller into the top track.
5. **Adjust and Secure:** Adjust the pivots and roller to ensure the door hangs plumb and operates smoothly. Tighten all fasteners.
6. **Install Knob:** Attach the knob to the pre-drilled hole on the door panel.



Image: A front view of the AINLARRY bifold door, showing its full dimensions and design, useful for visual reference during installation.

5. OPERATING INSTRUCTIONS

To open the bifold door, gently pull the knob towards you and slide the panels along the top track. The door will fold inward, maximizing your opening space. To close, push the panels back along the track until they meet and form a flat surface.



Solid Pine Wood

Image: The AINLARRY bifold door shown partially open, demonstrating its folding mechanism and how it saves space compared to traditional swinging doors.

6. MAINTENANCE

Regular maintenance will ensure the longevity and smooth operation of your bifold door.

- **Cleaning:** Wipe the door panels with a soft, damp cloth to remove dust and dirt. Avoid abrasive cleaners or harsh chemicals that could damage the pine wood finish.
- **Hardware:** Periodically check all screws and fasteners for tightness. Lubricate the top track and pivots with a silicone-based lubricant if the door begins to stick or squeak.
- **Finishing:** The door is unfinished and paintable. You can apply paint, stain, or varnish to match your interior decor. Ensure the door is clean and dry before applying any finish.

Orange 

Blue 

Black 

Brown 

Grey 

Let your imagination run wild, you don't have to settle for plain old white primer

Yellow 

Pink 


Image: An unfinished pine wood door panel, illustrating its paintable surface and the potential for customization to match various interior designs.

7. TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|--|---|---|
| Door sticks or is difficult to open/close. | Track is dirty, rollers are dry, or hardware is loose. | Clean the track, lubricate rollers and pivots with silicone spray, tighten all hardware. |
| Door does not hang plumb or is uneven. | Pivots are not properly adjusted or track is not level. | Adjust top and bottom pivots. Ensure the top track is perfectly level using a spirit level. |
| Door panels rub against each other or the frame. | Misalignment of panels or track. | Check pivot and roller adjustments. Ensure the door opening dimensions are correct. |

8. SPECIFICATIONS

- **Product Dimensions:** 0.83 x 36 x 80 inches (Overall assembled)
- **Each Door Panel:** 17.75" (W) x 77.75" (H) x 0.85" (T)
- **Recommended Opening Size:** 36" (W) x 80.5" (H)
- **Material:** Solid Pine Wood
- **Finish:** Unfinished
- **Item Weight:** Approximately 40 pounds
- **Model Number (ASIN):** B0DQL8B57Z



BIFOLD DOOR SIZE GUIDE

Image: A close-up view of solid pine wood blocks and sawdust, highlighting the natural material used in the construction of the door.

9. WARRANTY INFORMATION

For specific warranty details regarding your AINLARRY bifold door, please refer to the documentation

included with your purchase or contact AINLARRY customer support directly. Warranty terms typically cover manufacturing defects under normal use.

10. SUPPORT

If you have any questions, require assistance with installation, or need to report a missing or damaged part, please contact AINLARRY customer support. You can typically find contact information on the product packaging or the official AINLARRY website.

For more information, visit the [AINLARRY Store on Amazon](#).