

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [OLIXIS](#) /

> [OLIXIS Cross Legged Armless Wide Adjustable Swivel Padded Home Office Desk Chair User Manual](#)

OLIXIS JFPO356

OLIXIS Cross Legged Armless Wide Adjustable Swivel Padded Home Office Desk Chair User Manual

INTRODUCTION

Thank you for choosing the OLIXIS Cross Legged Armless Wide Adjustable Swivel Padded Home Office Desk Chair. This manual provides essential information for the safe assembly, operation, and maintenance of your new chair. Please read these instructions carefully before use and retain them for future reference.

WHAT'S IN THE BOX?

Upon unpacking, please verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- 1 Armless Office Chair
- 1 Set of Assembling Tools
- 1 User Manual (this document)

SETUP AND ASSEMBLY

We strongly recommend reading this user manual completely before beginning the assembly process. Follow the step-by-step instructions provided with the included assembling tools. Ensure all connections are secure before using the chair.



Image: An overview of the OLIXIS Cross Legged Armless Office Chair, illustrating its design, dimensions, and key features such as the wide seat, adjustable height, and swivel base. This image helps in identifying components during assembly.

Important Safety Note: Do not use power tools for assembly as this may overtighten screws and damage the chair components. Hand-tighten all fasteners.

OPERATING INSTRUCTIONS

Your OLIXIS office chair is designed for comfort and versatility. Familiarize yourself with its adjustable

features:

1. Height Adjustment

To adjust the seat height, locate the lever under the seat cushion on the right side. While seated, pull the lever upwards to lower the seat. To raise the seat, stand up and pull the lever upwards. Release the lever at your desired height. The seat height is adjustable from 15.94 inches to 19.69 inches.

2. Tilt Function and Tension

The chair features a tilt function allowing the seat to swing back up to 21 degrees. To activate the tilt, pull the same lever (used for height adjustment) outwards. To lock the chair in an upright position, push the lever inwards. To adjust the tilt tension, turn the round knob located under the seat cushion at the front. Turn clockwise to increase tension (making it harder to recline) and counter-clockwise to decrease tension (making it easier to recline).

3. Swivel Function

The chair is equipped with a 360-degree swivel base, allowing for easy movement and access to different areas around your workspace without needing to reposition the entire chair.

MAINTENANCE

Proper maintenance will extend the life and appearance of your OLIXIS office chair.

- **Cleaning:** For general cleaning, wipe the PU leather and other surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the material.
- **Inspection:** Periodically check all screws and fasteners to ensure they are tight. Re-tighten if necessary to maintain stability and safety.
- **Avoid Overloading:** Do not exceed the recommended weight capacity of the chair.
- **Environment:** Keep the chair away from direct sunlight and extreme temperatures to prevent material degradation.

TROUBLESHOOTING

If you encounter any issues with your chair, please refer to the following common solutions:

- **Chair feels wobbly:** Ensure all assembly screws are securely tightened. Check that the base and casters are properly attached.
- **Height adjustment not working:** Verify that the gas lift lever is fully engaged. If the issue persists, the gas lift mechanism may need replacement.
- **Chair squeaks:** Apply a small amount of silicone lubricant to moving parts, such as the tilt mechanism or caster stems.
- **Casters not rolling smoothly:** Check for debris (hair, dust) caught in the casters and clean them.

If these steps do not resolve the issue, please contact OLIXIS customer support for further assistance.

SPECIFICATIONS

Overall Height:	30.71" - 34.45"
Seat Height:	15.94" - 19.69"

Seat Depth:	18.7"
Seat Width:	25.2"
Back Height:	13.78"
Back Width:	25.2"
Tilt Angle:	Up to 21°
Swivel:	360°
Material:	Upgraded PU Leather
Model Number:	JFPO356
ASIN:	B0DQL9T1QB

WARRANTY AND SUPPORT

OLIXIS stands behind the quality of its products. Your chair comes with a **12-month insurance** (warranty) from the date of purchase. This warranty covers manufacturing defects and material flaws under normal use.

For warranty claims, technical support, or any questions regarding your product, please contact our customer support team. We are committed to providing friendly and easy-to-reach support to ensure your satisfaction.

Please have your model number (JFPO356) and proof of purchase ready when contacting support.