

[Manuals.plus](#) /

› [Bitzee](#) /

› Bitzee Jurassic World Interactive Dinosaur Companion - User Manual

Bitzee 6074096

Bitzee Jurassic World Interactive Dinosaur Companion - User Manual

Model: 6074096

INTRODUCTION

Welcome to the world of Bitzee Jurassic World! This interactive digital companion brings dinosaurs to life in a unique 3D holographic experience. Your Bitzee dinosaur responds to your touch and movements, offering a new way to interact with virtual pets. This manual will guide you through setting up, playing with, and caring for your Bitzee Jurassic World device.

WHAT'S INCLUDED

Your Bitzee Jurassic World package contains the following items:

- 1 Bitzee Jurassic World Interactive Dinosaur Companion
- 1 Quick Start Guide
- 1 Instruction Manual (this document)
- 3 LR6 (AA) Batteries



Image: The Bitzee Jurassic World product packaging, displaying the interactive dinosaur companion and indicating included accessories.

SETUP

Battery Installation

Your Bitzee Jurassic World device comes with 3 LR6 (AA) batteries. To install or replace them:

1. Locate the battery compartment on the underside of the device.
2. Using a Phillips head screwdriver (not included), unscrew the battery compartment cover.
3. Insert 3 new LR6 (AA) batteries, ensuring correct polarity (+/-).
4. Replace the cover and secure it with the screw.

First Use

Once batteries are installed, open the fossil-shaped case. Your first digital dinosaur will appear, ready for interaction.




Image: The Bitzee Jurassic World device, designed as a fossilized dinosaur skull, ready for interaction.

OPERATING INSTRUCTIONS

Interacting with Your Dinosaur

Bitzee dinosaurs are 3D virtual pets that respond to your actions. You can interact with them by:

- **Sliding:** Gently slide your finger across the touch-sensitive area.
- **Tilting:** Tilt the device to make your dinosaur move or react.
- **Touching:** Directly touch the holographic display to pet or interact with your dinosaur.



© 2025 Universal Studios and Amblin Entertainment, Inc. All Rights Reserved.


Fais éclore, grandir & entraîne ton dinosaure

Image: Demonstrates how to interact with the Bitzee device by sliding, tilting, and touching the holographic display, causing the digital dinosaur to react.

Hatching and Growing Dinosaurs

Each dinosaur begins as an egg. Through care and interaction, you can hatch it and help it grow through different life stages:

1. **Hatch:** Interact with the egg until it hatches into a baby dinosaur.
2. **Care:** Feed, play with, and care for your baby dinosaur to help it grow into an adult.
3. **Evolve:** Continue caring for your adult dinosaur to unlock its full potential.



© 2025 Universal Studios and Amblin Entertainment, Inc. All Rights Reserved.

Joue à des jeux & prépare tes dinosaures au combat

Image: Illustrates the process of hatching a dinosaur egg, nurturing it into a baby, and then an adult dinosaur within the Bitzee device.

Training and Mini-Games

To make your dinosaurs stronger and prepare them for battles, engage in training and mini-games:

- Access the mini-game menu through the device's interface.
- Play any of the 6 available mini-games to improve your dinosaur's skills and stats.
- Successful training makes your dinosaur more formidable in battles.



Connecte 2 boîtiers & affronte d'autres dinosaures

Image: Shows the Bitzee device in use, with a digital dinosaur on screen and graphical elements representing game progress and battle readiness.

Connecting and Battling with Friends

You can wirelessly connect two Bitzee Jurassic World devices for interactive battles or dinosaur exchanges:

1. Ensure both devices are powered on and within close proximity.
2. Follow the on-screen prompts to initiate a connection.
3. Once connected, you can choose to battle your friend's dinosaur or exchange characters.
4. Winning battles may reward you with amber, which can be used to customize your dinosaurs.



© 2025 Universal Studios and Amblin Entertainment, Inc. All Rights Reserved.

Découvre & collectionne les 25 personnages dans 1 boîtier !

Image: Two Bitzee Jurassic World devices are shown side-by-side, wirelessly connected, with digital dinosaurs engaged in a battle on their respective screens.

Collecting All 25 Dinosaurs

There are 25 unique Jurassic World dinosaurs to discover and collect within your Bitzee device. Continue playing, exploring, and interacting to unlock them all, including iconic species like T-rex, Triceratops, and Velociraptor.



© 2025 Universal Studios and Amblin Entertainment, Inc. All Rights Reserved.

Boîter en forme de tête de fossile

Image: The Bitzee device is open, showing a digital dinosaur, with an array of 25 pixelated dinosaur characters floating above, representing the full collection.

MAINTENANCE

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, store the Bitzee device in a cool, dry place away from direct sunlight.
- **Battery Care:** Remove batteries if the device will not be used for an extended period to prevent leakage. Dispose of used batteries responsibly.

TROUBLESHOOTING

Problem	Solution
---------	----------

Problem	Solution
Device does not turn on.	Check battery installation. Ensure batteries are new and correctly inserted. Replace if necessary.
Dinosaur is not responding to touch/movement.	Ensure the device is powered on. Try restarting the device. Make sure your fingers are clean and dry for optimal touch interaction.
Cannot connect to another Bitzee device.	Ensure both devices are within close range and powered on. Follow the on-screen instructions carefully for connection.
Display appears dim or flickering.	Batteries may be low. Replace with fresh LR6 (AA) batteries.

SPECIFICATIONS

Brand: Bitzee

Model Number: 6074096

Age Range: 5-99 years

Material: Plastic

Item Dimensions (L x W x H): 14.8 x 11.7 x 17.1 cm (5.8 x 4.6 x 6.7 inches)

Power Source: 3 x LR6 (AA) Batteries (included)

Number of Players: 2 (for connected play)

Theme: Dinosaur, Jurassic World

Educational Objective: Develop responsibility, strategic thinking, basic scientific concepts (DNA extraction).

Characters: T-rex, Triceratops, Velociraptor, and 22 other unique dinosaurs.

WARRANTY AND SUPPORT

Manufacturer Warranty: No explicit manufacturer warranty information is provided in the product details. Please refer to your point of purchase for return or exchange policies.

Manufacturer Contact: For further assistance or inquiries, you may contact Spin Master International:

Address: Kingsfordweg 151, 1043 GR Amsterdam, NL

Customer Support Website: <https://www.spinmaster.com/en-US/customer-support/>

IMPORTANT SAFETY INFORMATION

Please read all instructions before use. Adult supervision is recommended. This toy contains small parts and magnets, which may pose a choking hazard for children under 3 years. This toy produces flashes that may trigger epilepsy in sensitized individuals. Always ensure the battery compartment is securely closed.

PRODUCT VIDEOS

No official seller videos were found in the provided product data to embed in this manual.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question